


Quick Start Guide

Smart Wireless Bullet Camera







Model: E977

Welcome

Thank you for choosing our smart camera. Getting started is easy.


What's Included

 Security Camera
  Antenna
  Alignment Sticker

 Power Adapter
  Wall Mount Screw Sets
  Tight Line Waterproof Kit


 Quick Start Guide

Product Details



1. Connection Preparation


Bring the camera and phone within 1 to 3 feet (30 to 100 centimeters) of the router.



Note: Make sure smart phone is connected with your wireless router.
Please note the camera is only working under 2.4G Wi-Fi, not support 5G Wi-Fi.

2. Get the APP and Account


For the best experience, please download the "Tuya Smart" APP to your smartphone from App Store or Google Play, or you can also scan the QR code below, the APP icon will be displayed after installed successfully.



3. Insert the Micro SD card


As the SD card slot is built-in, so we suggest customers to insert it in factory during assembling. If you need to insert it by yourself, please follow the following instructions.

- Open the in front black glass and unscrew these screws.




4. Connect the power to the camera

Connect the power to the camera by DC12V/1A Power Adapter.




Take out the whole module carefully and find the SD card slot, insert this SD card and restore it.



5. Set up your camera

- Press the Reset button from the tight line cable for above 5 seconds, then release the button to start Reset processing.
- Launch the app from your smartphone and click the Sign Up button. Follow the on-screen instructions.
- Click "Add Device" or "+" on the right corner to add device; Then click "Security&Sensor" to select "Smart Camera";
- Click the button to confirm if the indicator is red and blinking quickly, then input the correct working wifi password to proceed;
- Point the QR code to the camera lens for 15-20cm ; When the indicator turns to blue and blink quickly, click for next step. If failed, please reset and go back to start again




6. Place or Mount Your Camera


You can place your camera on a shelf or other flat surface, or you can mount it to the wall.

To mount your camera to the wall:

- Fasten the mounting screw into the wall, and then mount the camera from the screw.
- If you're mounting the camera to drywall, be sure the plastic drywall anchors that are provided.




Mounting on Wall



Mounting on Ceiling

You're done!

Congratulations! Your camera is set up and ready to go.



CE FCC RoHS

All trademarks are used for reference purposes only. Thanks again for choosing our smart camera! Make life safe in your hands!
Boost security mobility in your smartphone!

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.


Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

尺 寸 公 差			要求		品名	云摄像头 E977 说明书		比例	1 : 1	日 期 DATE	2019.05.07
位 数	尺 寸	角 度									
x / x . x	±1mm	±1°	128g铜版纸， 单黑色两面印刷， RoHS		料号	40610E9770004	设 计 DESIGNED	杨炎月	审 核 CHECKED		
		±1°									
					版 本 FORMAT	A	制 图 DRAWN		批 准 APPROVED		
					深圳奥尼电子股份有限公司 SHENZHEN AONI ELECTRONIC CO., LTD						
记 事			变更NO.	年/月/日							