



802.11b CHANNEL 2, SPURIOUS

30 MHz ~ 3 GHz




802.11b CHANNEL 2, SPURIOUS

2 GHz ~ 25 GHz




802.11b CHANNEL 3 CARRIER LEVEL




802.11b CHANNEL 3, SPURIOUS

2 GHz ~ 25 GHz






802.11b CHANNEL 3, SPURIOUS


30 MHz ~ 3 GHz




802.11b CHANNEL 4 CARRIER LEVEL

802.11b CHANNEL 4, SPURIOUS
30 MHz ~ 3 GHz802.11b CHANNEL 4, SPURIOUS
2 GHz ~ 25 GHz


802.11b CHANNEL 5 CARRIER LEVEL




802.11b CHANNEL 5, SPURIOUS 30 MHz ~ 3 GHz




802.11b CHANNEL 5, SPURIOUS 2 GHz ~ 25 GHz




802.11b CHANNEL 6 CARRIER LEVEL





802.11b CHANNEL 6, SPURIOUS 30 MHz ~ 3 GHz




802.11b CHANNEL 6, SPURIOUS 2 GHz ~ 25 GHz



802.11b CHANNEL 7 CARRIER LEVEL


802.11b CHANNEL 7, SPURIOUS
30 MHz ~ 3 GHz802.11b CHANNEL 7, SPURIOUS
2 GHz ~ 25 GHz

802.11b CHANNEL 8 CARRIER LEVEL




802.11b CHANNEL 8, SPURIOUS

30 MHz ~ 3 GHz




802.11b CHANNEL 8, SPURIOUS

2 GHz ~ 25 GHz




802.11b CHANNEL 9 CARRIER LEVEL




802.11b CHANNEL 9, SPURIOUS

2 GHz ~ 25 GHz






802.11b CHANNEL 9, SPURIOUS


30 MHz ~ 3 GHz




802.11b CHANNEL 10 CARRIER LEVEL

802.11b CHANNEL 10, SPURIOUS
30 MHz ~ 3 GHz802.11b CHANNEL 10, SPURIOUS
2 GHz ~ 25 GHz


802.11b CHANNEL 11 CARRIER LEVEL




802.11b CHANNEL 11, SPURIOUS 30 MHz ~ 3 GHz




802.11b CHANNEL 11, SPURIOUS 2 GHz ~ 25 GHz




802.11g CHANNEL 1 CARRIER LEVEL






802.11g CHANNEL 1, SPURIOUS 30 MHz ~ 3 GHz




802.11g CHANNEL 1, SPURIOUS 2 GHz ~ 25 GHz



802.11g CHANNEL 2 CARRIER LEVEL


802.11g CHANNEL 2, SPURIOUS
30 MHz ~ 3 GHz802.11g CHANNEL 2, SPURIOUS
2 GHz ~ 25 GHz

802.11g CHANNEL 6 CARRIER LEVEL




802.11g CHANNEL 6, SPURIOUS

30 MHz ~ 3 GHz




802.11g CHANNEL 6, SPURIOUS

2 GHz ~ 25 GHz




802.11g CHANNEL 10 CARRIER LEVEL




802.11g CHANNEL 10, SPURIOUS

2 GHz ~ 25 GHz






802.11g CHANNEL 10, SPURIOUS


30 MHz ~ 3 GHz




802.11g CHANNEL 11 CARRIER LEVEL

802.11g CHANNEL 11, SPURIOUS
30 MHz ~ 3 GHz802.11g CHANNEL 11, SPURIOUS
2 GHz ~ 25 GHz


802.11n-20 MHz CHANNEL 1 CARRIER LEVEL




802.11n-20 MHz CHANNEL 1, SPURIOUS 30 MHz ~ 3 GHz




802.11n-20 MHz CHANNEL 1, SPURIOUS 2 GHz ~ 25 GHz



802.11n-20 MHz CHANNEL 2 CARRIER LEVEL






802.11n-20 MHz CHANNEL 2, SPURIOUS 30 MHz ~ 3 GHz



802.11n-20 MHz CHANNEL 2, SPURIOUS 2 GHz ~ 25 GHz



802.11n-20 MHz CHANNEL 6 CARRIER LEVEL

802.11n-20 MHz CHANNEL 6, SPURIOUS
30 MHz ~ 3 GHz802.11n-20 MHz CHANNEL 6, SPURIOUS
2 GHz ~ 25 GHz

802.11n-20 MHz CHANNEL 10 CARRIER LEVEL

