User manual



Read these safety instructions before using the device and store them for future reference.

This OWs Open Blue Tooth Headset, when using the YKY-5headset connected to the device, even when performing otheractivities (such as fitness), still can listen to music and answer calls.Before using their mobile devices, make sure they are compatible with this device.

Be careful not to wet the equipment when using it. If the equipment is damaged by water, it may malfunction. Avoid storing or using the device at temperatures lower than -15°C or higher than 55°C, which could shorten the headset or battery life.

Specifications

Modelo : YKY-5 Bluetooth Version: V 5.4 Bluetooth Bange: 10meters Plavback time: 6-7 hours Charging time: 1-1.5 hour Standby time: 100 hours


Accessories:

1*user manual 1*type-c charging cable

Key function diagram

Charging box





Use headphones

- 1. Insert the headset into the acupoint of the headset charging box correctly. If the indicator light does not blink, connect the charging box to the charger and charge it for more than 10 minutes.
- 2. Close the charging box.
- 3. Open the charging box and take out the headset, the headset will automatically enter the pairing mode
- 4. On your mobile device, launch the Bluetooth feature search for "YKY-5" to connect it to your mobile device.

5. When the YKY-5 headset is connected, the pairing can be completed.

Touch control

Double-click	Left headphone	Previous song
Double-click	Right headphone	Next song
Three hits	Left headphone	Volume down
Three hits	Right headphone	Volume up

Function	Touch pannel	
Answer calls	Single Touch	
Reject incoming call	Long press (2 seconds)	
Redial last number	Single Touch	
Voice Assistant	Third times Touch	
Language switching	Double-click twice when not connected	

When the left and right ears cannot pair. Please click four times when not connected to your phone Earphones (both sides need to be pushed). After four clicks take effect, it will automatically shut down. The reset is now complete.Put the earphones into the charging compartment and take them out to pair them again

Charging

You need to charge your device for 10 minutes before using it for the first time or after a long period of absence

When the battery of the earplug is low, it will issue "Please charge" which can put the earphone into the charging box. When the earphone is charging, the red light will be displayed, and the light will be off if the charge is slow.Please close the charging case when storing or charging the headphones.

The charging case has a built-in battery, please use a type-c cable to charge it box, then connect it to a computing or other charger for charging, charging When charging, the indicator light flashes, and the fully charged indicator light is always on.

ECC Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

Any Changes or modifications not expressly approved by the party responsible fo compliance could void the user's authority to operate the equipment. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver -Connect the equipment into an outlet on a circuit different from that to which the

-Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction



使用说明书



在使用设备之前, 请阅读这些安全说明, 并将它们存储起来、以备将来参考

此款OWS开放式蓝牙耳机,使用时将YKY-5耳机连接到 设备后,即使是进行其他活动的时候(例如健身),仍然可 以听音乐和接听来电。使用其移动设备前,请确保它们与 本设备兼容。

使用时注意不要弄湿设备,如果设备因水受损, 可能会发生故障。 避免将设备储存或使用于温度低于-15℃或者高 于55℃的环境否则会缩短耳机或电池寿命。

参数

蓝牙版本:v5.4 蓝牙范围:10米 播放时间:6-7小时 充电时间:1-1.5小时 待机时间:100小时

配件:

1*使用说明书 1*Type-c充电线

按键功能示意图

充电盒



耳机



使用耳机

1.将耳机正确的插入耳机充电盒穴位中,如果指示灯没 有闪烁,将充电盒连接到充电器为其充电10分钟以上。 2.关闭充电盒。 3.打开充电盒, 取出耳机后, 耳机将自动进入配对模式。 4.在移动设备上,启动蓝牙功能搜索"YKY5"将其连接 至移动设备。 5.当已经连接了YKY-5 耳机后,即可完成配对。

功能使用

-27 HG IX 74				
双击	左耳机	上一曲		
双击	右耳机	下一曲		
三击	左耳机	音量减		
三击	右耳机	音量加		
功能	按键			
接听电话	单击			
拒接来电	长按1秒			
挂断电话	単击			
语音助手	长按耳机功能键 2 秒			
语言切换	在未连接状态下双击触摸区			

当出现左右耳无法配对时。请在未与手机连接状态下四击 耳机(左右都需操作)。四击生效后会自动关机。即完成重置。 再将耳机放入充电仓后拿出即可重新配对。

充电

初次使用耳机前或长时间未用耳机后,需要充电10 分钟才能使用设备。

当耳塞电量不足时,会发出"Please charge"可以 将耳机放进充好的充电盒,耳机充电时将显示红灯,充 满灯灭。存放耳机或耳机充电时,请合上充电盒。

充电盒配有内置电池,请使用type-c电缆与其充电 盒连接,然后将其连接到电脑或其他充电器进行充电,充 电时,指示灯闪烁,充满电指示灯常亮。

