






NTNV-n41-PC2-30-40-L-DFT-256QAM-Outer_Full-Ant1-PASS



NTNV-n41-PC2-30-40-L-CP-QPSK-Outer_Full-Ant1-PASS




NTNV-n41-PC2-30-40-L-CP-16QAM-Outer_Full-Ant1-PASS




NTNV-n41-PC2-30-40-L-CP-64QAM-Outer_Full-Ant1-PASS




NTNV-n41-PC2-30-40-L-CP-256QAM-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-40-M-DFT-BPSK-Outer_Full-Ant1-
PASS



NTNV-n41-PC2-30-40-M-DFT-QPSK-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-40-M-DFT-16QAM-Outer_Full-Ant1-
PASS







NTNV-n41-PC2-30-40-M-CP-64QAM-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-40-M-CP-256QAM-Outer_Full-Ant1-
PASS



NTNV-n41-PC2-30-40-H-DFT-BPSK-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-40-H-DFT-QPSK-Outer_Full-Ant1-
PASS







NTNV-n41-PC2-30-40-H-CP-16QAM-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-40-H-CP-64QAM-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-40-H-CP-256QAM-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-50-L-DFT-BPSK-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-50-L-DFT-QPSK-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-50-L-DFT-16QAM-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-50-L-DFT-64QAM-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-50-L-DFT-256QAM-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-50-L-CP-QPSK-Outet_Full-Ant1-PASS




NTNV-n41-PC2-30-50-L-CP-16QAM-Outet_Full-Ant1-PASS





NTNV-n41-PC2-30-50-L-CP-64QAM-Outet_Full-Ant1-PASS




NTNV-n41-PC2-30-50-L-CP-256QAM-Outet_Full-Ant1-PASS








NTNV-n41-PC2-30-50-M-CP-256QAM-Outer_Full-Ant1-
PASS



NTNV-n41-PC2-30-50-H-DFT-BPSK-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-50-H-DFT-QPSK-Outer_Full-Ant1-
PASS



NTNV-n41-PC2-30-50-H-DFT-16QAM-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-50-H-DFT-64QAM-Outer_Full-Ant1-
PASS



NTNV-n41-PC2-30-50-H-DFT-256QAM-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-50-H-CP-QPSK-Outer_Full-Ant1-PASS




NTNV-n41-PC2-30-50-H-CP-16QAM-Outer_Full-Ant1-
PASS



NTNV-n41-PC2-30-50-H-CP-64QAM-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-50-H-CP-256QAM-Outer_Full-Ant1-
PASS



NTNV-n41-PC2-30-60-L-DFT-BPSK-Outer_Full-Ant1-
PASS



NTNV-n41-PC2-30-60-L-DFT-QPSK-Outer_Full-Ant1-
PASS






NTNV-n41-PC2-30-60-L-CP-16QAM-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-60-L-CP-64QAM-Outer_Full-Ant1-
PASS



NTNV-n41-PC2-30-60-L-CP-256QAM-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-60-M-DFT-BPSK-Outer_Full-Ant1-
PASS







NTNV-n41-PC2-30-60-M-CP-QPSK-Outet_Full-Ant1-PASS




NTNV-n41-PC2-30-60-M-CP-16QAM-Outet_Full-Ant1-PASS




NTNV-n41-PC2-30-60-M-CP-64QAM-Outet_Full-Ant1-PASS




NTNV-n41-PC2-30-60-M-CP-256QAM-Outet_Full-Ant1-PASS




NTNV-n41-PC2-30-60-H-DFT-BPSK-Outer_Full-Ant1-
PASS



NTNV-n41-PC2-30-60-H-DFT-QPSK-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-60-H-DFT-16QAM-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-60-H-DFT-64QAM-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-60-H-DFT-256QAM-Outer_Full-Ant1-PASS



NTNV-n41-PC2-30-60-H-CP-QPSK-Outer_Full-Ant1-PASS




NTNV-n41-PC2-30-60-H-CP-16QAM-Outer_Full-Ant1-PASS




NTNV-n41-PC2-30-60-H-CP-64QAM-Outer_Full-Ant1-PASS




NTNV-n41-PC2-30-60-H-CP-256QAM-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-70-L-DFT-BPSK-Outer_Full-Ant1-
PASS





NTNV-n41-PC2-30-70-L-DFT-QPSK-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-70-L-DFT-16QAM-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-70-L-CP-64QAM-Outer_Full-Ant1-
PASSNTNV-n41-PC2-30-70-L-CP-256QAM-Outer_Full-Ant1-
PASSNTNV-n41-PC2-30-70-M-DFT-BPSK-Outer_Full-Ant1-
PASSNTNV-n41-PC2-30-70-M-DFT-QPSK-Outer_Full-Ant1-
PASS







NTNV-n41-PC2-30-70-M-CP-16QAM-Outer_Full-Ant1-
PASS



NTNV-n41-PC2-30-70-M-CP-64QAM-Outer_Full-Ant1-
PASS



NTNV-n41-PC2-30-70-M-CP-256QAM-Outer_Full-Ant1-
PASS



NTNV-n41-PC2-30-70-H-DFT-BPSK-Outer_Full-Ant1-
PASS