

KEEP THIS INSTRUCTION MANUAL AS IT CONTAINS  
IMPORTANT INFORMATION FOR FUTURE REFERENCE.  
DUE TO CONTINUOUS PRODUCT IMPROVEMENTS,  
THE PICTURES ON THIS MANUAL MAY DIFFER  
SLIGHTLY FROM THE ACTUAL PRODUCT.

- IPX7 Waterproofing
- Defogging
- Mountable

## FEATURES

- SpaStudio™ Fogless Mirror
- Wall Mount
- Charging Dock
- Charging Cable

## CONTENTS

## FCC STATEMENT

This device complies with part 15 of the FCC Rules.  
Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received,  
including interference that may cause undesired  
operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## SAFETY WARNINGS: PLEASE READ BEFORE USE

- Not a children's item. Keep out of reach of children.
- Install mirror in an area where it will not be accidentally struck.
- Inspect the product before every use. If the product appears worn, frayed, cracked, or broken in any manner, discontinue use and discard immediately.
- Do not submerge in water.
- Do not place the mirror in a location where water will directly fall onto it.
- Do not disassemble.
- Do not use for anything other than its intended purpose.
- Do not charge in shower or when items are wet.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



THE BLUETOOTH® WORD MARK AND LOGOS ARE  
REGISTERED TRADEMARKS OWNED BY BLUETOOTH  
SIG, INC.

SHARPER IMAGE® NAME AND LOGOS (INCLUDING  
THE 77 LOGO AND TOMORROW'S TOMORROW) ARE  
TRADEMARKS OR REGISTERED TRADEMARKS.  
DISTRIBUTED BY AND © 2021 MERCHSOURCE, LLC,  
IRVINE, CA 92618. ALL RIGHTS RESERVED.

PRINTED IN CHINA.




SHARPER IMAGE®

SPASTUDIO™  
FOGLESS MIRROR




# GETTING STARTED

## 01 CHARGE




- 1. Make sure the mirror, dock, and charging cable are completely dry.
- 2. Attach the small end of the USB charging cable to the dock.
- 3. Attach the other end of the cable to a USB port.
- 4. Place mirror onto charging dock.

## 02 CONNECT




- 1. Place your Bluetooth enabled device within 3 feet of the mirror.
- 2. Enable Bluetooth on your device and search for new Bluetooth devices.
- 3. Press and hold the power button to turn mirror on.
- 4. Select SI Fogless Mirror Speaker from the list of Bluetooth devices.

## 03 MOUNT




- 1. Clean and dry a flat, hard surface where the mounting plate will be placed. Ensure the location is not directly underneath falling water and not in an area where it can be accidentally struck.
- 2. Peel the red sticker from the plate.
- 3. Firmly press the plate onto the area for at least 1 minute.
- 4. Wait 30 minutes then connect the magnetic back of the mirror to the plate.

# USING YOUR MIRROR



- Once connected, use your device to stream music to the speaker.
- Hold and press the multifunction button/knob to disconnect the current device and connect a new device.
- Speaker will power off after 10 minutes of no connection.
- Charge when LED Indicator begins to flash.
- Hard reset by pressing the power button for 12 seconds.

# COMPATIBLE WITH



# RECHARGEABLE BATTERY WARNINGS:

- This product contains batteries that are non-replaceable.
- There is a risk of fire and personal injury if battery is punctured, damaged, or misused.
- Do not dismantle, crush, incinerate or short-circuit battery.
- Never expose battery to extreme temperatures or moisture.
- Keep away from flammable materials and direct sunlight.
- Only charge using the provided charger, cable, and/or adapters.
- Rechargeable battery is only to be charged by an adult.
- Adult supervision is required while charging the battery.
- Allow battery to cool to room temperature before charging.
- Charge on a non-flammable surface and keep away from flammable products.
- Discontinue charging if battery becomes hot, swells, smokes, or gives off a strong odor.
- Battery chargers used with the product are to be regularly examined for damage to the cord, plug, enclosure, and other parts. In the event of such damage, chargers must not be used until the damage has been repaired.
- Recycle or dispose of battery according to federal, state, and local laws.
- Keep these instructions for future reference.