

PROPELLER INSTALLATION

Propeller A

Lock the propeller into 2 screws

AIRCRAFT BATTERY AND REMOTE CONTROL CHARGIN

Please ensure that all propellers are installed in the correct orientation according to the

Lock the propeller into 2 screws

Press and hold the buckle on the battery,

The red light stays on during charging

Full of green lights constantly on

then pull it back to remove the battery

from the drone.

— 7 —

following diagram. If installed incorrectly, the aircraft will not be able to fly normally.

PDF