






NTNV-n77(3450-3550)-PC2-30-30-L-CP-256QAM-
Outer_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-30-M-DFT-BPSK-
Outer_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-30-M-DFT-QPSK-
Outer_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-30-M-DFT-16QAM-
Outer_Full-Ant1-PASS

