Size: H: 100mm x W: 194mm




GAMING SOUNDBAR


Instruction Manual

Thank you for purchasing the Gaming Soundbar This manual provides more information about this Gaming Soundbar, please read the instructions before using.



Product Overview





Package Contents

1(One) Gaming Soundbar:11in. x 1.9in. x 2.4in. (28cm x 4.8cm x 6cm) 1(One) Charging Cable 19.7 in. (50 cm) 1(One) Instruction Manual

Power On/Off


Power on

Long press the DI Button to turn on the speaker

Solutions

Long press the DII Button again to turn off the speaker

How to use



Power On/Off Long Press to turn On/Off the speaker.

> Play/Pause the music Short Press to turn On/Off the speaker.

On/Off the light
Double Short Press to turn On/Off the LED light.

Volume Down Long Press to decrease the volume.

Previous song Short Press to play previous song.

Volume Up Long Press to increase the volume.

Next song Short Press to play Next song.

Pair Wireless speaker with your mobile device

- 1. Keep the distance between your wireless speaker and mobile phone (or other devices) within 32.8 Feet.
- 2 Power on the wireless speaker
- 3. Activate the Bluetooth function on your phone within range and select 'GA-0071" from the list shown.
- 4. You will hear a beep sound when pairing is successful.

Reconnect Wireless speaker to your mobile device

When powered on, the wireless speaker will automatically connect with the last

Charging your wireless speaker with charging cable

- 1. Use the Micro USB charging cable provided with this wireless speaker.
- 2. Connect the Micro USB plug to Micro USB charging port on the speaker, then connect the USB plug to wall adapter to begin charging,
- 3. The light will turn red while charging and will turn off once fully charged.

- You must select a qualified charger from a regular manufacturer
- You must charge the Wireless speaker if it has been not used for more than 12 months.



Technical Specification

Driver Diameter: 52 mm Impedance : 4 Ohms

Charging Time: 1.5 Hours Power Supply: Li-Ion Battery 3.7V 300 mAh

Bluetooth Range: 32.8 feet

Playing Time: 1 hour (different environment condition will affect play time) Micro USB Charging Cable Included

Remarks

This is not a toy. Do not let children use unsupervised. Avoid dropping the unit. Do not hit/beat the unit. Do not repair the unit by yourself, should have a qualified technician

FAQ

Questions

Bluetooth mode

Unsuccessful 1. Make sure the speaker has not been connected with Pairing for the other device. Connection 2.Check if there are many Bluetooth device working around, which may interfere the Bluetooth connection 3. Try to restart the Bluetooth of the phone or tablet and reconnect the speaker again. No voice of 1. Check the volume of your phone or the speaker, Distortion of and adjust the volume. sound 2. Check if the battery is too low ,Please recharge it 1.Check if the device is beyond the effective Music breaking connection distance. play 2.Check if there is any obstacle between the speaker and your device. The indicator 1.The battery is low. Please charge it. not shining in

⚠ Safety instructions for the lithium battery and charging the product

2.Please reboot the speaker.

- -The input voltage to the product is DC 5V 1A.
- -In order to charge the product in safe manner and reliable conditions, please only adopt certified appropriate charger/ adapter for charging the product.
- -Only charge the product at ambient temperatures between 10 deg °C/50 deg °F and 40 deg °C/104 deg °F.
- Do not heat above 70 deg °C/158 deg °F, eg. Do not expose to sunlight or throw into fire. -Switch off the product after use.
- -Please note that we won't take any responsibility for any wrong operation (eg. Voltage higher than 5V) as this may result in severe injury or loss of property, and we cannot control the operating process during the time the user using this product.
- In extreme cases, abuse or misuse of Lithium battery pack can lead to explosion, heat generation, fire development or smoke development

ECC STATEMENT

- 1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may
- 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the ECC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Item#GA-0071



Class 1 LED product

FCC ID: 2ADM5-GA-0071

Distributed by 1616 Holdings, Inc. 701 Market Street, Suite 200 Philadelphia, PA 19106

