





2-2-20MHz-20MHz-64QAM@64QAM-64QAM@64QAM-1
8700-18898-1RB#99@100RB#0-0RB#0@100RB#0-PAS

S




2-2-20MHz-20MHz-64QAM@64QAM-64QAM@64QAM-1
8700-18898-100RB#0@100RB#0-100RB#0@100RB#0-P


ASS




2-2-20MHz-20MHz-QPSK@QPSK-QPSK@QPSK-18902-
19100-1RB#0@100RB#0-0RB#0@100RB#0-PASS




2-2-20MHz-20MHz-QPSK@QPSK-QPSK@QPSK-18902-
19100-1RB#0@100RB#0-1RB#99@100RB#0-PASS




2-2-20MHz-20MHz-QPSK@QPSK-QPSK@QPSK-18902-
19100-1RB#99@100RB#0-0RB#0@100RB#0-PASS




2-2-20MHz-20MHz-QPSK@QPSK-QPSK@QPSK-18902-
19100-100RB#0@100RB#0-100RB#0@100RB#0-PASS




2-2-20MHz-20MHz-16QAM@16QAM-16QAM@16QAM-1
8902-19100-1RB#0@100RB#0-0RB#0@100RB#0-PASS




2-2-20MHz-20MHz-16QAM@16QAM-16QAM@16QAM-1
8902-19100-1RB#0@100RB#0-1RB#99@100RB#0-PAS
S




2-2-20MHz-20MHz-16QAM@16QAM-16QAM@16QAM-1
8902-19100-1RB#99@100RB#0-0RB#0@100RB#0-PAS
S



2-2-20MHz-20MHz-16QAM@16QAM-16QAM@16QAM-1
8902-19100-100RB#0@100RB#0-100RB#0@100RB#0-P
ASS



2-2-20MHz-20MHz-64QAM@64QAM-64QAM@64QAM-1





2-2-20MHz-20MHz-64QAM@64QAM-64QAM@64QAM-1

8902-19100-1RB#0@100RB#0-0RB#0@100RB#0-PASS

8902-19100-1RB#0@100RB#0-1RB#99@100RB#0-PAS

S



2-2-20MHz-20MHz-64QAM@64QAM-64QAM@64QAM-1



2-2-20MHz-20MHz-64QAM@64QAM-64QAM@64QAM-1

8902-19100-1RB#99@100RB#0-0RB#0@100RB#0-PAS

8902-19100-100RB#0@100RB#0-100RB#0@100RB#0-P

S

ASS





5-5-3MHz-5MHz-QPSK@QPSK-QPSK@QPSK-20416-20


5-5-3MHz-5MHz-QPSK@QPSK-QPSK@QPSK-20416-20

455-1RB#0@15RB#0-0RB#0@25RB#0-PASS


455-1RB#0@15RB#0-1RB#24@25RB#0-PASS




5-5-3MHz-5MHz-QPSK@QPSK-QPSK@QPSK-20416-20
455-1RB#14@15RB#0-0RB#0@25RB#0-PASS




5-5-3MHz-5MHz-QPSK@QPSK-QPSK@QPSK-20416-20
455-15RB#0@15RB#0-25RB#0@25RB#0-PASS




5-5-3MHz-5MHz-16QAM@16QAM-16QAM@16QAM-204
16-20455-1RB#0@15RB#0-0RB#0@25RB#0-PASS




5-5-3MHz-5MHz-16QAM@16QAM-16QAM@16QAM-204
16-20455-1RB#0@15RB#0-1RB#24@25RB#0-PASS



5-5-3MHz-5MHz-16QAM@16QAM-16QAM@16QAM-204
16-20455-1RB#14@15RB#0-0RB#0@25RB#0-PASS




5-5-3MHz-5MHz-16QAM@16QAM-16QAM@16QAM-204
16-20455-15RB#0@15RB#0-25RB#0@25RB#0-PASS




5-5-3MHz-5MHz-64QAM@64QAM-64QAM@64QAM-204

5-5-3MHz-5MHz-64QAM@64QAM-64QAM@64QAM-204


16-20455-1RB#0@15RB#0-0RB#0@25RB#0-PASS




16-20455-1RB#0@15RB#0-1RB#24@25RB#0-PASS




5-5-3MHz-5MHz-64QAM@64QAM-64QAM@64QAM-204
16-20455-1RB#14@15RB#0-0RB#0@25RB#0-PASS




5-5-3MHz-5MHz-64QAM@64QAM-64QAM@64QAM-204
16-20455-15RB#0@15RB#0-25RB#0@25RB#0-PASS



5-5-3MHz-5MHz-QPSK@QPSK-QPSK@QPSK-20586-20
625-1RB#0@15RB#0-0RB#0@25RB#0-PASS




5-5-3MHz-5MHz-QPSK@QPSK-QPSK@QPSK-20586-20
625-1RB#0@15RB#0-1RB#24@25RB#0-PASS




5-5-3MHz-5MHz-QPSK@QPSK-QPSK@QPSK-20586-20
625-1RB#14@15RB#0-0RB#0@25RB#0-PASS


5-5-3MHz-5MHz-QPSK@QPSK-QPSK@QPSK-20586-20
625-15RB#0@15RB#0-25RB#0@25RB#0-PASS




5-5-3MHz-5MHz-16QAM@16QAM-16QAM@16QAM-205
86-20625-1RB#0@15RB#0-0RB#0@25RB#0-PASS




5-5-3MHz-5MHz-16QAM@16QAM-16QAM@16QAM-205
86-20625-1RB#0@15RB#0-1RB#24@25RB#0-PASS




5-5-3MHz-5MHz-16QAM@16QAM-16QAM@16QAM-205
86-20625-1RB#14@15RB#0-0RB#0@25RB#0-PASS




5-5-3MHz-5MHz-16QAM@16QAM-16QAM@16QAM-205
86-20625-15RB#0@15RB#0-25RB#0@25RB#0-PASS




5-5-3MHz-5MHz-64QAM@64QAM-64QAM@64QAM-205
86-20625-1RB#0@15RB#0-0RB#0@25RB#0-PASS




5-5-3MHz-5MHz-64QAM@64QAM-64QAM@64QAM-205
86-20625-1RB#0@15RB#0-1RB#24@25RB#0-PASS




5-5-3MHz-5MHz-64QAM@64QAM-64QAM-205
86-20625-1RB#14@15RB#0-0RB#0@25RB#0-PASS




5-5-3MHz-5MHz-64QAM@64QAM-64QAM-205
86-20625-15RB#0@15RB#0-25RB#0@25RB#0-PASS




5-5-5MHz-3MHz-QPSK@QPSK-QPSK-20425-20
464-1RB#0@25RB#0-0RB#0@15RB#0-PASS




5-5-5MHz-3MHz-QPSK@QPSK-QPSK-20425-20
464-1RB#0@25RB#0-1RB#15@15RB#0-PASS




5-5-5MHz-3MHz-QPSK@QPSK-QPSK-20425-20
464-1RB#24@25RB#0-0RB#0@15RB#0-PASS




5-5-5MHz-3MHz-QPSK@QPSK-QPSK-20425-20
464-25RB#0@25RB#0-15RB#0@15RB#0-PASS




5-5-5MHz-3MHz-16QAM@16QAM-16QAM@16QAM-204
25-20464- 1RB#0@25RB#0-0RB#0@15RB#0-PASS




5-5-5MHz-3MHz-16QAM@16QAM-16QAM@16QAM-204
25-20464-1RB#0@25RB#0-1RB#15@15RB#0-PASS




5-5-5MHz-3MHz-16QAM@16QAM-16QAM@16QAM-204
25-20464-1RB#24@25RB#0-0RB#0@15RB#0-PASS




5-5-5MHz-3MHz-16QAM@16QAM-16QAM@16QAM-204
25-20464-25RB#0@25RB#0-15RB#0@15RB#0-PASS




5-5-5MHz-3MHz-64QAM@64QAM-64QAM@64QAM-204
25-20464- 1RB#0@25RB#0-0RB#0@15RB#0-PASS




5-5-5MHz-3MHz-64QAM@64QAM-64QAM@64QAM-204
25-20464-1RB#0@25RB#0-1RB#15@15RB#0-PASS




5-5-5MHz-3MHz-64QAM@64QAM-64QAM-204
25-20464-1RB#24@25RB#0-0RB#0@15RB#0-PASS




5-5-5MHz-3MHz-64QAM@64QAM-64QAM-204
25-20464-25RB#0@25RB#0-15RB#0@15RB#0-PASS




5-5-5MHz-3MHz-QPSK@QPSK-QPSK-20595-20
634-1RB#0@25RB#0-0RB#0@15RB#0-PASS




5-5-5MHz-3MHz-QPSK@QPSK-QPSK-20595-20
634-1RB#0@25RB#0-1RB#15@15RB#0-PASS




5-5-5MHz-3MHz-QPSK@QPSK-QPSK-20595-20
634-1RB#24@25RB#0-0RB#0@15RB#0-PASS




5-5-5MHz-3MHz-QPSK@QPSK-QPSK-20595-20
634-25RB#0@25RB#0-15RB#0@15RB#0-PASS




5-5-5MHz-3MHz-16QAM@16QAM-16QAM@16QAM-205
95-20634- 1RB#0@25RB#0-0RB#0@15RB#0-PASS




5-5-5MHz-3MHz-16QAM@16QAM-16QAM@16QAM-205
95-20634-1RB#0@25RB#0-1RB#15@15RB#0-PASS




5-5-5MHz-3MHz-16QAM@16QAM-16QAM@16QAM-205
95-20634-1RB#24@25RB#0-0RB#0@15RB#0-PASS




5-5-5MHz-3MHz-16QAM@16QAM-16QAM@16QAM-205
95-20634-25RB#0@25RB#0-15RB#0@15RB#0-PASS




5-5-5MHz-3MHz-64QAM@64QAM-64QAM@64QAM-205
95-20634- 1RB#0@25RB#0-0RB#0@15RB#0-PASS




5-5-5MHz-3MHz-64QAM@64QAM-64QAM@64QAM-205
95-20634-1RB#0@25RB#0-1RB#15@15RB#0-PASS




5-5-5MHz-3MHz-64QAM@64QAM-64QAM-205
95-20634-1RB#24@25RB#0-0RB#0@15RB#0-PASS




5-5-5MHz-3MHz-64QAM@64QAM-64QAM-205
95-20634-25RB#0@25RB#0-15RB#0@15RB#0-PASS




5-5-10MHz-10MHz-QPSK@QPSK-QPSK-20450-
20549-1RB#0@50RB#0-0RB#0@50RB#0-PASS




5-5-10MHz-10MHz-QPSK@QPSK-QPSK-20450-
20549-1RB#0@50RB#0-1RB#49@50RB#0-PASS




5-5-10MHz-10MHz-QPSK@QPSK-QPSK-20450-
20549-1RB#49@50RB#0-0RB#0@50RB#0-PASS




5-5-10MHz-10MHz-QPSK@QPSK-QPSK-20450-
20549-50RB#0@50RB#0-50RB#0@50RB#0-PASS




5-5-10MHz-10MHz-16QAM@16QAM-16QAM@16QAM-2
0450-20549-1RB#0@50RB#0-0RB#0@50RB#0-PASS




5-5-10MHz-10MHz-16QAM@16QAM-16QAM@16QAM-2
0450-20549-1RB#0@50RB#0-1RB#49@50RB#0-PASS




5-5-10MHz-10MHz-16QAM@16QAM-16QAM@16QAM-2
0450-20549-1RB#49@50RB#0-0RB#0@50RB#0-PASS




5-5-10MHz-10MHz-16QAM@16QAM-16QAM@16QAM-2
0450-20549-50RB#0@50RB#0-50RB#0@50RB#0-PASS




5-5-10MHz-10MHz-64QAM@64QAM-64QAM@64QAM-2
0450-20549-1RB#0@50RB#0-0RB#0@50RB#0-PASS




5-5-10MHz-10MHz-64QAM@64QAM-64QAM@64QAM-2
0450-20549-1RB#0@50RB#0-1RB#49@50RB#0-PASS




5-5-10MHz-10MHz-64QAM@64QAM-64QAM-2
0450-20549-1RB#49@50RB#0-0RB#0@50RB#0-PASS




5-5-10MHz-10MHz-64QAM@64QAM-64QAM-2
0450-20549-50RB#0@50RB#0-50RB#0@50RB#0-PASS




5-5-10MHz-10MHz-QPSK@QPSK-QPSK@QPSK-20501-
20600-1RB#0@50RB#0-0RB#0@50RB#0-PASS




5-5-10MHz-10MHz-QPSK@QPSK-QPSK@QPSK-20501-
20600-1RB#0@50RB#0-1RB#49@50RB#0-PASS




5-5-10MHz-10MHz-QPSK@QPSK-QPSK@QPSK-20501-
20600-1RB#49@50RB#0-0RB#0@50RB#0-PASS




5-5-10MHz-10MHz-QPSK@QPSK-QPSK@QPSK-20501-
20600-50RB#0@50RB#0-50RB#0@50RB#0-PASS




5-5-10MHz-10MHz-16QAM@16QAM-16QAM@16QAM-2
0501-20600-1RB#0@50RB#0-0RB#0@50RB#0-PASS




5-5-10MHz-10MHz-16QAM@16QAM-16QAM@16QAM-2
0501-20600-1RB#0@50RB#0-1RB#49@50RB#0-PASS




5-5-10MHz-10MHz-16QAM@16QAM-16QAM@16QAM-2
0501-20600-1RB#49@50RB#0-0RB#0@50RB#0-PASS



5-5-10MHz-10MHz-16QAM@16QAM-16QAM@16QAM-2
0501-20600-50RB#0@50RB#0-50RB#0@50RB#0-PASS



5-5-10MHz-10MHz-64QAM@64QAM-64QAM@64QAM-2
0501-20600-1RB#0@50RB#0-0RB#0@50RB#0-PASS



5-5-10MHz-10MHz-64QAM@64QAM-64QAM@64QAM-2
0501-20600-1RB#0@50RB#0-1RB#49@50RB#0-PASS