

Brand : MOMAX

Model Name : KMIC PRO Mobile Karaoke Microphone

Model Number : IM2

Specification

Power Supply: Built-in 3.7V Li-ion rechargeable battery

Capacity: 2500mAh

Battery Life: Approx. 4 hour (full charge)

Charging Time: Approx. 2 hours

Bluetooth version: V4.1

Connectivity Range: Line of sight approx. 10m (33 ft)

Compatible Devices: Work with most smartphones with Bluetooth function

Speaker Output Power: 5W

Frequency response: 40Hz – 18KHz

Micro USB socket: for charging

3.5mm Port 1: allow songs/voice to be captured for output or recording

3.5mm Port 2: allow music to be played using headphones

Weight: Approx. 540g

Contains



1. Bluetooth Karaoke Mic w/ Speaker (KMIC Pro)
2. MicStand
3. Adapter
4. Mic Clip
5. Phone Mount
6. Micro USB Charging Cable
7. 3.5mm AUX IN Cable
8. Carrying Pouch
9. Instruction Manual and Warranty Card

Overview of KMIC Pro

1. Microphone
2. Volume Control Button
3. Echo Control Button
4. Switch on/off Button
5. 3.5mm port x 2 (phone jack, earphone jack)
6. Micro USB port
7. LED Circle Light

8. Speaker
9. Mic-phone stand (mic stand, mic clip, phone mount)

Instruction for Use

1. Press and hold  for 2 seconds until you are alerted with a “Bu-beep” sound and circle light turns ON. This indicates that the Bluetooth speaker is ready for “connection”.
2. Select “MOMAX IM2” on your Bluetooth device, once the Bluetooth speaker is “connected”, you will hear a “beep” sound.
3. You can play music from either your music library or KTV apps of your Bluetooth device via the speaker of KMIC Pro.
4. Press + or – of VOL to adjust the vocal volume on the KMIC Pro. There are 8 levels of vocal volume.
5. To enjoy echo live sound effect, press + or – of ECH. There are 5 levels of echo volume.
6. To adjust the sound volume, use the volume control button on your Bluetooth device.
7. Press and hold  for 2 seconds to switch off KMIC Pro. You will hear a “Beep-bu-bu” sound and circle light turns off.

Features

SING with LYRICS: Equip mobile with karaoke apps

HANDS FREE: Make a recording or LIVE show at ease

2-IN-1 DESIGN: Mic stand with phone mount

360° ROTATION: Find you perfect angle to view your smartphone

~~AUDIO RECORDING in SILENT MODE: Plug in an “AUX IN” cable to connect the mobile device with 3.5mm port 1. Connect headphone with 3.5mm port 2. Enable recording function of your mobile device.~~

Indicator Lights

When KMIC Pro is ON	Circle light is flashing in different colors
When the music is playing	Circle light is flashing in different colors following to the beat of music
The battery is charging while KMIC Pro is OFF	Red light is ON in breathing feel
Battery is fully charged	Blue light is ON

Trouble Shooting

Circle light is not “ON” or KMIC Pro is not operating	Make sure the Bluetooth speaker’s is “charged”.
Low or “no” sound	Check the Bluetooth speaker or our Bluetooth device’s volume level
Music is playing on a device but isn’t transferring to Bluetooth speaker	Make sure your Bluetooth is “connected”
Battery is fully charged	Blue light is ON
There are “beep” sound during music is playing	Low battery. Please charge the battery.

Notice of compliance

This product complies with all applicable standards and regulations regarding exposure to electromagnetic fields. That includes CE, RoHS, BQB etc.

FCC ID: 2ANBQ-IM2

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Cautions

1. Do not dismantle or modify the product;
2. Do not store the product in wet conditions;
3. Do not keep or use the product near heat sources;
4. Do not let water or any other liquid flows into the inside part of the product’s interface. This would cause damages to the product.

Disposal of Electronic Products

1. Do not place the product as household waste;
2. Please dispose of discarded electronic products properly according to local regulations;
3. MOMAX encourages you to participate in electronics recycling program.

Warranty Conditions

Warranty/ 保用證/ 保用证

Model/ 型號/ 型号: _____

Date of Purchase/ 購買日期/ 购买日期: _____

Remarks/ 備註/ 备注: _____

Customer Service/客戶服務中心/客户服务中心

Hong Kong and Macau:

Unit B, 2/F, Cheong Lung Building,
10 Cheung Yee Street, Lai Chi Kok, Kowloon, Hong Kong
Hotline: 852-24023186 E-Mail: info@momax.net

香港及澳門:

香港九龍荔枝角長義街10號昌隆大廈2樓B室
服務熱線: 852-24023186 電郵: info@momax.net

中国:

摩米士科技(深圳)有限公司
中国广东省深圳市福田区深南大道7006号万科富春
东方大厦7楼
邮编: 518000 全国服务热线: 86-400-886-0010
电邮: info@momax.net.cn

Copyright ©2015 MOMAX Technology Ltd. All rights reserved.
MOMAX is registered trademark of MOMAX Technology Ltd. All
other trademarks are the property of their respective owners.

版權所有©2015 MOMAX Technology Ltd。保留所有權利。MOMAX
是MOMAX Technology Ltd 的註冊商標。所有其他商標均為其各自
擁有者的財產。

版權所有©2015 MOMAX Technology Ltd。保留所有權利。MOMAX
是MOMAX Technology Ltd 的註冊商標。所有其他商標均為其各自
擁有者的財產。

MOMAX®

(Copyright year change to 2017)

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.