


骑马钉

NUBWO

NUBWO WIRELESS GAMING HEADSET



Package Contents

- NUBWO Wireless Gaming Headset
- 2.4GHz Wireless Transmitter
- User Manual
- 3.5mm Audio Cable
- USB Type-C Charging Cable

Overview

- Rotatable Headband
- Soft Memory-Peep Cushion
- Underside Microphone

1



- Volume Wheel
- Mute Noise Button
- Power On/Off Button
- 3.5mm Audio Cable
- USB Type-C Charging port

Power ON/OFF

Power On

Power Off

2

Wireless Mode Usage



Power On

LED

- Green: LED
- Yellow: 3.5mm Tone Connected
- Red: 3.5mm Tone Connected
- Blue: 3.5mm Tone Connected

MIC ON/OFF


Tone

On: Microphone On

Off: Microphone Off

3

Headset Charging



Red LED

Output 5V 1A

Note


- If your headset is disconnected from your device and no operation is performed for five minutes, your headset will turn off automatically.
- When the 3.5mm audio cable is connected, the headset will turn off and enter the wired mode.
- Low Battery Reminder: When you hear the low battery tone 'batteryp' and the red light flashes, please charge the headset in time.

4

Device	PC		Mac	
	Source	Mc	Mc	Mc
PC	✓	✓	✓	✓
PS4/PS5 Console	✓	✓	✓	✓
Xbox Series X	✓	✓	✓	✓
PS4/PS5 Controller	✓	✓	✓	✓
Xbox Series X Controller	✓	✓	✓	✓
Switch	✓	✓	✓	✓
Phone (Android)	✓	✓	✓	✓
Phone (iOS)	✓	✓	✓	✓

5

① Using with PC/Mac in Wireless Mode



1. Choose your input device NUBWO-202

2. 2.4GHz wireless headset can be used.



3. Open Sound settings

2. Choose your output device


6

② Using with PS4/PS5 Controller in Wired Mode



7

Using with PS4/PS5 Console in Wireless Mode



Router: Settings -> Devices -> Audio Devices

Set NUBWO-202 as Input Device & Output Device


8

③ Using with Xbox Controller in Wired Mode



9

④ Using with Phone on Bluetooth Mode



10

No Sound or Intermittent Sound from the Headset

- Check if there are other obstacles when using the transmitter.
- Remember sound occurs when you are communicating with whether the network of your device works or not.
- Check whether you've set the headset as the default recording device.
- Check whether the headset is in normal setup setting.

Can't Connect to Devices

- Check whether you used a USB Extension Cable or USB Hub. It is not recommended.
- Plug directly into the USB jack of the device host.
- Try to plug into a USB jack. (Some USB jacks may be power shortage)
- Try to plug into a USB jack. (Some USB jacks may be power shortage)

11