


尺寸:50*70MM

TWS Earbuds
S42,S43,S47,S48,S49



User Manual
Please read it carefully before use.

Specifications:

Model	S42/S43/S47/S48/S49
Material	ABS
Color	Black/White
Weight	10.5g (each earbud)
Charging Case Weight	45g
Charging Case Capacity	100mAh
Charging Case Output	5V/100mA
Charging Case Input	5V/100mA
Charging Case Type	USB-C
Charging Case Material	ABS
Charging Case Color	Black/White
Charging Case Size	45x25x25mm
Charging Case Weight	45g

Package Include:
1 x Earbuds
1 x Charging Case
1 x USB-C Cable
1 x User Manual

Diagram & Operations:




Diagram Labels:
1. Microphone
2. Earbud
3. Charging Case
4. Touch Control

Operation:
1. Charge the earbuds in the charging case.
2. Press the touch control to play/pause music.
3. Press the touch control to answer/reject a call.
4. Press the touch control to activate voice assistant.
5. Press the touch control to switch between earbuds.
6. Press the touch control to reset the earbuds.

Auto Power Off:
The earbuds will auto power off when they are not used for 10 minutes.
Charging:
The earbuds will charge when they are in the charging case.
Touch Control:
Touch the touch control to play/pause music, answer/reject a call, activate voice assistant, and switch between earbuds.
Touch & Hold:
Touch & hold the touch control to power on/off the earbuds.

FAQ:
Q: Why can't I hear the earbuds?
A: Check if the earbuds are fully charged.
Q: Why can't I connect the earbuds to my phone?
A: Turn on Bluetooth on your phone and search for the earbuds.
Q: Why can't I hear the earbuds clearly?
A: Clean the earbuds and the charging case.

FCC Compliance Statement:
This device complies with FCC Part 15.247 Class 1 digital device limits.
CORRECT DISPOSAL OF THIS PRODUCT
This symbol shows the product is hazardous.
Do not dispose of this product with other household waste.
Please refer to the instructions for disposal information.

TWS耳机



用户手册
使用前请仔细阅读。

规格:

型号	S42/S43/S47/S48/S49
材质	ABS
颜色	黑色/白色
重量	10.5g (单耳)
充电盒重量	45g
充电盒容量	100mAh
充电盒输出	5V/100mA
充电盒输入	5V/100mA
充电盒类型	USB-C
充电盒材质	ABS
充电盒颜色	黑色/白色
充电盒尺寸	45x25x25mm
充电盒重量	45g

包装配件:
1 x 耳机
1 x 充电盒
1 x USB-C 数据线
1 x 用户手册

示意图:



示意图标注:
1. 麦克风
2. 耳机
3. 充电盒
4. 触控按键

操作:
1. 将耳机放入充电盒进行充电。
2. 轻触触控按键播放/暂停音乐。
3. 双击触控按键接听/拒接来电。
4. 轻触触控按键激活语音助手。
5. 轻触触控按键切换耳机。
6. 长按触控按键重置耳机。

自动关机:
耳机在10分钟内无操作会自动关机。
充电:
耳机放入充电盒即可充电。
触控操作:
轻触触控按键播放/暂停音乐, 接听/拒接来电, 激活语音助手, 切换耳机。
触控长按:
触控长按触控按键开机/关机。

常见问题:
Q: 为什么听不到声音?
A: 检查耳机是否电量充足。
Q: 为什么无法连接到手机?
A: 打开手机蓝牙并搜索耳机。
Q: 为什么听不清楚?
A: 清洁耳机和充电盒。

FCC合规声明:
本产品符合FCC第15.247类1数字设备限值。
正确处置产品
此符号表示产品含有有害物质。
请勿将此产品与其他生活垃圾一起处理。
请参考说明书中的处理信息。