


MC 9060^{ex}-G

Quick Start Guide

See Product Reference Guide for more information

Battery Insertion




Battery Removal


You are allowed to replace the battery in hazardous areas.



To charge the battery in hazardous areas is strictly prohibited.



Stylus Removal



Accessories for safe area

Charging Instructions


Slow Flash = Normal Charge

Solid Amber = Full Charge

Fast Flash = Charging Error


● = LED Indicator Location

safe area




Four Slot Spare Battery Charger

safe area



Single Slot Serial Cradle


safe area




Four Slot Cradles

Charge-Only Cradle and Ethernet Cradle

Optimum Scanning Positions





ALTERNATE LEFT AND RIGHT HANDS
TAKING BREAKS AND TASK ROTATION RECOMMENDED



Optimum Upright Body Posture

Avoid Extreme Wrist Angles



Optimum Body Posture for Low Scanning

ALTERNATE LEFT AND RIGHT KNEES

