


SAR Test Setup Photographs

EUT Side Definition





Phantom Position : ELI	EUT side : Horizontal-UP
Spacing to phantom : 5 mm	Accessory : N/A



Phantom Position : ELI	EUT side : Horizontal-Down
Spacing to phantom : 5 mm	Accessory : N/A



Phantom Position : ELI	EUT side : Vertical-Front
Spacing to phantom : 5 mm	Accessory : N/A
	
Phantom Position : ELI	EUT side : Vertical-Back
Spacing to phantom : 5 mm	Accessory : N/A
	

Phantom Position : ELI	EUT side : Tip
Spacing to phantom : 5 mm	Accessory : N/A
	
Phantom Position : ELI	EUT side : Bottom
Spacing to phantom : 5 mm	Accessory : N/A
	