

EUT Internal Photographs


1.1 EUT(ITS-RS4-M-SPEW) – Open Enclosure View



1.2 EUT(ITS-RS4-M-SPEW) – Mainboard Top View



1.3 EUT(ITS-RS4-M-SPEW) – Mainboard Bottom View



1.4 EUT(ITS-RS4-M-SPEW) – Support Board Top View



1.5 EUT(ITS-RS4-M-SPEW) – Support Board Bottom View



1.6 EUT (ITS-RS4-M-SM66) – Open Enclosure View



1.7 EUT (ITS-RS4-M-SM66) – Main Board Top View



1.8 EUT(ITS-RS4-M-SM66) – Mainboard Bottom View



1.9 EUT(ITS-RS4-M-SM66) – Support Board Top View



1.10 EUT(ITS-RS4-M-SM66) – Support Board Bottom View



1.11 EUT(ITS-RS4-M-W-C495-BL5-S-SGLB) – Open Enclosure View



1.12 EUT(ITS-RS4-M-W-C495-BL5-S-SGLB) – Mainboard Top View




1.13 EUT(ITS-RS4-M-W-C495-BL5-S-SGLB) – Mainboard Bottom View



1.14 EUT(ITS-RS4-M-W-C495-BL5-S-SGLB) – Support Board Top View



1.15 EUT(ITS-RS4-M-W-C495-BL5-S-SGLB) – Support Board Bottom View**1.16 EUT(ITS-RS4-M-W-C495-BL5-S-SGLB) – Backup Power Board Top View**

1.17 EUT(ITS-RS4-M-W-C495-BL5-S-SGLB) – Backup Power Board Bottom View