


Programming Step 2



Depress the button marked "PGM" on the Martec Access Products HomeLink® Compatible Default Receiver. This will cause the "STATUS" LED on the receiver to light. You now have 30 seconds to complete step 3.

Programming Step 3

Depress the HomeLink® Universal Transceiver button that you have selected to control the opener: continue holding until the "STATUS" LED on the receiver goes "OFF". You now have 30 seconds to complete step 4.

Programming Step 4

Depress the same HomeLink® Universal Transceiver button a second time and hold until "STATUS" LED on the receiver starts to flash. The default rolling code format is now installed.

Your installation is now complete.

NOTE: To install additional HomeLink® Universal Transceiver buttons follow Programming Steps 2, 3, and 4 for each button.

If a seventh HomeLink® Universal Transceiver button is installed into the Martec Access Products HomeLink® Compatible Default Receiver, the first button installed will be pushed out. All buttons are treated on a "first in", "first out" basis after six individual buttons have been installed.

Depress the Martec Access Products HomeLink® Compatible Default Receiver Program button for 10 seconds to erase all transceiver codes stored in memory.

This device complies with FCC Rules Part 15 and IC Canada Rules and Regulations. Operation of this device is subject to the following conditions: (1) This device may not cause harmful interference; (2) This device must accept any interference that may be received, including interference that may cause undesired operation; (3) Changes or modifications not expressly approved by the manufacturer, could void the authority of users to operate this equipment.

MARTEC ACCESS PRODUCTS LIMITED WARRANTY

This product is warranted to the original user against defects in material and workmanship for one year from the date of purchase. Warrantor will repair or replace, at its option, any device found to require service under this Warranty. The repaired or replaced device will be returned to the customer at the warrantors cost. Call 1-800-483-2539 for instructions on how to proceed with a warranty claim. The user will pay the cost of returning the device to the warrantor for service. This warranty is void if the failure of the device is determined to have been caused by improper installation or use, abuse, fire, water, or acts of God. This warranty excludes all other warranties, expressed or implied, including any warranty of merchantability. Martec Access Products shall not be liable for consequential or incidental damages that may arise from any defect or failure of the radio control device. Some states do not allow the exclusion or limitation of consequential or incidental damages. This limitation is not valid in jurisdictions, which do not allow limitation of incidental or consequential damages or limitation of warranty periods. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state.


HomeLink® is a registered trademark of Johnson Controls, Inc., Holland, Michigan.

MARTEC

Martec Access Products Inc.
240 Sheffield Street, Mountainside, NJ 07092
908 233 0691 ■ FAX 908 233 5766
www.martecaccess.com

MDN-199 rev-A

Martec Access Products HomeLink® Compatible Default Receiver Kit



INSTALLATION & PROGRAMMING INSTRUCTIONS

The Martec Access Products HomeLink® Compatible Default Receiver is intended for the control of garage door and gate openers that do not have HomeLink compatible radio receivers. The default receiver can be used to program up to six HomeLink transceiver buttons. The power is supplied to the receiver by a 24 volt plug-in transformer. A two-wire harness is supplied for connecting the relay output from the default receiver to the radio control input of the opener. In some cases it will be necessary to make the connections to the push button terminals on the opener.



WARNING

Radio Controls are prohibited from providing constant contact closure when installed on the push button inputs of residential garage door openers that are provided with monitored safety systems.

MARTEC

Martec Access Products Inc.
240 Sheffield Street, Mountainside, NJ 07092
908 233 0691 ■ FAX 908 233 5766
www.martecaccess.com

WARNING

DO NOT ALLOW CHILDREN TO PLAY WITH OR OPERATE REMOTE CONTROL TRANSMITTERS. The garage door could close and cause serious injury or death.




WARNING

Disconnect power from opener before installing receiver

Step 1. Mount the Receiver.


TO AVOID INTERFERENCE FROM UNWANTED "CROSS TALK" MOUNT THE HomeLink® COMPATIBLE RECEIVER AS FAR AWAY AS POSSIBLE FROM ANY OPENER THAT HAS A BUILT-IN RADIO RECEIVER.

Mount the Martec Access Products HomeLink® Compatible Default Receiver as far from the existing opener as possible, but within reach of the wire connecting the power transformer and the wire going to the opener terminals.




Step 2A. Connect Receiver to Opener

Connect the two white wire harness to the appropriate terminals on the opener. (See opener instructions, in some cases it will be necessary to make these output connections to the push button terminals on the opener).



Step 3. Plug the 24 Volt Power Transformer Lead into the Receiver.

Plug the power transformer lead into the receiver output terminal marked "PWR".



Step 4. Plug the Power Transformer into a 115 VAC Receptacle.

Reconnect power to the opener and proceed to programming.

PROGRAMMING



CAUTION

The opener may operate unexpectedly as you are programming your remote controls.

NOTE: The Martec Access Products HomeLink® Compatible Default Receiver can be programmed before it is mounted and connected to the opener. Simply plug the power transformer into a convenient receptacle or extension cord, connect the 24 volt power transformer lead to the receiver, and proceed with the Programming Instructions. After programming, unplug the transformer from the temporary power source and move the receiver and power transformer to their permanent locations. Connect the white wire harness from the receiver to the push button or radio control terminals.



Programming Step 1

Enable the HomeLink® Universal Transceiver to transmit the default code by simultaneously holding the three push buttons down for 20 seconds until the transceiver LED changes from solid "On" to flashing "On and Off". Continue to hold the buttons down for approximately 10 additional seconds until the transceiver LED stops flashing and goes out. The HomeLink® Universal Transceiver is now in the default rolling code format.

(continued)