- AN Select Start, select Windows Update, select Check for updates, and then install any updates. Restart the computer, if necessary,
- B. Select Start, and then select Mixed Reality Portal. **C**. Follow the on-screen instructions.
- AR Select Start, select Windows Update, select Check for updates, and then install any updates. Restart the computer, if necessary,
- B. Select Start, and then select Mixed Reality Portal. C. Follow the on-screen instructions.
- AP Select Start, select Windows Update, select Check for updates, and then install any updates. Restart the
- computer, if necessary. B. Select Start, and then select Mixed Reality Portal.
- **C**. Follow the on-screen instructions. AG Select Start, select Windows Update, select Check
- for updates, and then install any updates. Restart the computer, if necessary. B. Select Start, and then select Mixed Reality Portal.
- **C**. Follow the on-screen instructions.
- AS Select Start, select Windows Update, select Check for updates, and then install any updates. Restart the computer, if necessary.
- **B**. Select **Start**, and then select **Mixed Reality Portal**. **C**. Follow the on-screen instructions.
- A. Select Start, select Windows Update, select Check
- for updates, and then install any updates. Restart the computer, if necessary.
- **B**. Select **Start**, and then select **Mixed Reality Portal**. C. Follow the on-screen instructions.
- A. Select Start, select Windows Update, select Check
- for updates, and then install any updates. Restart the computer, if necessary.
- **B**. Select **Start**, and then select **Mixed Reality Portal**. **C**. Follow the on-screen instructions.
- A. Select Start, select Windows Update, select Check for updates, and then install any updates. Restart the
- computer, if necessary. B. Select Start, and then select Mixed Reality Portal. C. Follow the on-screen instructions.
- A: Select Start, select Windows Update, select Check for updates, and then install any updates. Restart the
- computer, if necessary,
- B. Select **Start**, and then select **Mixed Reality Portal**.

C. Follow the on-screen instructions.

- A. Select Start, select Windows Update, select Check for updates, and then install any updates. Restart the computer, if necessary.
- B. Select Start, and then select Mixed Reality Portal. **C**. Follow the on-screen instructions.
- A. Select Start, select Windows Update, select Check for updates, and then install any updates. Restart the
- computer, if necessary, B. Select Start, and then select Mixed Reality Portal.

C. Follow the on-screen instructions.

- A. Select Start, select Windows Update, select Check for updates, and then install any updates. Restart the
- computer, if necessary. B. Select Start, and then select Mixed Reality Portal.
- **C**. Follow the on-screen instructions.
- A. Select Start, select Windows Update, select Check for updates, and then install any updates. Restart the computer, if necessary.
- **B**. Select **Start**, and then select **Mixed Reality Portal**. C. Follow the on-screen instructions.
- A. Select Start, select Windows Update, select Check for updates, and then install any updates. Restart the
- computer, if necessary. **B**. Select **Start**, and then select **Mixed Reality Portal**. **C**. Follow the on-screen instructions.
- A. Select Start, select Windows Update, select Check for updates, and then install any updates. Restart the
- computer, if necessary.
- B. Select Start, and then select Mixed Reality Portal. C. Follow the on-screen instructions.
- A. Select Start, select Windows Update, select Check
- for updates, and then install any updates. Restart the computer, if necessary.
- **B**. Select **Start**, and then select **Mixed Reality Portal**. **C**. Follow the on-screen instructions.
- A. Select Start, select Windows Update, select Check
- for updates, and then install any updates. Restart the
- computer, if necessary, **B**. Select **Start**, and then select **Mixed Reality Portal**.
- C. Follow the on-screen instructions. A. Select Start, select Windows Update, select Check
- for updates, and then install any updates. Restart the computer, if necessary.
- B. Select Start, and then select Mixed Reality Portal. **C**. Follow the on-screen instructions.

- A. Select Start, select Windows Update, select Check for updates, and then install any updates. Restart the computer, if necessary.
- B. Select Start, and then select Mixed Reality Portal. **C**. Follow the on-screen instructions.
- A. Select Start, select Windows Update, select Check for updates, and then install any updates. Restart the computer, if necessary.
- B. Select Start, and then select Mixed Reality Portal. C. Follow the on-screen instructions.
- A. Select Start, select Windows Update, select Check for updates, and then install any updates. Restart the computer, if necessary.
- B. Select Start, and then select Mixed Reality Portal. C. Follow the on-screen instructions.
- A. Select Start, select Windows Update, select Check for updates, and then install any updates. Restart the
- computer, if necessary, B. Select Start, and then select Mixed Reality Portal.
- **C**. Follow the on-screen instructions. A. Select Start, select Windows Update, select Check for updates, and then install any updates. Restart the
- computer, if necessary. **B**. Select **Start**, and then select **Mixed Reality Portal**.
- **C**. Follow the on-screen instructions. A. Select Start, select Windows Update, select Check
- for updates, and then install any updates. Restart the computer, if necessary.
- **B**. Select **Start**, and then select **Mixed Reality Portal**. **C**. Follow the on-screen instructions.
- A. Select Start, select Windows Update, select Check for updates, and then install any updates. Restart the computer, if necessary.
- **B**. Select **Start**, and then select **Mixed Reality Portal**. **C**. Follow the on-screen instructions.
- A. Select Start, select Windows Update, select Check for updates, and then install any updates. Restart the
- computer, if necessary. B. Select Start, and then select Mixed Reality Portal.
- A. Select Start, select Windows Update, select Check for updates, and then install any updates. Restart the

C. Follow the on-screen instructions.

C. Follow the on-screen instructions.

- computer, if necessary. B. Select Start, and then select Mixed Reality Portal.

computer, if necessary, B. Select Start, and then select Mixed Reality Portal. C. Follow the on-screen instructions. A. Select Start, select Windows Update, select Check

A. Select Start, select Windows Update, select Check

B. Select Start, and then select Mixed Reality Portal.

A. Select Start, select Windows Update, select Check

B. Select Start, and then select Mixed Reality Portal.

A. Select Start, select Windows Update, select Check

for updates, and then install any updates. Restart the

for updates, and then install any updates. Restart the

computer, if necessary,

computer, if necessary.

C. Follow the on-screen instructions.

C. Follow the on-screen instructions.

for updates, and then install any updates. Restart the


- for updates, and then install any updates. Restart the computer, if necessary.
- B. Select Start, and then select Mixed Reality Portal.
- C. Follow the on-screen instructions.
- A. Select Start, select Windows Update, select Check for updates, and then install any updates. Restart the computer, if necessary.
- B. Select Start, and then select Mixed Reality Portal.

C. Follow the on-screen instructions.

- A. Select Start, select Windows Update, select Check for updates, and then install any updates. Restart the
- computer, if necessary.
- B. Select Start, and then select Mixed Reality Portal. C. Follow the on-screen instructions. A. Select Start, select Windows Update, select Check

for updates, and then install any updates. Restart the

- computer, if necessary. B. Select Start, and then select Mixed Reality Portal.
- C. Follow the on-screen instructions.
- A. Select Start, select Windows Update, select Check for updates, and then install any updates. Restart the
- computer, if necessary. B. Select Start, and then select Mixed Reality Portal.
- C. Follow the on-screen instructions.























- EN *LCD refresh rate: Hybrid 60/90 Hz High refresh rate with maximum fidelity on PCs that support DisplayPort 1.3. Maximum 60 Hz refresh rate on PCs that support DisplayPort 1.2. For more information, go to http://www.hp.com/go/mixedreality/Support.
- AR *LCD refresh rate: Hybrid 60/90 Hz High refresh rate with maximum fidelity on PCs that support DisplayPort 1.3. · Maximum 60 Hz refresh rate on PCs that support DisplayPort 1.2. For more information, go to http://www.hp.com/go/mixedreality/Support.
- ID *LCD refresh rate: Hybrid 60/90 Hz High refresh rate with maximum fidelity on PCs that support DisplayPort 1.3. Maximum 60 Hz refresh rate on PCs that support DisplayPort 1.2. For more information, go to http://www.hp.com/go/mixedreality/Support.
- BG *LCD refresh rate: Hybrid 60/90 Hz
 •High refresh rate with maximum fidelity on
 PCs that support DisplayPort 1.3. Maximum 60 Hz refresh rate on PCs that support DisplayPort 1.2. For more information, go to http://www.hp.com/go/mixedreality/Support.
- CS *LCD refresh rate: Hybrid 60/90 Hz
 High refresh rate with maximum fidelity on PCs that support DisplayPort 1.3. Maximum 60 Hz refresh rate on PCs that support DisplayPort 1.2.
- For more information, go to http://www.hp.com/go/mixedreality/Support DA *LCD refresh rate: Hybrid 60/90 Hz
 • High refresh rate with maximum fidelity on PCs that support DisplayPort 1.3
- Maximum 60 Hz refresh rate on PCs that For more information, go to http://www.hp.com/go/mixedreality/Support.

- DE*LCD refresh rate: Hybrid 60/90 Hz High refresh rate with maximum fidelity on PCs that support DisplayPort 1.3. · Maximum 60 Hz refresh rate on PCs that support DisplayPort 1.2. For more information, go to
- http://www.hp.com/go/mixedreality/Support. ES*LCD refresh rate: Hybrid 60/90 Hz High refresh rate with maximum fidelity on PCs that support DisplayPort 1.3.
- · Maximum 60 Hz refresh rate on PCs that support DisplayPort 1.2. For more information, go to http://www.hp.com/go/mixedreality/Support
- EL*LCD refresh rate: Hybrid 60/90 Hz High refresh rate with maximum fidelity on PCs that support DisplayPort 1.3. Maximum 60 Hz refresh rate on PCs that support DisplayPort 1.2. For more information, go to http://www.hp.com/go/mixedreality/Support
- FR*LCD refresh rate: Hybrid 60/90 Hz
 High refresh rate with maximum fidelity on PCs that support DisplayPort 1.3. Maximum 60 Hz refresh rate on PCs that support DisplayPort 1.2. For more information, go to
- http://www.hp.com/go/mixedreality/Support HR*LCD refresh rate: Hybrid 60/90 Hz
 • High refresh rate with maximum fidelity on PCs that support DisplayPort 1.3
- Maximum 60 Hz refresh rate on PCs that support DisplayPort 1.2. For more information, go to http://www.hp.com/go/mixedreality/Suppor IT*LCD refresh rate: Hybrid 60/90 Hz
 • High refresh rate with maximum fidelity on
- PCs that support DisplayPort 1.3 Maximum 60 Hz refresh rate on PCs that support DisplayPort 1.2. For more information, go to http://www.hp.com/go/mixedreality/Support.

- KK*LCD refresh rate: Hybrid 60/90 Hz High refresh rate with maximum fidelity on PCs that support DisplayPort 1.3.
 Maximum 60 Hz refresh rate on PCs that support DisplayPort 1.2. For more information, go to
- http://www.hp.com/go/mixedreality/Support LV*LCD refresh rate: Hybrid 60/90 Hz High refresh rate with maximum fidelity on PCs that support DisplayPort 1.3. Maximum 60 Hz refresh rate on PCs that support DisplayPort 1.2. For more information, go to
- http://www.hp.com/go/mixedreality/Support. LT*LCD refresh rate: Hybrid 60/90 Hz

 • High refresh rate with maximum fidelity on PCs that support DisplayPort 1.3. Maximum 60 Hz refresh rate on PCs that support DisplayPort 1.2. For more information, go to
- http://www.hp.com/go/mixedreality/Support HU*LCD refresh rate: Hybrid 60/90 Hz
 High refresh rate with maximum fidelity on PCs that support DisplayPort 1.3. Maximum 60 Hz refresh rate on PCs that support DisplayPort 1.2.
- For more information, go to http://www.hp.com/go/mixedreality/Support NL*LCD refresh rate: Hybrid 60/90 Hz

 • High refresh rate with maximum fidelity on PCs that support DisplayPort 1.3. Maximum 60 Hz refresh rate on PCs that support DisplayPort 1.2.
- For more information, go to http://www.hp.com/go/mixedreality/Support NO *LCD refresh rate: Hybrid 60/90 Hz
 • High refresh rate with maximum fidelity on PCs that support DisplayPort 1.3.
 - Maximum 60 Hz refresh rate on PCs that support DisplayPort 1.7 For more information, go to

http://www.hp.com/go/mixedreality/Support.

- PL*LCD refresh rate: Hybrid 60/90 Hz High refresh rate with maximum fidelity on PCs that support DisplayPort 1.3. • Maximum 60 Hz refresh rate on PCs that support DisplayPort 1.2. For more information, go to
- PT*I CD refresh rate: Hybrid 60/90 Hz High refresh rate with maximum fidelity on PCs that support DisplayPort 1.3. Maximum 60 Hz refresh rate on PCs that support DisplayPort 1.2. For more information, go to http://www.hp.com/go/mixedreality/Support.

http://www.hp.com/go/mixedreality/Support

- BR*LCD refresh rate: Hybrid 60/90 Hz

 High refresh rate with maximum fidelity on PCs that support DisplayPort 1.3. Maximum 60 Hz refresh rate on PCs that support DisplayPort 1.2.
 For more information, go to http://www.hp.com/go/mixedreality/Support
- RO*LCD refresh rate: Hybrid 60/90 Hz
 High refresh rate with maximum fidelity on PCs that support DisplayPort 1.3. Maximum 60 Hz refresh rate on PCs that support DisplayPort 1.2. For more information, go to http://www.hp.com/go/mixedreality/Support RU*LCD refresh rate: Hybrid 60/90 Hz
 • High refresh rate with maximum fidelity on
- PCs that support DisplayPort 1.3. Maximum 60 Hz refresh rate on PCs that support DisplayPort 1.2. For more information, go to http://www.hp.com/go/mixedreality/Suppor
- SK*LCD refresh rate: Hybrid 60/90 Hz
 •High refresh rate with maximum fidelity on PCs that support DisplayPort 1.3. Maximum 60 Hz refresh rate on PCs that support DisplayPort 1.2. For more information, go to http://www.hp.com/go/mixedreality/Support.

- St*LCD refresh rate: Hybrid 60/90 Hz High refresh rate with maximum fidelity on PCs that support DisplayPort 1.3. Maximum 60 Hz refresh rate on PCs that support DisplayPort 1.2. For more information, go to
- FtI CD refresh rate: Hybrid 60/90 Hz High refresh rate with maximum fidelity on PCs that support DisplayPort 1.3. Maximum 60 Hz refresh rate on PCs that support DisplayPort 1.2. For more information, go to

http://www.hp.com/go/mixedreality/Support

http://www.hp.com/go/mixedreality/Support.


- SRLCD refresh rate: Hybrid 60/90 Hz
 High refresh rate with maximum fidelity on PCs that support DisplayPort 1.3. Maximum 60 Hz refresh rate on PCs that support DisplayPort 1.2.
 For more information, go to http://www.hp.com/go/mixedreality/Support
- SGLCD refresh rate: Hybrid 60/90 Hz
 High refresh rate with maximum fidelity on PCs that support DisplayPort 1.3. Maximum 60 Hz refresh rate on PCs that support DisplayPort 1.2. For more information, go to http://www.hp.com/go/mixedreality/Support
- TH_{LCD} refresh rate: Hybrid 60/90 Hz
 High refresh rate with maximum fidelity on PCs that support DisplayPort 1.3.
- Maximum 60 Hz refresh rate on PCs that support DisplayPort 1.2. For more information, go to http://www.hp.com/go/mixedreality/Support
- TR_{LCD} refresh rate: Hybrid 60/90 Hz •High refresh rate with maximum fidelity on PCs that support DisplayPort 1.3. Maximum 60 Hz refresh rate on PCs that support DisplayPort 1.2. For more information, go to

 High refresh rate with maximum fidelity on PCs that support DisplayPort 1.3. · Maximum 60 Hz refresh rate on PCs that support DisplayPort 1.2. For more information, go to http://www.hp.com/go/mixedreality/Support. JA*LCD refresh rate: Hybrid 60/90 Hz

UK*LCD refresh rate: Hybrid 60/90 Hz

- High refresh rate with maximum fidelity on PCs that support DisplayPort 1.3. · Maximum 60 Hz refresh rate on PCs that support DisplayPort 1.2. For more information, go to http://www.hp.com/go/mixedreality/Support.
- KO *LCD refresh rate: Hybrid 60/90 Hz
 High refresh rate with maximum fidelity on PCs that support DisplayPort 1.3. Maximum 60 Hz refresh rate on PCs that support DisplayPort 1.2.
 For more information, go to http://www.hp.com/go/mixedreality/Support.
- CN *LCD refresh rate: Hybrid 60/90 Hz
 High refresh rate with maximum fidelity on PCs that support DisplayPort 1.3. Maximum 60 Hz refresh rate on PCs that support DisplayPort 1.2. For more information, go to http://www.hp.com/go/mixedreality/Support.
- TW *LCD refresh rate: Hybrid 60/90 Hz

 High refresh rate with maximum fidelity on PCs that support DisplayPort 1.3 Maximum 60 Hz refresh rate on PCs that support DisplayPort 1.2.
- For more information, go to http://www.hp.com/go/mixedreality/Support.











- Thumbstick (Teleport, Rotate)*
 - Menu button
 - O TouchPad*
 - 4 Windows® button 5 Trigger (Select)
 - 6 Grab button (Grasp)
 - Quickly blinking: Pairing mode Slowly blinking: Idle mode Blinking (2 times): Blinking (3 times): Critical battery level
 - 8 Microphones (2)
 - Activity light On: Headset is on.
 - Make your gesture and then press to execute your action
- 1 Thumbstick (Teleport, Rotate)*
- 2 Menu button
- TouchPad*
- 5 Trigger (Select)

4 Windows® button

- 6 Grab button (Grasp)
- Quickly blinking: Pairing mode Slowly blinking: Idle mode Blinking (2 times): Low battery level Blinking (3 times): Critical battery level
- 8 Microphones (2) Activity light
- On: Headset is on. * Make your gesture and then press to execute your action.
- 1D 1 Thumbstick (Teleport, Rotate)*
- 2 Menu button
- TouchPad* 4 Windows® button
- 5 Trigger (Select) Grab button (Grasp)

8 Microphones (2)

Activity light

- Lights
- Quickly blinking: Pairing mode Slowly blinking: Idle mode Blinking (2 times): Low battery level Blinking (3 times): Critical battery level
- On: Headset is on execute your action
- * Make your gesture and then press to
- Thumbstick (Teleport, Rotate)* Menu button
- TouchPad*
- 4 Windows® button
- 5 Trigger (Select) 6 Grab button (Grasp)
- Lights Quickly blinking: Pairing mode Slowly blinking: Idle mode Blinking (2 times): Low battery level Blinking (3 times):
- 8 Microphones (2) Activity light
- On: Headset is on. Make your gesture and then press to execute your action
- 1 Thumbstick (Teleport, Rotate)* 2 Menu button
- TouchPad* 4 Windows® button
- Trigger (Select)
- 6 Grab button (Grasp)
- Lights
- Quickly blinking: Pairing mode Slowly blinking: Idle mode Blinking (2 times): Low battery level Blinking (3 times): Critical battery level
- Activity light
- Microphones (2) On: Headset is on. Make your gesture and then press to execute your action

- DA 1 Thumbstick (Teleport, Rotate)* Menu button
 - TouchPad*
 - Windows® button 5 Trigger (Select)
 - 6 Grab button (Grasp)
 - Quickly blinking: Pairing mode Slowly blinking: Idle mode Blinking (2 times): Blinking (3 times):
 - Critical battery level 8 Microphones (2)
 - Activity light On: Headset is on.
 - * Make your gesture and then press to execute your action.

 - DE 1 Thumbstick (Teleport, Rotate)*
 - 2 Menu button

 - TouchPad*
 - 4 Windows® button 5 Trigger (Select)
 - 6 Grab button (Grasp)
 - Lights Quickly blinking: Pairing mode Slowly blinking: Idle mode Blinking (2 times): Low battery level Blinking (3 times): Critical battery level
 - 8 Microphones (2) Activity light
 - On: Headset is on. * Make your gesture and then press to execute your action.
 - ES 1 Thumbstick (Teleport, Rotate)*
 - Menu button TouchPad*
 - 4 Windows® button
 - 5 Trigger (Select) 6 Grab button (Grasp)
 - Lights
 - Quickly blinking: Pairing mode Slowly blinking: Idle mode Blinking (2 times): Low battery level Blinking (3 times): Critical battery level
 - 8 Microphones (2) Activity light
 - On: Headset is on. * Make your gesture and then press to execute your action.
 - EL 1 Thumbstick (Teleport, Rotate)*
 - 2 Menu button TouchPad*
 - Windows® button 5 Trigger (Select)
 - Grab button (Grasp)
 - Lights Quickly blinking: Pairing mode Slowly blinking: Idle mode Blinking (2 times): Low battery level Blinking (3 times): Critical battery level
 - 8 Microphones (2) Activity light
 - On: Headset is on.
 - Make your gesture and then press to execute your action.
 - FR 1 Thumbstick (Teleport, Rotate)* 2 Menu button
 - TouchPad*
 - 4 Windows® button 5 Trigger (Select)
 - 6 Grab button (Grasp)
 - Lights
 - Quickly blinking: Pairing mode Slowly blinking: Idle mode Blinking (2 times): Low battery level Blinking (3 times): Critical battery level 8 Microphones (2)
 - Activity light
 - On: Headset is on. Make your gesture and then press to execute your action.

HR 1 Thumbstick (Teleport, Rotate)* NO 1 Thumbstick (Teleport, Rotate)* 2 Menu button

OuchPad*

Lights

Windows® button

6 Grab button (Grasp)

Blinking (2 times):

Low battery level

8 Microphones (2)

Activity light

Menu button

Windows® button

6 Grab button (Grasp)

Blinking (2 times):

Low battery level

8 Microphones (2)

Activity light

2 Menu button

Windows® button

6 Grab button (Grasp)

Blinking (2 times):

Blinking (3 times):

Critical battery level

On: Headset is on.

Low battery level

8 Microphones (2)

Activity light

Menu button

4 Windows® button

6 Grab button (Grasp)

Blinking (2 times): Low battery level

Blinking (3 times):

Critical battery level

On: Headset is on.

8 Microphones (2)

Activity light

2 Menu button

4 Windows® button

6 Grab button (Grasp)

Blinking (2 times):

Low battery level

Blinking (3 times):

Critical battery level

On: Headset is on.

8 Microphones (2)

Activity light

2 Menu button

4 Windows® button

(Grah button (Grasp)

Blinking (2 times):

Blinking (3 times):

Critical battery level

On: Headset is on.

execute your action.

Low battery level

Microphones (2)

Activity light

5 Trigger (Select)

TouchPad*

Lights

5 Trigger (Select)

TouchPad*

Lights

5 Trigger (Select)

TouchPad*

5 Trigger (Select)

TouchPad*

Lights

Blinking (3 times):

Critical battery level

On: Headset is on.

execute your action.

PT 1 Thumbstick (Teleport, Rotate)*

5 Trigger (Select)

TouchPad*

Lights

Blinking (3 times):

Critical battery level

On: Headset is on.

execute your action.

Quickly blinking: Pairing mode

Make your gesture and then press to

1 Thumbstick (Teleport, Rotate)*

Quickly blinking: Pairing mode

* Make your gesture and then press to

Ouickly blinking: Pairing mode

* Make your gesture and then press to execute your action.

1 Thumbstick (Teleport, Rotate)*

Quickly blinking: Pairing mode

* Make your gesture and then press to execute your action.

1 Thumbstick (Teleport, Rotate)*

Quickly blinking: Pairing mode

* Make your gesture and then press to execute your action.

1 Thumbstick (Teleport, Rotate)*

Quickly blinking: Pairing mode

Slowly blinking: Idle mode

5 Trigger (Select)

- 2 Menu button
- TouchPad*
- Windows® button
- Trigger (Select) 6 Grab button (Grasp) Liahts
- Quickly blinking: Pairing mode Slowly blinking: Idle mode Blinking (2 times): Low battery level Blinking (3 times): Critical battery level
- Microphones (2) Activity light
- On: Headset is on. Make your gesture and then press to execute your action
- IT 1 Thumbstick (Teleport, Rotate)*
- 2 Menu button
- TouchPad*
- Windows® button Trigger (Select)
- 6 Grab button (Grasp) Lights Quickly blinking: Pairing mode Slowly blinking: Idle mode Blinking (2 times): Low battery level
- Blinking (3 times): Critical battery level
- 6 Microphones (2) Activity light
- On: Headset is on. * Make your gesture and then press to execute your action
- KK 1 Thumbstick (Teleport, Rotate)*
- 2 Menu button TouchPad*
- Windows® button Trigger (Select) 6 Grab button (Grasp)
- Lights Ouickly blinking: Pairing mode Slowly blinking: Idle mode Blinking (2 times): Blinking (3 times):
- Critical battery level Microphones (2)
- Activity light On: Headset is on. * Make your gesture and then press to execute your action
- LV 1 Thumbstick (Teleport, Rotate)*
- 2 Menu button TouchPad*
- Windows® button 5 Trigger (Select)
- Grab button (Grasp) Lights Quickly blinking: Pairing mode Slowly blinking: Idle mode Blinking (2 times): Blinking (3 times):
- Microphones (2) Activity light On: Headset is on.

* Make your gesture and then press to

Critical battery level

- Menu button

execute your action

- 3 TouchPad*
- Windows® button 5 Trigger (Select) 6 Grab button (Grasp)
- Lights Quickly blinking: Pairing mode Slowly blinking: Idle mode Blinking (2 times): Low battery level
- Blinking (3 times): Critical battery level
- Microphones (2) 9 Activity light On: Headset is on.
- * Make your gesture and then press to execute your action
- HU 1 Thumbstick (Teleport, Rotate)* 2 Menu button
- TouchPad 4 Windows® button
- 5 Trigger (Select) 6 Grab button (Grasp) Quickly blinking: Pairing mode
- Slowly blinking: Idle mode Blinking (2 times): Low battery level Blinking (3 times):
- Critical battery level 8 Microphones (2)
- 9 Activity light On: Headset is on. * Make your gesture and then press to execute your action.
- NL 1 Thumbstick (Teleport, Rotate)*
- 2 Menu button
- 3 TouchPad*
- Windows® button 5 Trigger (Select) 6 Grab button (Grasp)
- Lights Quickly blinking: Pairing mode Slowly blinking: Idle mode Blinking (2 times): Low battery level
- Blinking (3 times): Critical battery level
- 8 Microphones (2) Activity light On: Headset is on. * Make your gesture and then press to execute your action.
- 2 Menu button TouchPad*
- 4 Windows® button 5 Trigger (Select)
- Lights Blinking (2 times): Low battery level
- Blinking (3 times): Critical battery level Microphones (2) Activity light
- * Make your gesture and then press to
- 1 Thumbstick (Teleport, Rotate)*
- 6 Grab button (Grasp) Quickly blinking: Pairing mode Slowly blinking: Idle mode
- On: Headset is on. Make your gesture and then press to execute your action.

SR 1 Thumbstick (Teleport, Rotate)*

SL 1 Thumbstick (Teleport, Rotate)*

2 Menu button

Windows® button

6 Grab button (Grasp)

Low battery level

Blinking (3 times):

On: Headset is on.

execute your action.

FI 1 Thumbstick (Teleport, Rotate)*

6 Microphones (2)

Activity light

2 Menu button

Windows® button

Grab button (Grasp)

Blinking (2 times):

Low battery level

8 Microphones (2)

Activity light

Blinking (3 times): Critical battery level

On: Headset is on.

execute your action.

Quickly blinking: Pairing mode

* Make your gesture and then press to

Slowly blinking: Idle mode

5 Trigger (Select)

TouchPad*

Liahts

Critical battery level

Quickly blinking: Pairing mode

* Make your gesture and then press to

Slowly blinking: Idle mode Blinking (2 times):

5 Trigger (Select)

TouchPad*

Lights

- 2 Menu button
- TouchPad* Windows® button
- 6 Trigger (Select) 6 Grab button (Grasp)
- Lights Ouickly blinking: Pairing mode Slowly blinking: Idle mode Blinking (2 times): Low battery level Blinking (3 times):
- Critical battery level 8 Microphones (2) Activity light
- On: Headset is on. * Make your gesture and then press to execute your action.

SE 1 Thumbstick (Teleport, Rotate)*

- 2 Menu button TouchPad* Windows® button
- 5 Trigger (Select) Grab button (Grasp) Lights Quickly blinking: Pairing mode Slowly blinking: Idle mode Blinking (2 times):
- Critical battery level 8 Microphones (2) Activity light

Low battery level

Blinking (3 times):

- On: Headset is on. * Make your gesture and then press to execute your action.
- TH 1 Thumbstick (Teleport, Rotate)*
- Menu button TouchPad*
- Windows® button 6 Trigger (Select)
- 6 Grab button (Grasp) Lights Quickly blinking: Pairing mode Slowly blinking: Idle mode Blinking (2 times): Low battery level
- Blinking (3 times): Critical battery level 6 Microphones (2)
- Activity light On: Headset is on. * Make your gesture and then press to execute your action.
- TR 1 Thumbstick (Teleport, Rotate)* Menu button TouchPad*
- Windows® button 5 Trigger (Select) 6 Grab button (Grasp)
- Quickly blinking: Pairing mode Slowly blinking: Idle mode Blinking (2 times): Low battery level
- Blinking (3 times): Critical battery level 8 Microphones (2)
- 9 Activity light On: Headset is on. * Make your gesture and then press to execute your action.
- UK 1 Thumbstick (Teleport, Rotate)* Menu button
- TouchPad* Windows® button
- Trigger (Select) 6 Grab button (Grasp) Lights Quickly blinking: Pairing mode
- Slowly blinking: Idle mode Blinking (2 times): Low battery level Blinking (3 times): Critical battery level
- 8 Microphones (2) Activity light On: Headset is on. * Make your gesture and then press to execute your action.



© Copyright 2019 HP Development Company, L.P. Bluetooth is a trademark owned by its proprietor and used by HP Inc. under license. Windows is either a registered trademark or trademark of Microsoft Corporation in the United

States and/or other countries he information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statement

accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein. First Edition: January 2019

On: Headset is on. Make your gesture and then press to

execute your action

JA 1 Thumbstick (Teleport, Rotate)*

Quickly blinking: Pairing mode

Slowly blinking: Idle mode

Menu button

4 Windows® button

6 Grab button (Grasp)

Blinking (2 times):

Low battery level

Blinking (3 times):

6 Microphones (2)

Activity light

Critical battery level

5 Trigger (Select)

TouchPad*

Lights

- KO Thumbstick (Teleport Rotate)* 2 Menu button
- TouchPad*
- Windows® button 5 Trigger (Select)
- 6 Grab button (Grasp) Lights Quickly blinking: Pairing mode Slowly blinking: Idle mode
- Blinking (2 times): Low battery level Blinking (3 times):
- Critical battery level 8 Microphones (2)
- On: Headset is on. Make your gesture and then press to execute your action
- CN Thumbstick (Teleport, Rotate)*
- Menu button TouchPad*

Activity light

- Windows® button
- 5 Trigger (Select) 6 Grab button (Grasp) Lights Ouickly blinking: Pairing mode
- Slowly blinking: Idle mode Blinking (2 times): Low battery level Blinking (3 times): Critical battery level Microphones (2)

* Make your gesture and then press to

- Two Thumbstick (Teleport, Rotate)* 2 Menu button

TouchPad

Lights

Activity light

On: Headset is on.

execute your action.

Windows® button 5 Trigger (Select) Grab button (Grasp)

> Quickly blinking: Pairing mode Slowly blinking: Idle mode

- Low battery level Blinking (3 times): Critical battery level
- Microphones (2) Activity light On: Headset is on. * Make your gesture and then press to

Blinking (2 times):