


中



Monster Airmars XK006
真无线蓝牙耳机
使用说明书

产品参数

蓝牙版本	V5.4
传输距离	>10m
喇叭直径	Φ16.2mm
喇叭阻抗	20Ω±15%
灵敏度	124±3dB
频率范围	50Hz-20KHz
电池容量(充电盒)	400mAh 3.7V
电池容量(耳机)	70mAh 3.7V
充电时间(充电盒)	≈2.5小时
播放时间(耳机)	≈10小时
配合充电盒播放时间	≈30小时

包装清单

耳机 *2	充电盒 *1
使用说明书 *1	Type-C 充电线 *1

产品示意图

耳机 指示灯 功能触控键 (MFB) 充电触点 Type-C 充电盒

给充电盒充电

用Type-C充电线连接充电盒到5V电源适配器。

额定输入: 5V=70mA(耳机) 额定输入: 5V=400mA(充电盒)

指示灯指南

模式	描述	语音提示
关机	耳机红色指示灯闪烁3次	"Power on"
开机	耳机红色指示灯长亮1秒	"Power off"
配对	主耳蓝色指示灯交替闪烁, 副耳熄灭	"Pairing"
连接	耳机指示灯熄灭	"Connected"
断开	主耳蓝色指示灯交替闪烁, 副耳熄灭	"Disconnected"
耳机低电	耳机红色指示灯闪烁	"Battery low"
耳机盒低电	充电盒红色指示灯长亮	---
耳机盒低电	充电盒红色指示灯闪烁	---
充电盒低电	充电盒红色指示灯长亮	---
充电盒低电	充电盒红色指示灯闪烁	---
充电盒充满	充电盒绿色指示灯长亮	---

产品操作说明

1. 开机
方式一: 打开充电盒上盖, 取出耳机自动开机。
方式二: 长按左/右耳机的MFB按钮约3秒, 耳机开机。
2. 关机
方式一: 将耳机放回充电盒中, 耳机自动关机。
方式二: 与蓝牙耳机断开连接3分钟后, 自动关机。
3. 配对
步骤一: 打开充电盒上盖, 取出耳机自动开机。
步骤二: 打开智能设备的蓝牙列表, 搜索 "Monster Airmars XK006" 进行配对, 连接成功后, 你会听到提示音 "Connected"。

* 超出距离, 在断开连接3分钟后, 回到有效范围, 自动连接设备。

触控操作

常闭模式

语音助手: 长按2秒左耳机MFB
音量加: 单击右耳机MFB
音量减: 单击左耳机MFB

音乐播放模式

暂停/播放: 双击左/右耳机MFB
上一曲: 三击左耳机MFB
下一曲: 三击右耳机MFB

电话免提

接听: 双击左/右耳机MFB
挂断: 双击左/右耳机MFB
拒接: 长按2秒左/右耳机MFB

模式切换: 已连接

游戏模式: 长按2秒右耳机MFB进入游戏模式
音乐模式: 长按2秒右耳机MFB进入音乐模式

恢复出厂设置

1. 耳机开机后未与蓝牙设备配对状态下, 左/右耳机同时长按, 连左/右耳机5秒后左/右耳机关机 (清除配对和连接的所有信息)
2. 耳机连接状态, 左/右耳机连击5次, 35秒内按105后关机 (清除配对和连接的所有信息)。

注意

- 1.从充电盒取出耳机, 不要任何接触, 耳机自动开机, 连接或配对, 耳机放入充电盒, 充电盒将自动关机并充电, 耳机关机。
- 2.避免高温、潮湿、灰尘等环境, 建议15天内充电1次, 延长电池寿命。耳机需充电部分使用棉布清洁擦拭, 避免吸取充电磁, 避免接触水, 影响使用体验。
- 3.请勿将耳机或充电盒自行拆解或拆卸, 拆解或拆卸过程中可能会导致损坏, 禁止拆解、撞击、挤压或放入水中, 以免造成严重损坏, 切勿将耳机放入微波炉中加热, 禁止长时间暴晒。
- 4.由于本产品采用无线充电方式, 在日常使用中, 应避开微波炉、手机充电器、使用炉等电磁影响, 可能会使播放音质下降, 会出现延迟, 轻触的耳机音量会降低等异常。

警告

- 1.长时间高音量使用耳机可能会损害听力, 建议只使用适当音量收听, 请保持所告知。
- 2.请不要将耳机或产品放入水中, 以免造成损坏。
- 3.不要自行拆解产品及其附件, 以免造成损坏及保修失效。
- 4.请勿将产品带到禁止使用电子设备的地方。
- 5.请勿将化学溶剂或清洁剂弄到本产品。

Name of the Parts		Hazardous Substances							
部件名称		有害物质							
Flourescent	外壳	汞	镉	铬	六价铬	PBB	多溴联苯	PBDE	多溴二苯醚
Flourescent	外壳	0	0	0	0	0	0	0	0
Flourescent	喇叭单元	0	0	0	0	0	0	0	0
PCBA	电路板组件	X	0	0	0	0	0	0	0
Accessories	包装纸、说明书	X	0	0	0	0	0	0	0

This table is compiled according to SJ/T 11364.
本表格依据SJ/T 11364标准编制。

0: Indicates that this hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in GB/T 26572.
0: 有害物质含量在所有均质材料中均低于GB/T 26572标准规定的限值。

X: Indicates that this hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in GB/T 26572.
X: 有害物质含量在所有均质材料中至少有一项高于GB/T 26572标准规定的限值。

FCC 声明

根据FCC规则第15部分, 本设备经过测试, 符合B类数字设备的限制。这些限制旨在提供合理的住宅环境中的有害干扰防护。该设备产生使用并可能辐射射频能量, 如果未按指定安装和使用该设备可能会对无线电信号造成有害干扰。然而, 有不兼容证在特定安装中不会发生干扰。如果这个设备对无线电或电视接收造成有害干扰, 可通过以下措施来避免: 重新定位或重新定位接收天线。
-增加设备与接收器之间的距离。
-将设备连接到与接收器不同的电路上的插座已连接。
-请咨询经销商或经验丰富的无线电/电视技术人员以获得帮助。

此设备符合FCC规则的第15部分, 操作受以下两个条件限制:
(1) 本装置不得引起有害干扰。
(2) 本装置必须接受任何接收到的干扰, 包括可能导致意外操作的干扰。未经合规责任方明确批准的变更或修改可能使用户对设备的操作失效。

FCCID: 2ABPV-QSMXK006

Environment Friendly Use Period (EFUP)

This logo refers to the period (10 years) during which the hazardous substances in electronic and electrical products will not leak or mutate so that the use of these [substances] will not result in any severe environmental pollution, any bodily injury or damage to any assets.
这标志所指的期间 (10年) 是电子电气产品中有毒物质在正常使用的条件下不会发生泄漏或突变, 电子电气产品用户使用该电子电气产品不会对环境造成严重污染或对其人身、财产造成严重损害的时间。

保修卡

尊敬的客户, 本保修卡是您购买本产品的凭证, 请您妥善保管并妥善保管使用!

用户信息

用户姓名	电子邮箱
联系电话	邮政编码
联系地址	

产品信息


产品名称	产品型号
产品条码/编号/批号	

销售信息

名称	
地址	
联系电话	邮政编码
销售日期	发票号码
备注	

M MONSTER 合格证
产品编号: _____
生产日期: _____

英



Monster Airmars XK006
True wireless Bluetooth headphone
instruction manual

Product parameters

Bluetooth version	V5.4
Transmission distance	>10m
Driver diameter	Φ16.2mm
Driver impedance	20Ω±15%
sensitivity	124±3dB
Frequency response	50Hz-20KHz
Battery capacity(Charging case)	400mAh 3.7V
Battery capacity(Headphone)	70mAh 3.7V
Charging time(Charging case)	≈2.5 hours
Music playtime(Headphone)	≈10 hours
Music playtime with charging case	≈30 hours

Product Schematic Description

Headphone*2 充电盒*1

Instructions Manual*1 Type-C Charging cable*1

Product Schematic Description

Indicator 充电触点 Type-C 充电盒

Charge the charging case

Connect the charging case to the 5V power adapter with Type-C charging cable.

Rated input: 5V=70mA(Headphone) Rated input: 5V=400mA(Charging case)

Indicator guide

TPS: When the cover of the charging box is closed, the indicator light of the charging box flashes for 3s, please charge the charging box.

Mode	Describe	Sound prompt
Power On	Ice blue light on the headset blinks three times	"Power on"
Power Off	Red indicator on the headset will be on for 1s and then turn off automatically	"Power off"
Pairing	Ice blue and red light flashes alternately in the main ear, and the secondary ear is extinguished	"Pairing"
Connected	Headphones LED indicator is off	"Connected"
Disconnected	Ice blue and red light flashes alternately in the main ear, and the secondary ear is extinguished	"Disconnected"
Low Battery	Red indicator on the headset blinks	"Battery low"
Headphones placed in charging case	Red indicator on the charging case is steadily on	---
Headphones charging case low power	Red indicator of the charging case blinks	---
Charging case fully charged	Red indicator of the charging case blinks	---
Charging case fully charged	Seven indicator of the charging box is steadily on	---

Product operating instructions

1. Power on
Method 1: Open the top cover of the charging case, take out the headset and turn it on automatically.
Method 2: Long press the MFB button of the left/right headset for about 3 seconds to power on the headset.
2. Power off
Method 1: Put the earphones back in the charging case and the earphones automatically turn off.
Method 2: The device automatically shuts down after 3 minutes of disconnection from the Bluetooth device.
3. Pairing
Step one: Open the top cover of the charging case, take out the headset and turn it on automatically.
Step two: Open the Bluetooth list of smart devices, search for "Monster Airmars XK006" to pair, and the connection is successful After that, you will hear the "Connect" tone.

* Headphones will try reconnecting to the device within 3 minutes when connection is lost.

NOTE:

- * Fully charge the headphones and power off before an intended not-in-use period.
- * Unplug the charging cable after charging.

Operation

Normal

Voice Assistant: Press and hold left MFB for 2 S
Volume +: Click right MFB
Volume -: Click left MFB

Music playback

Pause/Play: Double click Left/Right MFB
Last song: Three hits left MFB
Next song: Three hits right MFB

Phone

Answer: Double click the left/right MFB
Hang up: Double click the left/right MFB
Reject: Long press left/right MFB for 2 S

Mode switching : Device connected

Game mode: Press and hold right earphone MFB for 2 seconds enter Game mode
Music mode: Press and hold right earphone MFB for 2 seconds enter Music mode

Restore factory settings

1. If the headset is not paired with the Bluetooth device after the headset is turned on, the left/right headset is paired successfully. After clicking the left/right headset for 5 times, the left/right ear is turned off (all information about pairing and connection is cleared).
2. In the power-on connection state, tap the left and right headphones five times, hold down for 10S within 3S, and then power off (clear all pairing and connection information).

Precautions

1. Take out the earphone from the charging box, without pressing any button, the earphone will automatically turn on, connect or pair out the earphone into the charging box, and the charging box will automatically charge your headphones. Turn them off.
2. Often clean, long life, if not used for a long time, it is recommended to charge once every 15 days to extend battery life, and the charging part of the headset is often used with cotton swabs alcohol wipe, can help smooth charging, avoid bad contact, affect the use experience.
3. The battery (battery pack or battery combination) shall not be exposed to lightning, baking or similar overheating environment. Do not disassemble, knock, squeeze or throw in the fire, if there is serious swelling, do not continue to use. Do not place in high temperature environment. Do not use after soaking water.
4. Because this product adopts wireless connection mode, it is affected by environment, mobile phone brand, usage behavior and other factors in daily use, it may be normal to have a brief, slight sound delay during the playing of music.

Warnings

1. Do not use headphones at high volume for an extended period of time.
2. Keep the headphones away from dust and water.
3. Do not disassemble the headphones and accessories, otherwise warranty will be voided.
4. Keep headphones away from any impact or vibration.
5. Do not use any chemical solvents or cleaning agent on the headphones.

Name of the Parts		Hazardous Substances							
部件名称		有害物质							
Flourescent	外壳	汞	镉	铬	六价铬	PBB	多溴联苯	PBDE	多溴二苯醚
Flourescent	外壳	0	0	0	0	0	0	0	0
Flourescent	喇叭单元	0	0	0	0	0	0	0	0
PCBA	电路板组件	X	0	0	0	0	0	0	0
Accessories	包装纸、说明书	X	0	0	0	0	0	0	0

This table is compiled according to SJ/T 11364.
0: Indicates that this hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in GB/T 26572.
X: Indicates that this hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in GB/T 26572.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure condition without restriction.

FCCID: 2ABPV-QSMXK006

Environment Friendly Use Period (EFUP)

This logo refers to the period (10 years) during which the hazardous substances in electronic and electrical products will not leak or mutate so that the use of these [substances] will not result in any severe environmental pollution, any bodily injury or damage to any assets.

Warranty Service

Dear user, this warranty card is the proof of your future warranty application, please cooperate with the seller to fill it out and keep it for future use!

User info

User name	Email
Contact number	Postal code
Mailing address	

Product information

Product name	Product number
Product barcode / Serial number / Batch number	

Vendor information

Name	
Address	
Contact number	Postal code
Sales date	Invoice number
Remark	

M MONSTER Certificate of Approval
Product No.: _____
Production Time: _____
QC: _____

文件名称	魔声XK006说明书			材料	全书60g书纸+单黑印刷+骑马钉		单位	mm	厂商物料编号		变更履历		修改		日期	
文件尺寸	60X90mm（单P尺寸）			工艺	1C印刷 风琴折		公差	±0.5mm	XXXXXXXXXX		审核			批准	日期	
设计日期	2024/02/19	文件版本	2024V01				比例	1:1							日期	

PCB