660 mm(W)

THE COMMUNITY INCLUDES

Sign up now for · special offers events · contests · access to new products launch




www.muveacoustics.com/community



User Manual and Warranty


STORY



ALL FUNCTIONS

Functions vary depending on your phone, tablet or application.

FEATURES STORY



HARGING PORT

Impedance

Play time

Rattery type

Recharge time

Dimensions

Battery capacity

Charging method

Bluetooth profiles Connectivity class Bluetooth Class 2 (10 meter) High performance driver 2 x Ø10 mm 20 Hz - 20 kHz Frequency response 103dB +/- 3dB at 1kHz

Type-C or Wireless charging 2 x 40 mAh (earbuds) 00 mAh (charging case)

SPECIFICATIONS

7hours and the charging case can provid 3times for earbuds charging.) Approx. 1 hours (earbuds) 27 x 26 x 25.5 mm (LxWxD(earbuds)

one of the earbuds stopped flash, the left

and right earbuds are paired successfully.

At this time, it can be connected to the

Bluetooth equipped device. Make sure

Bluetooth Connection

To use Bluetooth for your audio connec- | connections. Press 'pair' or 'connect' on your tion, first pair NEO earbuds with your audio device and after the connection is made, the source (music player, smartphone, laptop or | indicator light will off. (Support single earbud other Bluetooth equipped device that can use) act as audio source). Make sure NEO | From now on, when you turn on NEO earbuds, it earbuds is fully charged and turn it on by will automatically search for the last Bluetooth take out from the charging box. When device it was paired with. take out both earbuds form the charging box at the same time. The LED indicator light will flash between red and blue. When

Bluetooth is enabled on your audio source | Earbuds Battery Charging and in a few moments 'MUVEACOUSTICS:NEO' | Put the earbuds into the charging box, it will

will appear on your list of possible Bluetooth automatically shut down and start charging.



Charging Case Battery Charging with USB Charger

Please use the cable

provided to recharge the

narging case. It will take 2



take 3 hours to fully Next Track | right (Next) touch

GUIDANCE

				. Vol
Function	Button	Audio	LED] , '''
Turn On & the pairing mode	Take out the earbuds from the charging box	N/A	Red & Blue light flashing	Vol
Pairing success		1 tone		An
Play / pause	Tap the touch control area once	N/A	N/A	En
Turn Off	Put the earbuds into the charging box	N/A	LED lights turn off	Rei
Previous Track	Tap and hold the	1 tone	N/A	l Voi

'ume Down Tap the left touch N/A control area twice lume Up Tap the right control N/A touch area twice charging Tap the touch N oming call | control area once nd a call Tap the touch 2 tones Tap & hold coming call the touch control area for 2 seconds Voice Assistant | Tap the touch | 1 tone control area 3 (depend on the battery fully nnected device) times

Earbuds battery Earbuds' Red LED on Charging Case Blue LED on Earbuds battery Earbuds' LED off fully charged Charging Case's LED off Charging case Charging Case's Blue LED flashing Charging Case's Blue LED on charged

封面 (cover) 封底 (back cover)





SOUND THAT INSPIRES







Warnings

hazard. Not suitable for children under age three. Set a low volume setting before using the earbuds. Long-term exposure to loud music or sounds

may cause hearing damage. It is best to avoid high volume levels when using these earbuds, especially for extended periods.

 Do not use these earbuds when operating a motor vehicle, a bicycle, machinery or where your inability to hear outside sounds may present a danger to you or others.

Using these earbuds limits your ability to hear

• Contains small parts which may be a choking be immersed in water.

This symbol indicates that this product shall not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling

Unsuitable for children under three years

listen at high volume levels for long periods

Please use caution when using these earbuds. • Do not drop, sit on, or allow the earbuds to

charge the product. DO NOT USE Quick

of electrical and electronic equipment.

because it might, for instance, contain

To prevent possible hearing damage, do not

noises around you, regardless of listening volume. | A The input voltage to the product is 5V 1A. For your safety, please always use appropriate 5V output charger/Adapter to

Charging USB Adapter to charge the product, as it might damage the product. The USB charging cable included with this item is intended for use with this product only. Only use the included USB charging cable to charge this product. Only operate the product at ambient temperatures between 10°C/50°F and 40 °C/104 °F. The unit should be stored below 70°C/158°F.

Switch off the product after use. Please note that we won't take any responsibility for any wrong operation (eg. Voltage higher than 5V) as this may result in severe injury or loss of property, and we

development.

NOTE: This equipment has been tested and | the following measures: found to comply with the limits for a Class B reasonable protection against harmful | and receiver. interference in a residential installation. This | - Connect the equipment into an outlet on a radio frequency energy and, if not installed connected. and used in accordance with the instructions, I - Consult the dealer or an experienced radio/TV may cause harmful interference to radio technician for help.

during the time the user using this | that interference will not occur in a particular | by the party responsible for compliance could void product. In extreme cases, abuse or misuse installation. If this equipment does cause harmful the user's authority to operate the equipment. of Lithium battery pack can lead to explosion, | interference to radio or television reception, | This device complies with Part 15 of the FCC Rules. heat generation, fire development or smoke which can be determined by turning the Operation is subject to the following two conditions: equipment off and on, the user is encouraged to | (1) this device may not cause harmful interfertry to correct the interference by one or more of ence, and

digital device, pursuant to part 15 of the FCC | Regrient or relocate the receiving antenna. Rules. These limits are designed to provide - Increase the separation between the equipment

equipment generates uses and can radiate | circuit different from that to which the receiver is

cannot control the operating process | communications. However, there is no guarantee | Changes or modifications not expressly approved , MUVEACOUSTICS NEO earbuds have been

> (2) this device must accept any interference undesired operation.



FCC ID: 2ADM5-MA-3045

ONE-YEAR LIMITED WARRANTY

subjected to a thorough series of tests to ensure the highest level of dependability. It is unlikely received, including interference that may cause that you will experience any problem, but if a This warranty does not cover normal wear and for a period of 12 months from the date of your al, professional or commercial purposes. original purchase from an authorized dealer. If a 005330/31 defect covered by this warranty occurs,

MUVEACOUSTICS, at its option, will repair or replace the product purchase at no repair charge (postage charges will apply). If a replacement is necessary and your product is no longer available, a comparable product may be substituted at the sole discretion of MUVEACOUSTICS.

control area 2 sec

| defect should become apparent during the use | tear, abusive use or misuse, modification, of this product, MUVEACOUSTICS warrants to tampering or by any other cause not related to the original purchaser that this product will be either materials or workmanship. This warranty free from defects in material and workmanship does not apply to product used for any industri-

For service on any defective under 12

Email: consumersupport@zeeva.com

Keep all relevant information for future reference eva International Limited. All rights reserved

Suite 1007B-1008, 10/F, Exchange Tower 33 Wang Chiu Road, Kowloon Bay, Hong Kong



Thank you for trusting MUVEACOUSTICS with delivering you excellence in sound. We encourage you to connect with us and become a part of our community!

SCAN THE QR CODE YOU WILL FIND INSIDE. SHARE WITH US YOUR PRODUCT EXPERIENCE.

(back

THE COMMUNITY INCLUDES:

Sign up now for
• special offers
• events
• contests
• access to new products launch



True Wireless

EARBUDS

____ Play time

. Dimensions

Recharge time

YOUR EARBUDS




me Up	Tap the right control touch area twice	N/A		Earbuc chargir Earbuc fully ch
ver ming call	Tap the touch control area once	N/A		
a call	Tap the touch control area once	2 tones		
ise ming call	Tap & hold the touch control area for 2 seconds	N/A		Chargii battery
e Assistant	Tap the touch	1 tone		Charair

number





' MuveAcoustics



MuveAcoustics

INSTRUCTIONS

Unsuitable for children under three years because it might, for instance, contain small parts.

noises around you, regardless of listening volume Please use caution when using these earbuds. • Do not drop, sit on, or allow the earbuds to

ONE-YEAR LIMITED WARRANTY




Suite 1007B-1008, 10/F, Exchange Tower, 33 Wang Chiu Road, Kowloon Bay,















SERVICES

delivering you excellence in sound.
We encourage you to connect with us and become a part of our community!

SCAN THE OR CODE YOU WILL FIND INSIDE.

SHARE WITH US YOUR PRODUCT EXPERIENCE.

