

(Fold Inward)

(Back Cover)

(Front Cover)

Compliance Information


Warranty Information

Phone Calls

- Press the [P/] button to answer an incoming phone call.
- 2x Press the [P/] button to end a phone call.
- 2x Press the [P/] button to reject an incoming call.

LED Light Function

- Press the [] button to turn the LED Light function ON/OFF.



[/] Button:
Power On/Off
Play/Pause Media
Answer/End Calls

Rating Label Definitions

-  Direct current symbol.
 This symbol signifies it to an appropriate collector resources, human nest
 This symbol signifies a



- and should be delivered
helps protect natural

Before You Begin...

Caution


Caution To ensure safe and proper use, read all safety information before using the device. Only use with manufacturer-approved batteries, chargers, accessories, and supplies.

- **THIS DEVICE IS NOT A TOY**, do NOT allow children or pets to use or play with this device.
- Do not disassemble, modify, or repair the device.
- Do not expose the unit to extreme temperatures (heat or cold), open flames, humid, or wet conditions.
- Do not submerge in water.
- Low power may cause poor Bluetooth connection or sound distortion.
- Do not overcharge battery.
- If using with a USB adapter, make sure the adapter is not damaged.
- Do not allow the Type-C port or the connectors of the supplied Type-C cable to be exposed to dust, or water, or come into contact with any conductive materials such as liquids, metal, and so on.
- The adapter and its accessories should not be disposed of with regular household waste. Please consult the local authorities on the correct way to dispose of this device.

In the Box

- Wireless LED Headphones (x1)
- USB Type-C Charging Cable (x1)
- Instruction Manual (x1)


Location of Controls



Getting Started

Charging the Headphones

Plug the small connector of the included charging cable into the TYPE-C charging port on the headphones. Plug the large connector into a USB power source such as the USB port on a computer, or a 5V USB adapter (not included) and plug into a wall socket.




Powering ON/OFF

Please charge the headphones fully before using.

- **Long-Press (3s)** the [] button to power the headphones ON. The LED indicator will flash BLUE.
- When powered ON, the headphones may automatically reconnect to the device most recently paired to, so long as that device is within connection range (33 ft), and Bluetooth is enabled
- **Long-Press (3s)** the [] button to power the headphones OFF. The LED indicator will turn OFF.

Bluetooth Pairing

1. Power the headphones ON.
2. Set your mobile device to search for Bluetooth devices. When it appears, select BSBTH24WH from the list of found devices.
3. Once successfully paired, a tone will be heard, and the LED indicator will turn solid BLUE. When playing music, the LED indicator will turn solid BLUE.



Playback will be controlled from your paired device, or the controls on the headphones' earcup:

- **2x Press the [] button to PLAY/PAUSE playback.**
- **Press the [] button to DECREASE the volume.**
- **Press the [] button to INCREASE the volume.**
- **Long-Press the [] button to continue decreasing the volume.**
- **Long-Press the [] button to continue increasing the volume.**
- **2x Press the [] button to skip to the NEXT track.**
- **2x Press the [] button to skip to the PREVIOUS track.**