

AM171-RD86 Android System User Use Instruction

rugged tablet

Foreword:

Dear user, thanks for you use our company product. In order to you faster know about product, please reference file instruction when you have question. The file main instruction I86 item body interface and system use instruction. By picture sign information, user can faster know about the way of product. Please connect our company technology staff to deal, when you encounter question you can't deal with, thanks for your faith.

content

1.File version information	.2
2.Device performance structure	.3-5
3.Desktop layout	.6-8
4.Menu layout	.8
5.System setting	.8-19

Filo	e name			ST86 Andro	oid	system user use introd	uctio	n
File	number		0002			version		V1. 0
Issue	e date		2017-04	-19		page		
Change record								
Number	Change num	ıber	Version	sion Change da		Change content		Maintenance department
1	YDXX-0	2	V1. 0	2017-04-28	}	First published		Service FAE department

Device function interface description:

Device front (touch screen/display screen/front camera/sign light/light sense)



Device back (suona/back camera/NFC induction zone)



Device right about



Device flank





Device flank



Initial page: Lock screen layout, Unlock the slide, as the follow of picture:



Initial desktop:

Press OK enter desktop, as the follow of picture:



Initial menu:

Press OK enter menu, as the follow of picture:



Desk reference:

In the layout, you can start application program by shortcut, entering menu ect operation, user can add shortcut of application, according to their need, as follow:



Menu interface:

System bring application and the application of user installation all will appear in this ar ea, all application can open, as the follow of picture:



System setting:

User can system stall in this area, detail please scan the next picture1.0

3			0.0.134
Settings			¢.
Windows & networks	Wifi and net		
♥ WI-Fi ←	WiFi	🗱 Bluetooth <	bluetooth
O Data usage - Flux	used condition	••• More	More than
Device	device		
O Display	display	🛄 номі 🧲	HD
Sound & notification <	warning tone	📕 Storage 🧲	storage
Battery <	battery	C Apps	apply
🚨 Users <	user	🖓 Тар 🖩 рау 🧲	Touch pay
	Ø	0 0	

1.1	
14 () () () () () () () () () (0 0 134
Settings	٩
Intel Smart Video	
Personal	
● Location ← Position information ■ Security ←	safe
Accounts Caccount account	← Language and input
Backup & reset	
System	
Date & time Cate and time	unobstacle
About rugged tablet	
4 O 🗆	

WiFi setting:

You can search WiFi AP, after choosing AP input mode can connect, under higher setting can directly connect WLAN, WLAN sleepy condition ectsetting, as the follow of picture:

12 19 4	`			.# 10 Q 1146
*	Wi-Fi			
	On			
•	AC			
٠	EM-guest			setting WiFi switch
•	EM-office			
۰.	EM-public	<u> </u>		
•	emdoorinfo_key		WITAP	
₩.	ChinaNet/ED5R			
•	EM-gm			
-	HISINO			
		Þ	0	0

Bluetooth setting :

In this layout can bluetooth search match, delete or cancel matched bluetooth. as the follow of picture:



Data flux setting:

When you connect mobile network, you can set data flux switch, supervisory application flux use condition, as the follow of picture:



7 9 1	ki l	⊲	0	
-------	------	---	---	--

Other setting

In this layout can start and put off fight mode, on or off NFC, setting network share and convenient hotspot, VPN setting, manual or automation create net and so on. as the follow of picture:

⊂ ⇒ A ← More	4 ≊ 0 1947 Q
Aimlane mode Flight mode	(2)
NFC NFC setting	
Android Beam Ready to transmit app content we NFC	
Tethering & portable hotspot Convenient	hotspot
VPN VPN setting	
Celular networks Kenter Mobile n	etwork
Ethernet configuration Ethernet setting	

⊲ 0 □

Display setting:

In this page can light regulate, change desktop picture, sleepy time setting, interaction screensaver, typeface size, screen gyrate switch and so on operation, as the follow of picture:

2 H A	4 0 147
← Display	Q
Brightness level	
Wallpaper	
Sleep After 1 minute of linearbidity	
Daydream	
Font size Normal	
When device is rotated. Rotate the contents of the screen	

		Þ	0		
--	--	---	---	--	--

Alert tone and inform setting:

In this page can set media volume, alarm clock volume, inform volume size(also can directly use physical key regulate in suitable interface), avoid disturb setting, inform ring setting and so on operation, please scan the next picture:

⊇ % A			_	# 0.0 197
← Sound & notification				Q,
Simul				
Media volume				
40				
Alarm volume				
U				•
Notification volume				
A				•
Interruptions				
Default notification ringtone Price Dutt				
Other sounds				
Netforation				
	\bigtriangledown	0		

Storage setting:

In this layout can look up system internal applied internal use situation, stall and unload SD card, please scan the next picture:

12 M A	A	# 10 Q 1947
*	Storage	۹ (
Antarra	al storage	
Total 25.55	spece.	
1	Available 25 Yatali	
	Apps (app data & media content) 271348	
	Pictures, videos 3.46MD	
	Audio (music, ringtories, podcasts, etc.) 40.00KB	
	o ک	0

Battery setting:

In this layout can scan battery power used conditional increase and decrease condition, used applied electric conditional:

12 H A	A				10.04	1 1947
÷	Battery			Q,	Санынын	÷
100%	- Charging on AC					
100%						
23.			ID secs			-
Batte	ry usage data isn't available.					
		Ø	0			

User setting:

In this meet user can add or delete account, as the follow of picture:



<	0	

Intel only video:

In this layout can open increase video. After start the mode can reduce noise, clean up interlaced scan content emerge false appearance, increase video quality. as the follow of picture:



Position information:

In this layout can start or shut GPS, or control some application use position information, as the follow of picture:



Safe setting:

In this layout can set screen lock ways and some encryption setting, can charge unknown origin apply installation and so on setting, as the follow of picture:

				*▼,≋≣1	0:12
÷	Security				۹
Screen	security				
Screen Swipe	lock				
Owner	info				
Smart To use,	Lock first set a screen lock				
Passw	vds				
Make	passwords visible			-	
Device	administration				
Device View o	administrators deactivate device administrators				
Unkno	wn sources				
	<	1	0		

Language and typewriting setting:

In this layout can set appear language and typewriting, word switch voice, mouse/touch board(guide spread)etc. as the follow of picture:

8			₩ ♥, 0 0 10:22
← Language & input			٩
Language English (United Statest)	Display	y language	
Spell checker Antroid Toell Clecker (ADSP)			
Personal dictionary			
Keyboard & Input methods			
Current Keyboard English (US) - Anthond Hispboard (ADSP)			
Android Keyboard (AOSP) English (US)			
Speech			
Text-to-speech output			
	Ø	0	

Backups and restart:

In this layout can data backup and recover factory set, recover factory set can clean up all content, please careful operation, as the follow of picture:



Date and time setting:

In this layout can set time, time zone and time form, 24 hours or 12 hours, also can open automatic confirm, after device connecting net can automatic step. as the follow of picture:



Relaxed use:

In this layout can personal operation habit setting, such as : bigger gesture, caption, bi g typeface, high contrast word, automatic gyrate screen switch, voice speak password an d other operation, as the follow of picture:

2 H A			4 11 0 1049
 Accessibility 			٩
Services			
No services installed			
System			
Captions Off			
Magnification gestures DM			
Large text			100
High contrast text (Experimental)			(8)
Auto-rotate screen			-
Q Q Q			
	Ø	0	

About rugged computer:

In this layout can look up status information, device model, android version, Android pa tch procedure rank, baseband version(mobile net mode model), core version, software ve rsion and so on. As picture1/ picture2:

12 18	*				1 1 0 1549
*	About tablet				٩
Firm	ware updates				
Wite	iess update				
Statu	at a of the battery, retream, and	offse information		picture1	
Lega	t information				
Mode Pugg	el number edPadition				
Andr 11.1	old version				
Andr 2016	old security patch level de d1				
		Ø	0		

12.48	*				1 10 10 1049
÷	About tablet				Q
Lega	al information				
Mod	lei number periPadilitàr				
And	roid version				
And 7018	rold security patch level.			Picture 2	
Base	eband version 0_V2A.0C.00 /01_T01				
Kerp 2.14	ef version 37				
Bulk 2017	d number 10723.012607				
		Ø	0	0	

Status information:

In this layout can look up battery condition, battery power, SIM card condition, IMEI information IP address WLANMAC address bluetooth address serial number opened time and so on. As picture1/ picture2:

About tablet		+ € 0 150
Formware upstattes	Status	
Winissu update	Battery status Charging on AC	
The fail and the f	Battery level	
Legal information Model number	SIM status Pic	ture
Reprintation	IMEI information	_
Andruad Version	IP address Unovaliatrie	
Annual accumy patch in-	185.E) 883/* addimen	
		0



FCC Caution:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

This Product meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health.

FCC RF Exposure Information and Statement the SAR limit of USA (FCC) is1.6 W/kg averaged over one gram of this Device AM171-RD86 (2A3JZ- AM171) has been tested against this SAR limit. SAR information on this can be viewed on-line at http://www.fcc.gov/oet/ea/fccid/. Please use the device FCC ID number for search. This device was tested for typical operations Omm from the body. To maintain compliance with FCC RF exposure requirements, Omm separation distance should. maintained to the user's bodies

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radiofrequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However,

there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

The WLAN function for this device is restricted to indoor use only when operating in the 5150 to 5250 MHz frequency range.

The end!

Thanks!

Please connect us if you have any question!