


Dimensions: 546.975mm x 95mm
Print 4 color, 2 sided, accordion fold



- Mobile device with WiFi enabled (requires iOS 12 or Android 11 and above)
- MicroSD card (256GB Max)

- Exercise all due caution when using this product and obey all applicable traffic laws.
- Do not install the product in a location where it can interfere with the driver's vision of the road and surroundings, or interfere with vehicle operating controls.
- Do not place unsecured on the vehicle's dashboard.
- Never attempt to take pictures, view recordings, or adjust the product while driving.
- Do not expose the product to sun or moisture, and do not use near water such as swimming pools, bathtubs, or sinks.
- Do not expose the product to excessive heat.
- Do not use the product in a strong magnetic field.

- Mount Pin
- USB-C Port
- MicroSD Port
- Up/Right Arrow
- Menu / Delete / Lock / Unlock
- Down / Left Arrow
- Camera Lens
- Ok / Select
- Camera / File Management / Go Back
- Lock File Button
- Power On / Off
- Display Screen
- Microphone
- Reset Button
- Camera Mount Suction Cup
- Camera Mount Locking Lever
- Camera Mounting Clip
- Power Cord USB-C Connector
- Power Cord 12V DC Connector



1. Insert the mount into the camera's mount port with the mounting clip nuts positioned on the right. Slide the mount to the right to fasten it. Check to make sure it is secure.
2. Choose where you want to place the camera on your windshield and wipe the area with a clean cloth.
Recommended: Choose a location near the rearview mirror that will provide a clear picture of the car interior without obstructing the driver's view.

- When the camera is powered on, press and hold the Camera Button for 2 seconds until it switches to the File Management screen. Here you can view your saved and locked videos.
- **Saved Videos:** Once you have reached the File Management screen, press the OK Button Twice and use the Up/Down Arrows to scroll through your saved videos.

File Management			
DIRECTORY	VIDEO	VIDEO_LOCK	PHOTO
FRONT	■ 20250108_172307_f.mk		 
	■ 20250108_172307_f.mk		 
	■ 20250108_172107_f.mk		 

- Saved Photos:** Once you have reached the File Management screen, press the OK Button then press the Down/Left Arrow twice to reach your saved photos. Press the OK Button again, then use the Up/Down Arrows to scroll through the photos.
- When you reach a photo or video you want to view, press the OK Button. When you are done viewing the photo or video, press the Camera Button to return to the File Management screen.
 - When you are finished viewing your videos, press the Camera Button until the camera returns to live recording mode.
- Note:** You can lock, unlock, or delete individual recordings by pressing the Menu Button on the left side of the camera as you scroll through your recordings.

- **Turn display on/off:** Press, but do not hold, the Power On/Off button when the camera is turned on. Note: The camera will continue actively filming even if the display is turned off.
- **Stop/Start recording:** Press the OK Button when the camera is turned on.
- **Take photos:** Press the Camera Button when the camera is turned on but NOT actively filming.
- **Access the menu:** Press the Menu Button.
- **Turn on/off Wi-Fi:** Press and hold the Up Button.
- **Turn on/off G-Sensor and Parking Monitoring:** You can turn these functions on/off in the camera menu. Note: To ensure the camera operates smoothly, Parking Monitoring should be switched off while driving and should only be turned on when the car is parked.
- **Lock a video while recording:** Press the Lock File Button once while the camera is actively filming to lock the current video. This means the video recording will remain locked until the loop recording restarts.
- **Download saved recordings:** Use the Monster Dash Cam app or download the saved recordings directly from the MicroSD card.
- **Add watermarks to the footage:** You can add license and time/date watermarks by going to the camera menu and navigating to 'License Stamp' and 'Time/Date Stamp'.
- **Erase the MicroSD:** It is important to erase or 'format' your MicroSD card every month to keep your camera running smoothly. This can be done in the camera menu or in the camera settings on the Monster Dash Cam app. Important: Make sure to save any important footage before erasing the MicroSD card so your files are not lost.

Scan this QR Code or follow the instructions below to download the free Monster Dash Cam smartphone app and connect to the camera's WiFi.

Use the HDMI app to complete setup.

MONSTER DASH CAM

SCAN TO INSTALL →

- Turn your camera on.
- Navigate to "WiFi" in the camera menu and press the OK Button to make sure the WiFi is toggled on. This will bring you to the WiFi Information Screen.
- Scan the QR Code on screen (or the QR Code above) to download the app, or search "Monster Dash Cam" in the App Store / Google Play.
- Open the app and press the "+" symbol at the top right of the screen. Follow the instructions to add a new camera and connect to the camera's WiFi.
- When connecting to WiFi, select the SSID that starts with "H1C4m" and when prompted, use the password 12345678.

Your device should now be connected.

What is Parking Monitoring?

Parking Monitoring automatically turns the camera on to record and lock video footage of sudden impacts when your car is parked. You can turn this function on/off in the camera menu.

What is G-Sensor?

G-Sensor automatically locks video footage of collisions and sudden impacts so it cannot be overwritten. You can turn this function on/off in the camera menu.

Note: If the G-Sensor is activated, you will receive a pop-up notification on the display screen, and the blinking red recording icon will turn temporarily yellow.

This camera is capable of recording time lapse content, but must be hardwired to the vehicle to do so. This requires a hardwiring kit with professional installation (not included).

Stick a needle or pin into the Reset button on the bottom of the camera (labeled RE). This will reset the camera so you can use it again.

Option 1: Stick a needle or pin into the Reset button on the bottom of the camera (labeled RE). This will reset the camera.

Option 2: Restore the camera to factory settings by navigating to 'Factory Reset' in the camera menu. This will restore the camera to default settings.

The camera keeps reverting to the default date and time.

Make sure the camera is connected to a power source and is fully charged before shutting it down to prevent this issue.

The camera shut off suddenly while filming

Turn off the Parking Monitoring function in the camera menu (turn it back on when your car is parked and you are no longer driving). Be sure you are not operating your camera at temperatures above 70°C / 158°F.

Make sure the WiFi on both your camera and smartphone is turned on, and that you allow all permissions when prompted. Keep your smartphone close to the camera (within several feet).

If this doesn't solve the problem, forget the camera's WiFi network on your smartphone and then reconnect to the camera's WiFi. You can also try restarting your phone and the camera.

If you continue to encounter the issue, contact the manufacturer.

Extend Your Warranty
Scan QR code on the front cover of this manual to extend your product warranty to 2 years.

866-246-2008

customerservice@monsterilluminescence.com

In the event this product becomes defective, please do not return this product to your retailer.

[illegible]

service of packaged or installed the product, the Amn Associates instrument that may be only authorized service personnel for the maintenance or repair. Unauthorized use of the Product or software can impact the Product's performance and may invalidate this Limited Warranty.

2. DISCLAIMER OF WARRANTIES: Except as stated above in this limited warranty, and to the maximum extent permitted by applicable law, Amn Associates disclaims, denies, implies, and/or clarifies any and all warranties, express or implied, including but not limited to the implied warranties of merchantability and fitness for a particular purpose. To the maximum extent permitted by applicable law, Amn Associates also limits the duration of any applicable implied warranties or conditions to the duration of this limited warranty.

3. LIMITATION OF DAMAGES: In addition to the above warranty disclaimer, in no event will Amn Associates be liable for any consequential, incidental, exemplary, or special damages, including any damages for lost data or lost profits, arising from or relating to this limited warranty or the product. The sole and exclusive remedy for any claim or damage arising out of this limited warranty or the product will not exceed the amount actually paid for the product by the original purchaser.

4. LIMITATION OF REMEDY: The Amn Associates online service at www.amnassociates.com/usa ("Services") may provide information ("Product Information") regarding your Amn Associates products or other peripherals connected to your products ("Product Peripherals"). The type of product peripherals that may be connected to your product may change from time to time. Without limiting the generality of the foregoing, should all of your Product Peripherals be your own equipment, "it is your responsibility," Amn Associates does not warrant, represent, or guarantee that product information will be available, accurate, or reliable or that product information or use of the service or product will be useful solely in your time. You use all product information, the services, and the product at your own discretion and risk. You will be solely responsible for (and Amn Associates disclaims) any and all loss, liability, or damages, including by your wiring, fires, electricity, loss, product, product peripherals, computer, mobile device, and all other items and profits you sustain, resulting from your use of the services or product. Amn Associates disclaims any and all liability for any such loss, liability, or damages as a substitute for the direct means of obtaining the information. For example, a notification provided through the service does not intend and is a substitute for audible and make calls into the home and on the product, may be a third party monitoring service that monitors alarm data.

5. YOUR RIGHT AND THE LIMITED WARRANTY: This Limited Warranty gives you specific legal rights. You may also have other legal rights that vary by state, province, or jurisdiction. Likewise, some of the terms in this Limited Warranty may not apply in certain states, provinces or jurisdictions. The terms of this Limited Warranty may vary to reflect compliance by applicable law. For a full description of your legal rights you should refer to the laws applicable to your jurisdiction and you may wish to contact a relevant competent advisory service.

If you wish to start a warranty claim, you may forward your claim, or please mail us Customer Support by emailing customerservice@amnassociates.com or calling our support number 1-800-746-2800.

Please allow 10-15 business days to process warranty claims. Customers located outside of the U.S. will be responsible for all shipping costs.

Changes in media use must be regularly reported by the party responsible for compliance and used by the state authority to optimize this device.

The device complies with part 21 of the EEC Directive. Operation is subject to the following two conditions: (1) This device may cause harmful interference, and (2) this device must accept any interference that it may receive, including interference from radio communications stations.

The equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the EEC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. The equipment generates, uses, and can radiate radio frequency energy and, if not installed and used according to the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If interference does occur, you may wish to take one of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

The equipment complies with FCC radiation exposure limits in both for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

The illustrated products and specifications may differ slightly from those supplied.
The M Moniker logo is a registered trademark of Mondelēz, Inc., and its subsidiaries in the U.S. and other countries and are used under license. Google, Android, Android Logo and Google Play are trademarks of Google LLC. Apple, Apple Logo™ and the Apple logo are trademarks of Apple Inc., registered in the U.S. and other countries. M refers to said parties are not subsidiaries of their respective owners, Nestlé Jern A/S, Aarhus, Denmark, and Mondelēz Inc., is affiliated with the respective owners of their trademarks.
Designed and Manufactured by Jern A/S Aarhus, Denmark. M 000017