

PANOX


AnyVue 360° Camera



AnyVue 360° Camera Package List:



Camera Overview:



| NO. | Component | NO. | Component |
|-----|------------------------|-----|------------------------------|
| 1 | Heat dissipation holes | 6 | Speaker |
| 2 | LED indicator | 7 | 3.1-inch HD touchscreen |
| 3 | Power button | 8 | TYPE-C interface |
| 4 | Lens*2 | 9 | TF card slot |
| 5 | Microphone*2 | 10 | Standard 1/4" mounting point |

Before You Start:

- 1. When using the camera for the first time, keep it fully charged.
- 2. Please use the included charging cable to connect the camera's Type-C port for charging.



3. Insert Memory Card

Notes:

- · Please use an exFAT formatted TF card that meets the U3/A2 specifications. Using a low-speed memory card may result in abnormal video recording. When using a memory card for the first time in this camera, please format it in-camera to ensure stable performance.
- \cdot Do not block the intake and exhaust vents to prevent any interference with the camera's heat dissipation during use.

Quick Guide:

Power On/Power Off



Power On: Press and hold the power button for 3 seconds.

Screen on/off: Press the power button briefly to turn the camera screen on/off.

Power Off: Press and hold the power button for 3 seconds to shut down the camera.

APP Download(Bluetooth/WiFi):

Scan the QR code below or search "PANOX" in the App store to download the companion app.

After installing PANOX, there are two ways to connect the camera with PANOX:

- 1. Both the camera and the smartphone are on the same WiFi network. Open the app and search for the camera.
- 2. The camera creates a hotspot, and the smartphone connects to that hotspot.

Note:

The WiFi connection range is up to 10 meters (under no interference conditions).

Specifications:

| Sony 1/2"*2 | |
|---|--|
| 200°/F2.0 Fisheye*2 | |
| 3.1 inch | |
| 12K(11968*5984) | |
| 8K(7680*3840)10fps | |
| 5.7K(5760*2880)30fps | |
| 9-axis | |
| Max 7W | |
| 1500mAh Lithium Polymer Battery | |
| WiFi: 802.11b/g/n, dual-band 2.4G | |
| BT: GFSK, PI/4 DQPSK, 8DPSK, 2402-2480MHz | |
| RGB LED | |
| Temperature: 0~40© (32~104°F) | |
| Humidity: -20~60② (-4~140°F) | |
| Main Body: 134.3 x 50 x 20mm | |
| With Lens: 134.3 x 50 x 33.75mm | |
| PD18W | |
| 200g | |
| | |

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

RF warning for Portable device: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.