

12	11	10	9	8	7	6	5	4	3	2	1
H											H
G											G
F											F
E											E
D											D
C											C
B											B
A											A
12	11	10	9	8	7	6	5	4	3	2	1

Cover

▼

This

Model: GD2

Quick Reference Guide

Please read the user manual before operating the TV box

Accessory List

Please open the package and check the following accessories:

TV Box x1

Remote Control x1

User Manual x1

Power Adapter x1

HDMI Cable x1

Hardware Structure

• Front Panel

Led Indicators

• Left Side Panel

USB1

USB2

Reset

• Back Panel

DC IN

AV

HDMI output

Ethernet

Optical

12V 1A

AV

HDMI

CF

12V 1A

AV

Remote Control

Standby On/Off

Profile

Enter

Back

Volume Up

Volume Down

YouTube

Prime Video

Input

Google Assistant Dashboard

Direction Keys

Live Guide*

Home

Channel Up

Channel Down

Mute

Netflix

Disney+

Instructions

• Indicator Light: Pressed any keys and indicator light flashes and the indicator will flashes quickly when the voltage is low.

• Bluetooth Pairing: Pressed the "HOME+BACK" keys together on your Remote Control for 10 seconds.

• Google Assistant: Press the Google Assistant button and use your voice to search what's on now, change channels, control your TV, open apps, and more.

• Live Guide*: US Only. Live TV is just a click away, with its own dedicated tab. Live entertainment is also mixed into your recommendations, based on your favorite teams, shows, and channels.

System Connection

Please refer to below instructions to connect TV, Power, Network and other devices.

Note: Please turn off all equipment before connecting.

Power Input

TV

12V 1A

AV

HDMI

CF

B/P DIF

Internet Connection

Amplifier

Step1: Connection with TV

Connect HDMI cable to HDMI port of the TV box and TV set.

Step2: Connection with network

The TV box supports both Ethernet and Wi-Fi connections.

• Ethernet: Use the Ethernet cable to connect the LAN port of the TV box and the port of the home broadband network.

• Wi-Fi: Select your Wi-Fi network & key in the password.(After the machine is powered on, press "Dashboard" button --> go to "All settings" --> "Network & Internet")

Step3: Connection with Power

Connect the power adapter to the TV box. After power is on, it can start automatically.

Step4: Set up your device

Follow the on-screen to set up your device.

Troubleshooting

• No display after power on?
Confirm your device connected to the TV well and set the correct HDMI Input from your TV configuration.

• TV has images but no sound?
Make sure your TV is not in mute and low volume.

• Fail to connect to network?
Make sure the Ethernet cable is properly connected. Make sure Wi-Fi is functional and your box has a strong enough signal from your router.

• Remote Control Failure?
Replace the battery of the remote control with a new one, and make sure it is placed in the correct polarity.
Make sure the remote control is within the range of the TV box.
Go to the Setting menu to unpair and re-pair the remote control.
While the device is powered on, using a pin to push down "RESET" for 3 seconds, follow the instructions on the screen to re-pair the remote control.

• Restore factory settings?
To restore factory settings, disconnect the power. While holding down the RESET button with a pin, plug in the power cord. Keep holding the button for 6 seconds after power up to complete the factory reset.

• Please use our accessories to avoid any risk.

Safety Instructions

WARNING!

• Presence of live parts inside the device! Do not open. Risk of electric shock!

• No parts should be repaired by users.

• Place the device on a flat, firm and stable surface. Do not put it on a carpet or rug.

• Place the device in a well-ventilated location to prevent the accumulation of internal heat.

• Protect the device from high temperatures, humidity, water and dust.

• Do not place any objects near your device that may damage it (e.g. liquid-filled objects or candles).

• Do not mix old and new batteries and Do not mix alkaline, standard (carbon-zinc) or rechargeable (ni-cd, ni-mh, etc.) batteries.

• Operating Temperature: 0℃~40℃.

Compliance

Dolby AUDIO

Google TV is the name of this device's software experience and a trademark of Google LLC. Google and YouTube are trademarks of Google LLC.

Manufactured under license from Dolby Laboratories. Dolby, Dolby Audio and the double-D symbol are trademarks of Dolby Laboratories Licensing Corporation.

Netflix is a trademark of Netflix, Inc.

All brands contained herein are trademarks of their respective owners.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, use and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.
To assure continued compliance, any changes or modifications not expressly approved by the party.
Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).
This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:
The equipment complies with FCC Radiation exposure limits set forth for uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

折页方式

技术要求:

1) 尺寸公差±2mm

2) 颜色△E<2

3) 环保要求RoHS、Reach

4) 印刷后封面机器图勿出现白点

折叠方式示意图

										2024-06-19										
										DATE 日期										
DESCRIPTION 备注说明										DATE 日期										
历史修订版本记录																				
资料名称: Manual										单位: mm										
物料编号: -					工艺描述汇总: 说明书, 100x140mm, 80g书写纸, 折页															
设计:																				
校对:																				
审核:																				
会签:						Size		Scale		Rev										
批准:						A1		1:1												