

# MONSTER SMART ILLUMINENESS

## SMART RGB+IC LED FLOW LIGHT STRIP

### QUICK START GUIDE

MER7-1065-RGB - V1.0 0122

## GETTING STARTED

Thank you for choosing the Smart RGB+IC LED Flow Light Strip by Monster Smart Illumineness. This Quick Start Guide will help you with setup and installation of your device.

### WHAT'S IN THE BOX

- 6ft/2m Smart RGB+IC LED Flow Light Strip with attached controller and preinstalled mounting adhesive
- Mounting Clips + Screws (optional use)
- Quick Start Guide

### WHAT DO YOU NEED?

- Cellphone or tablet with Android™ 6.0 Marshmallow or higher / iOS 10 or higher
- Wi-Fi router with an internet connection
- Wi-Fi 2.4GHz 802.11n
- Rubbing alcohol to clean the installation surface

Before setup, make sure your phone or tablet is connected to the 2.4GHz Wi-Fi network that your LED Strip will be placed on. For easier pairing, turn on Location and Bluetooth to quickly find nearby devices.

**TIP:** Do you know your Wi-Fi network name and password? Write it down now if it's hard to remember.

### ANYTHING ELSE?

Your LED Light Strip comes with preinstalled mounting adhesive, but you could use the included mounting clips and screws if you would like a more permanent installation. You will need a Phillips head screwdriver to install with the clips.

**TIP:** Save these instructions for future reference.

## SETUP

### COMPLETE SETUP BEFORE INSTALLATION

Remove your LED Strip and all components from the box. It is recommended to first pair your device in a location close to your router BEFORE installation.

**NOTE:** If desired, you can operate the device with the controller and without pairing to Wi-Fi and without the app. Advanced features like color customization, scheduling, and voice control will not be available. (See "How To Use" on page 5.)

### STEP 1

Download the **MONSTER SMART** app from the App Store (for iPhone) or Google Play Store (for Android phones).

[Download on the App Store](#)   [Get it on Google Play](#)

### STEP 2

Make sure your phone or tablet is successfully connected to the 2.4GHz Wi-Fi network that your device will be placed on and ensure that your Bluetooth is enabled.

Open the **MONSTER SMART** app and create an account by following the on-screen instructions.

**NOTE:** Most Smart devices only work on a 2.4GHz Wi-Fi network. Many newer home Wi-Fi networks are mixed networks that are set to 5GHz by default (ex: AT&T, Verizon) and you may need to use AP pairing mode to connect. If you still have difficulty, contact your Internet Service Provider for assistance with 2.4GHz network setup.

### STEP 3

Connect the USB plug to a powered 5V 2A USB wall adapter (not included) and the light should turn on. If needed press the multifunction button twice to turn on the light.

Press and hold the multifunction button for 5-6 seconds to enter pairing mode. The light will begin blinking when it has entered pairing mode and is ready to pair.

## STEP 4

Confirm that the device is in pairing mode. LED is RAPIDLY blinking. In the **MONSTER SMART** app, select the "+" in the upper right corner of the home screen to add a new device.

The app will detect the nearby Wi-Fi+BLE enabled device and ask if you would like to add it, click "Go to add". Ensure that the device is checked and then click the "+" button.

### STEP 5

Confirm that the network displayed is your 2.4GHz Wi-Fi network, then enter your Wi-Fi password and click "Confirm".

**TIP:** For best mounting results, place adhesive onto the desired surface with ONE attempt. Reapplying multiple times will not guarantee secure mounting onto the surface.

### OPTIONAL

Using the included mounting clips and screws, and a Phillips head screwdriver (not included), install the mounting clips over the LED Strip in equal intervals.

**TIP:** If desired, you can cut the light strip to shorter lengths by cutting on the designated scissors marks. Note: You cannot connect additional light strips to this product.

## INSTALLATION

### STEP 1

Determine where you will install the LED Strip. Make sure the location is close enough to a power source. Ensure that the mounting surface is smooth and clean.

Clean the mounting surface with a clean cloth and rubbing alcohol to remove any dust or oils that will weaken the adhesive. Be sure to let this surface dry before installation.

**NOTE:** This adhesive is not recommended for use on unsealed brick, raw wood, uneven/tumpled surfaces, or wallpaper.

### STEP 2

Peel off the beginning of the adhesive backing and firmly stick the LED Strip onto the surface. Peel off more of the adhesive backing as you mount the LED Strip, pressing on each section of the strip for 10 seconds as you place it.

### STEP 3

Once complete, your device will be connected to the network. Confirm or change the settings for your device and then click "Done". Your device is now setup and ready to use!

**STEP 3**

Connect the USB plug to a powered 5V 2A USB wall adapter (not included). The LED Strip will automatically reconnect to the paired Wi-Fi network and will now be ready to use.

## HOW TO USE

### BUTTON CONTROL

**POWER:** double click - click twice quickly to power on or off your device.

**SCENES:** click - change between preset scenes in Static, Dynamic, Music, and DIY (for access to the custom edits of those scenes, requires Wi-Fi pairing and app).

**RESET:** press and hold - reset the device and to pair to your Wi-Fi network. (Microphone opening)

### APP CONTROL: SCENES

Open the **MONSTER SMART** app and click on your device from the list of available paired devices.

**Device Info/Settings**

**EDIT SCENES**

**WHITE:** Multiwhite selector wheel and buttons with brightness adjust

**COLOR:** Multicolor selector wheel and buttons with brightness adjust

**STATIC:** Customizable static color scenes with color selectors and brightness adjust. Each Static scene has its own unique pattern.

**DYNAMIC:** Flowing multicolor scenes with brightness/speed adjust

**MUSIC:** Sound reactive multicolor scenes with mic sensitivity adjust

**DYI:** Customizable flowing multicolor scenes with color selectors, brightness and speed adjust. Each DIY scene has its own unique flowing pattern. Create and save your favorites!

**GROUPING DEVICES**

Your LED Strip is great to use in multiples, you can control each separately or easily group multiple lights together in the app to control them all as one. Click on the settings button in the upper right corner and then click "Create Group" to group your devices.

**NOTE:** Grouping different Monster Smart Illumineness devices with different features may cause communication issues when selecting Scenes. For best results create groups of the same products. If you would like to group together different items, it is recommended to control using the Color settings only, rather than Scenes.

## EDIT SCENES

**RESET:** reset to the default scene settings

**PICTURE:** edit your scene thumbnail

**NAME:** edit your scene name

**COLORS:** add or edit colors and arrange and adjust them as you wish

**SATURATION:** adjust the color saturation

**BRIGHTNESS:** adjust the brightness of the scene

**SPEED:** adjust the color transition speed


## TROUBLESHOOTING

### HAVING TROUBLE WITH SETUP?

**Don't return this product to the retailer; we're here to help.**  
Please call/write us for customer support: 866-246-2008  
[customerservice@monsterilluminessence.com](mailto:customerservice@monsterilluminessence.com)

Q: Why is my device failing to connect to my Wi-Fi network?

- A1: Make sure your phone or tablet is successfully connected to the 2.4GHz Wi-Fi network that your device will be placed on.  
A2: Make sure you enable Bluetooth and allow location services on your phone or tablet to find nearby devices.  
A3: If your Wi-Fi network is a mixed 2.4GHz/5GHz network, try using AP pairing mode for better results.



1. Press and hold the pairing button until the LED is **slowly** blinking.  
2. In the app, select the "+" in the upper right corner of the home screen to add a new device and then select "Lighting (Wi-Fi)".  
3. Click "Not Pairing" in the upper left to switch to AP mode.  
4. Confirm that the LED indicator is **slowly** blinking, confirm the network is your mixed Wi-Fi network, enter your Wi-Fi password, and click "Confirm".  
5. Follow on-screen instructions to set up your device via wireless access point.

A4: If you still have issues with your mixed network, you may need to access your router settings and/or call your Internet Service Provider to create a separate 2.4GHz network.

Q: Can I cut the LED Light Strip?

A1: Yes, if desired, you can cut the light strip to shorter lengths by cutting on the designated scissors marks. However, once cut, the strip will no longer be water resistant or covered under warranty.

Q: Why is the adhesive tape not holding?

- A1: In order to properly install this product, the mounting surface must first be cleaned with rubbing alcohol and allowed to air dry.  
A2: This adhesive is not recommended for use on unpainted brick, raw wood, uneven/bumpy surfaces, or wallpaper.  
A3: Mounting this product in excessively hot or humid environments may weaken the adhesive.

For other frequently asked questions please visit our website at [www.monsterilluminessence.com](http://www.monsterilluminessence.com)

## VOICE CONTROL OPTIONAL



### AMAZON VOICE CONTROL SETUP

Make sure your Amazon Alexa device is installed and setup.

- STEP 1: Open the Alexa app and go to Skills in the menu.  
STEP 2: Search for and choose **MONSTER SMART**.  
STEP 3: Enable the Skill and authorize your account using your login information.

NOTE: Use the same login information that you used to create your Monster Smart account.



At any time, go to the Alexa app to set nicknames and rooms for your devices. You can also rename devices in the Monster Smart app.

Using the name LED Flow, or the name you assigned your device, you can ask Alexa to control your device, just say "Alexa" and ask: "Turn on my LED Flow", "Set my LED Flow to blue", "Set my LED Flow to 50% brightness", and more!




### GOOGLE VOICE CONTROL SETUP

Make sure your Google Assistant device is installed and setup.

- STEP 1: Open the Google Home app, go to the Home menu, and tap the "+" button.  
STEP 2: Click "Set up devic".  
STEP 3: Click "Have something already set up?"  
STEP 4: Search for and choose **MONSTER SMART** and authorize your account using your login information.

NOTE: Use the same login information that you used to create your Monster Smart account.



At any time, go to the Google Home app to set nicknames and rooms for your devices. You can also rename devices in the Monster Smart app.

Using the name LED Flow, or the name you assigned your device, you can ask your Google Assistant to control your device, just say "Hey Google" and say: "Turn on my LED Flow", "Set my LED Flow to blue", "Set my LED Flow to 50% brightness", and more!



### SIRI VOICE CONTROL SETUP

Requires iPhone running iOS 12 or later.

- STEP 1: Open the **MONSTER SMART** app and go to the "Smart" menu, tap the "+" button to create a new Tap To Run Smart Scene.  
STEP 2: Tap "Launch Tap To Run" and fill out the Information.  
STEP 3: Once your Smart Scene is created and saved, click the button that appears at the bottom of the screen that says "Add to Siri" to open the list of options.

STEP 4: Select your new Tap To Run Smart Scene from the list and click "Add to Siri".

STEP 5: Create a custom phrase to say to Siri to run your Smart Scene (this can be any verbal command).



Now Siri can use your voice and custom verbal command to turn your LED Flow on or off, activate your favorite lighting pattern, adjust the device at the same time as your other smart devices, or whatever you've set up as your Tap To Run Smart Scene.

## NOTES

### WARRANTY

**1 Year Limited Warranty** - Please read and understand all instructions before using this product. If damage is caused by failure to follow the instructions, this warranty is null and void.

- STEP 1: Open the **MONSTER SMART** app and go to the "Smart" menu, tap the "+" button to create a new Tap To Run Smart Scene.

STEP 2: Tap "Launch Tap To Run" and fill out the Information.

STEP 3: Once your Smart Scene is created and saved, click the button that appears at the bottom of the screen that says "Add to Siri" to open the list of options.

STEP 4: Select your new Tap To Run Smart Scene from the list and click "Add to Siri".

STEP 5: Create a custom phrase to say to Siri to run your Smart Scene (this can be any verbal command).

STEP 6: Do not expose this product to open flames or use near fire.

STEP 7: Do not use this product in a strong magnetic field.

STEP 8: Do not use this product for emergency lighting/exits.

STEP 9: Do not allow small children to operate, modify, or install this device unsupervised.

STEP 10: Use a clean, soft cloth to clean – do not use any corrosive cleaners/oils to clean.

STEP 11: The external flexible cable or cord of this luminaire cannot be replaced; if the cord is damaged, the luminaire shall be destroyed.

STEP 12: The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person.

STEP 13: Provide safety in your home. Recycle all product information, the services, and the products of your new device and old.

STEP 14: You will be solely responsible for card less purchases (any card less than \$1000) and all less liability, or damages, including parts in your home resulting from your use of the product information, services, or products. Product information provided by the services is not intended as a substitute for direct means of obtaining the information. For example, a notification provided through the service is not intended as a substitute for visible and audible indications in the home and/or the product, nor as a third party monitoring service that monitors your state.

STEP 15: **YOUR RIGHTS AND THIS LIMITED WARRANTY** This Limited Warranty gives you specific legal rights. You may also have other legal rights that vary by state, province, or jurisdiction. Some of the limitations in this Limited Warranty may not apply in certain states, provinces, or jurisdictions. The terms of this Limited Warranty will apply in the extent permitted by applicable law. For a full description of your legal rights you should refer to the laws applicable in your jurisdiction and you may wish to contact a relevant consumer advice service.

If you need to start a warranty claim for your Monster Smart device, please email to [CustomerSupport@monsterilluminessence.com](mailto:CustomerSupport@monsterilluminessence.com) or call our support number 866-246-2008.

Please allow 7-10 business days to process warranty claims. Customers located outside of US, will be responsible for all shipping costs.

**2.000 SATISFACTION RETURN POLICY** If you are the original purchaser of the Product and you are not

## FCC Compliance

This device complies with Part 15 of the FCC. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference, including interference that may cause undesired operation.

The equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

— Increase the separation between the equipment and receiver.

— Connect the equipment into a circuit different from that to which the receiver is connected.

— Consult the dealer or an experienced radio/TV technician for help.

**RF Exposure Statement**

To satisfy FCC RF exposure requirements, a separation distance of 20cm or more should be maintained between the antenna of this device and persons during device operation. To ensure compliance, operations at closer than this distance is not recommended.

**ISED/CNR WARNING**

This device complies with Innovation, Science, and Economic Development Canada license-exempt RSS standard(s).

Operation is subject to the following two conditions:

(1) This device may not cause interference, and

(2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

(1) L'appareil ne doit pas causer d'interférence et

(2) L'appareil doit accepter toute interférence susceptible d'être générée par d'autres appareils.

The device is compliant with IC exposure guidelines, when used in accordance with IC-Antennas.com's 20cm.

Le présent appareil est conforme aux normes de sécurité et de performance de la Commission canadienne des télécommunications pour les appareils sans fil utilisés dans les résidences. La distance minimum entre l'appareil et l'utilisateur est de 20 cm.

**1 YEAR LIMITED WARRANTY**

Jew Accessories, Inc. Limited Warranty Policy for Monster Smart Products last updated: March 27, 2020

This limited warranty contains important information about your rights and obligations, as well as limitations and restrictions that may apply to you.

**1. WHAT THIS LIMITED WARRANTY COVERS** Period of Coverage: Jew Accessories, Inc. ("Jew Accessories") will be liable for defects in material and workmanship for a period of one year.

Networked lighting: The lighting, the Warranty Period for a bulb is reflected in Product Use (1 year), even if installed by a professional. If the Product fails to conform to this Limited Warranty during the Warranty Period, Jew Accessories will, at its sole discretion, either (a) replace or repair any defective Product or component; with parts of purchasing using original documentation. Repair or replacement may be made with a new or refurbished product or components, at the manufacturer's sole discretion. If the Product or a component is repaired or replaced, it is covered by the original warranty period.

Using the name LED Flow, or the name you assigned your device, you can ask Alexa to control your device, just say "Alexa" and ask:

"Turn on my LED Flow", "Set my LED Flow to blue", "Set my LED Flow to 50% brightness", and more!

The luminaire controls and specifications may differ slightly from those supplied.

TheMonster logo and Luminessence are trademarks or registered trademarks of Monster Inc., or its subsidiaries, in the U.S. and other countries, and are used under license. Apple and the Apple logo are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc. Google, Android and Google Play are trademarks of Google LLC. Siri is a trademark of Apple Inc. Amazon, Alexa, and all related marks are trademarks of Amazon.com, Inc. or its affiliates. All other brand names are trademarks of their respective owners. Neither Jew Accessories, Inc. nor Monster Inc. is affiliated with the respective owners of their trademarks.

2.000 SATISFACTION RETURN POLICY

If you are the original purchaser of the Product and you are not

## NOTES

### WARRANTY

**1 Year Limited Warranty** - Please read and understand all instructions before using this product. If damage is caused by failure to follow the instructions, this warranty is null and void.

The equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

— Increase the separation between the equipment and receiver.

— Connect the equipment into a circuit different from that to which the receiver is connected.

— Consult the dealer or an experienced radio/TV technician for help.

**RF Exposure Statement**

To satisfy FCC RF exposure requirements, a separation distance of 20cm or more should be maintained between the antenna of this device and persons during device operation. To ensure compliance, operations at closer than this distance is not recommended.

**ISED/CNR WARNING**

This device complies with Innovation, Science, and Economic Development Canada license-exempt RSS standard(s).

Operation is subject to the following two conditions:

(1) This device may not cause interference, and

(2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

(1) L'appareil ne doit pas causer d'interférence et

(2) L'appareil doit accepter toute interférence susceptible d'être générée par d'autres appareils.

The device is compliant with IC exposure guidelines, when used in accordance with IC-Antennas.com's 20cm.

Le présent appareil est conforme aux normes de sécurité et de performance de la Commission canadienne des télécommunications pour les appareils sans fil utilisés dans les résidences. La distance minimum entre l'appareil et l'utilisateur est de 20 cm.

**1 YEAR LIMITED WARRANTY**

Jew Accessories, Inc. Limited Warranty Policy for Monster Smart Products last updated: March 27, 2020

This limited warranty contains important information about your rights and obligations, as well as limitations and restrictions that may apply to you.

**1. WHAT THIS LIMITED WARRANTY COVERS** Period of Coverage: Jew Accessories, Inc. ("Jew Accessories") will be liable for defects in material and workmanship for a period of one year.

Networked lighting: The lighting, the Warranty Period for a bulb is reflected in Product Use (1 year), even if installed by a professional. If the Product fails to conform to this Limited Warranty during the Warranty Period, Jew Accessories will, at its sole discretion, either (a) replace or repair any defective Product or component; with parts of purchasing using original documentation. Repair or replacement may be made with a new or refurbished product or components, at the manufacturer's sole discretion. If the Product or a component is repaired or replaced, it is covered by the original warranty period.

The luminaire controls and specifications may differ slightly from those supplied.

TheMonster logo and Luminessence are trademarks or registered trademarks of Monster Inc., or its subsidiaries, in the U.S. and other countries, and are used under license. Apple and the Apple logo are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc. Google, Android and Google Play are trademarks of Google LLC. Siri is a trademark of Apple Inc. Amazon, Alexa, and all related marks are trademarks of Amazon.com, Inc. or its affiliates. All other brand names are trademarks of their respective owners.

2.000 SATISFACTION RETURN POLICY

If you are the original purchaser of the Product and you are not