





D7 55" Open Box Guide

DTEN.COM SALES@DTEN.COM SUPPORT@DTEN.COM


STEP 1 Take out the AV bar . ①




STEP 2 Take out the side foam strips. ②
Take out the accessory bag. ③



STEP 3 Pull out the display protection bag, along with the display. ④



STEP 4 Take out the wall mount box located at the bottom. ⑤



Model: DB71455