

尺寸: 80X100mm 骑马钉 20P 双铜纸 双面印刷

GRIHIN
Model: KM01

Karaoke Machine

User Manual

Contents

English User Manual	01
Manual del usuario	08
简体中文	13

Item list

01

Speaker icon introduction

02

Speaker button function introduction and prompt tone

	Operation method	Functional description	Voice Prompt
power on/off	Gently pull	power on/off	Power On
function key	short press	Switch: Bluetooth/TF card/AUX	Bluetooth Mode
	long press	Turn on/off vocal cancellation	Enable voice cancellation
volume+	short press	volume up	-
	long press	next track ("Audio input mode" invalid)	-
volume-	short press	volume down	-
	long press	previous piece ("Audio input mode" invalid)	-
play/pause	short press	Pause/playback	-
	long press	Lighting mode switching (long light/breathing/horse racing/music beat/rhythm move)	-
light mode key	short press	Color Variation Within Mode	-
	double click	turn on/off lights	-
Bluetooth		Bluetooth Connected	Bluetooth Connected
		Bluetooth Disconnected	Bluetooth Disconnected

03

Microphone icon introduction

04

Microphone button function introduction and prompt tone

	Operation method	Functional description	Voice Prompt
power on/off	long press	power on/off	-
	short press	Play/Pause (audio music)	-
microphone function key	short press	Switch: original sound, magic sound (Minions, Snow, baby sound, magic barrier sound)	Original sound, Ducker mode, Duck mode, Magic sound
	long press	Turn on/off vocal cancellation	Enable voice cancellation
	Double click	Turn on/off the light of MIC	-
volume+	short press	volume up	Maximum: Beep
volume-	short press	volume down	Minimum: Beep

05

Bluetooth connection

After the speaker is turned on, turn on the Bluetooth switch function of the Bluetooth device, search for "KM01", and click to connect

IC Caution

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- This device may not cause interference.
- This device must accept any interference, including interference that may cause undesired operation of the device.

06

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- l'appareil ne doit pas produire de brouillage, et
- l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si ce brouillage est susceptible d'en compromettre le fonctionnement.

07

ES

Lista de artículos

08

Introducción al icono del altavoz

09

Introducción de la función del botón del altavoz y tono de aviso

	Método de operación	Descripción funcional	Consejos de voz
Encendido/ apagado	tire suavemente	Encendido/apagado	Power On/ Bluetooth Connected
tecla de función	presa corta	Interruptor: Bluetooth/ tarjeta TF/AUX	Bluetooth Mode
	pulsación larga	Activar/desactivar la cancelación vocal	Enable voice cancellation/ Disable voice cancellation
volumen+	presa corta	sube el volumen	-
	pulsación larga	siguiente pista ("modo de entrada de Audio" no válido)	-
volumen-	presa corta	bajar volumen	-
	pulsación larga	pieza anterior ("modo de entrada de Audio" no válido)	-
reproducir/ pausar	presa corta	Pausa/reproducción	-
	pulsación larga	Cambio de modo de iluminación (luz larga/ res gracén/carreras de caballos/ritmo musical/ movimiento rítmico)	-
tecla de modo de luz	presa corta	Variación de color dentro del modo	-
	haga doble clic	encender/apagar luces	-
Bluetooth		Conexión Bluetooth	Bluetooth Connected
		Bluetooth está desconectado	Bluetooth Disconnected

10

Introducción al icono del micrófono

11

Introducción de la función del botón del micrófono y tono de aviso

	Método de operación	Descripción funcional	Consejos de voz
Encendido/ apagado	pulsación	Encendido/apagado	-
	presa corta	Reproducir/Pausar (música de audio)	-
tecla de función del micrófono	pulsación	Interruptor: sonido original, sonido más (original sound, Ducker mode, Duck mode, Magic sound)	Original sound, Ducker mode, Duck mode, Magic sound
	presa corta	Activar/desactivar la cancelación vocal	Enable voice cancellation/ Disable voice cancellation
	Double click	Encender/apagar la luz de MIC	-
volumen+	presa corta	sube el volumen	Maximum: Beep
volumen-	presa corta	bajar volumen	Minimum: Beep

12

Conexión Bluetooth

Después de encender el altavoz, active la función de interruptor de Bluetooth del dispositivo Bluetooth, busque "KM01" y haga clic para conectarse

CN

物品清单

13

功能介绍

14

音箱按钮的功能介绍和提示音

	操作方法	功能说明	语音提示
开/关机	短按	电源开/关	Power On/ Bluetooth Connected
功能键	短按	切换: 蓝牙/TF卡/AUX	Bluetooth Mode
	长按	开关消人声	Enable voice cancellation/ Disable voice cancellation
音量+	短按	音量加	-
	长按	下一曲 ("TF卡模式"无效)	-
音量-	短按	音量减	-
	长按	上一曲 ("TF卡模式"无效)	-
暂停/播放	短按	暂停/播放	-
	长按	灯光模式切换	-
照明模式	短按	模式内色彩变化	-
	双击	开/关灯	-
蓝牙		蓝牙连接成功	Bluetooth Connected
		蓝牙断开	Bluetooth Disconnected

15

麦克风图标的介绍

16

麦克风按钮的功能介绍和提示

	操作方法	功能说明	语音提示
电源开关/关	长按	开/关	-
	短按	播放/暂停	-
模式切换	短按	原声/魔音声效切换	Original sound, Ducker mode on, Ducker mode off, Magic sound
	长按	开/关消人声	Enable voice cancellation/ Disable voice cancellation
	双击	开/关话筒灯光	-
音量+	短按	话筒音量加	Maximum: Beep
音量-	短按	话筒音量减	Minimum: Beep

17

蓝牙连接

当你打开音箱时，蓝牙设备的蓝牙开关机打开功能，搜索 "KM01"，点击连接。

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.