Dual mode wireless keyboard (2.4G & Bluetooth)

User Manual



Compatible System

iOS / Android / Windows / Mac OS

1 v LISB Reneiver

Specifications

Weight: 197.3g Madrian distance: 10m

Stand-by time: 560 hours Sleen time: Ten minuter

Lithium battery capacity: 140mAh Awaken way : Arbitrarily key to awaken

Indicator Lights Descrip



(j) Power Indicator: Displays blue when turned or; stay in red when charging; flash red quickly when low power.

② Bluetooth indicator: Displays blue and then goes out when switching channels:

(i) Caps lock indicator: Displays blue when caps is locked

Keys and Functions

Function Keys	ios	Android	Windows 10	Mac OS	Windows Mac OS
Way to use	Press fn +	Press fn +	Press fn +	Press fn +	Press fin+ shift+
-	Home	Home or N/A	Web Browser	Home	esc
	Brightness -	Brightness -	Brightness -	Brightness -	F1
::	Brightness +	Brightness +	Brightness +	Brightness +	F2
	Search	Search or N/A	Search	Search	F3
	Previous Track	Previous Track	Previous Track	Previous Track	F4
·	Play/Pause	Play/Pause	Play/Pause	Play/Pause	FS
	Next Track	Next Track	Next Track	Next Track	F6
	Mute	Muse	Mute	Muse	F7
11	Volume -	Volume -	Volume -	Volume -	F8
	Volume +	Volume +	Volume +	Volume +	F9
	Battery Checking	Battery Checking	Battery Checking	Battery Checking	F10
==	Print Screen	Print Screen or N/A	Print Screen	Print Screen	F11
	Lock Scren	Lock Scren or N/A	Lock Scren	N/A	F12
"	Delete	Delete	Delete	Delete	N/A

. When switching the operating system, please remember to press the corresponding button (fin + Q/W/E/R) to switch, so as not to affect normal use.
 If it falls to connect properly, it is recommended to turn off the Bketooth keyboard power supply, restart and connect again.

eyboard Language Switching

- · iOS 8 or below: command + space
- · iOS 9 or above: ctrl + space · Android: ctd + space / shift + space / others
- Windows 10: ctrl / command +Space or alt + shift / caps Lock

Due to different system versions, the above way may not work in all

Important

As this is a multilingual keyboard, set the language of the device to your desired language before use

· For iOS devices only:

Settings > General > Keyboard > Keyboards > Add new keyboard > Select desired language

· For Samsung Android devices only:

Settings > Controls > Language and input > Samsung Keyboard > Select input languages > Select desired language

Settings > Language & input > Physical Keyboard > Set up keyboard layouts > Select desired language

For Windows devices only:

Control Panel > Clock, Language and Region > Select desired language

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off a nd on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receive
- -Connect the equipment into an outlet on a circuit different from that to

-Consult the dealer or an experienced radio/TV technician for belo

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

2.4G Pairing Instructions



1. Insert the USB receiver into the



2. Turn on the power switch located power indicator lights up in blue



3. Press fn + 🏚 to select 2.4 G channel.



you can use the keyboard.



5. Press fn + Q/W/E/R to select your system to ensure that the function keys and touchpad functions are

Bluetooth 1&2 Pairing Instructions



1. Turn on the nower switch located on the side of the keyboard, The power indicator lights up in blue and then goes out.



2. Press fn + 01/02 to select Bluetooth 1 channel or Bluetooth 2 channel



the pairing state: the Bluetooth





After the connection is successful you can use the keyboard.



3 Press the Bluetooth connection

button to make the keyboard enter indicator light starts to flash blue.

4. Turn on the Bluetooth settings on the



6. Press fn + Q/W/E/R to select your system to ensure that the function keys and touchpad functions are used normally.

NOTE:

- 1. If multiple devices are used at the same time, press Fn + 6/or/ a to
- 2. If you want to change the device connected to the 2.4G / Bluetooth1 / Bluetooth 2 channel, just follow the above connection method to re-pair and connect to the 2.4G / Bluetooth1 / Bluetooth 2 channel. 3. Auto re-connect function: when you turn on the keyboard, it will connect
- with the last-used device automatically. (After the connection, don't press the connect button again, or it will disconnect and you have to reconnect it.)
- 4. If the connection fails, please delete all the pairing records from your device; turn off your device Bluetooth function and turn it on again and then follow the above instructions again.

Touchpad Function Introduction

Touch Gesture	iOS (higher 13.4)	Android	Windows10	Mac OS
Switch Shortcut	fn + Q	fn + W	fn + E	fn + R
(One-layer (Bok)	Mouse Left	Mouse Left	Mouse Left	Mouse Left
(Twefinger dick)	Mouse Right	Mouse Right	Mouse Right	Mouse Righ
Twenty alde	Mouse Wheel	Mouse Wheel	Mouse Wheel	Mouse Whee

Touch Gesture	iOS (above13-4)	Android	Windows10	Mac OS				
Switch Shortcut	fn + Q	fn + W	fn + E	fn + R				
(Two-linger stretch)	Web Page Zoom	N/A	Zoom	N/A				
(Three-Inger click)	Main Screen	N/A	Screen	N/A				
(Three-finger slid up)	Open/hide Window or N/A	N/A	Open Task Browser	N/A				
(Three-larger slid down)	Open Al Active Windows	N/A	Back to Desktop	N/A				
(Three-linger sld)	Switch Active Window	N/A	Switch Active Window	N/A				
(Four-Inger class)	Screenshot	N/A	Open Action Center	N/A				
Disage many the commencering button to paint but as as not to affect normal use								

The fin key is used in combination with other keys to access special features.

Press fn + this key to choose 2.4G Channel.

Press fn + this key to choose Bluetooth Channel 1.

Press fn + this key to choose Bluetooth Channel 2.

Press fn + Q to switch the function keys to iOS system.

Press fo 4 W to exist the function less to Android susta

Press fo + R to switch the function keys to Mac OS system

Press fn + this key to check the battery reminding. The Indicator flashes once for 25%, twice for 50%, 3 times for 75%, and 4 time for 100%.

Press fo ± Z to perform a left mouse click

Press fn + X to perform a right mouse click.

Press fn + this key to work as virtual keyboard Note: this function work for iOS only.

Press fn + ito work as page up.

Press fn + ito work as page down.

Press fn + ____ to work as home.

Press fn + ___ to work as end.

A.

R

Z •

X

30

- Touch gestures may vary depending on the system version or device type.
 If the touchpad doesn't work in iOS13.4 or higher, please make sure you have it enabled Open "Settings"-"Accessibility"-"Touch"-"AssistiveTouch"-"On", and you can enable

System Requirements

- Mac OS X v10.6 to Mac OS X v10.12 and above
- Windows XP / Vista / 7 / 8 / 10 , PC computer with a Bluetooth host
 Android 3.0 and above with Bluetooth HID profile
- (Smartphones and Tablets) This keyboard is not compatible with Samsung Smart TV , Xbox and

How to Charge it

- 1. Use the included USB cable for charging. Connect one end to a USB
- charger, and the other to the keyboard. (USB charger is not included) In charging, the power indicator will turn red. Generally, it takes approximately 2-3 hours for a full charge. (Output: DC 5V/500mA)

FAQ

Q: Fail to connect. Step 1. Before to connect, please set as below.

- *Charge Samsers Bluetooth keyboard for 30 minutes.
 *On your device, delete/remove/forget the previous connection record with "Bluetooth Keyboard".
 *On your device, turn Bluetooth off, and turn Bluetooth on again.
 *Make sure that your Samsers device and your device are within close

Step 2. Follow the Pairing Instruction to connect it again. Q: My Samsers Bluetooth keyboard frequently gets disconn or laggy.

- Restart your Bluetooth product.
- Charge Samsers Bluetooth keyboard for 30 minutes. Low battery power can adversely affect connectivity and overall functionality.
- 3. Make sure that your Samsers Bluetooth keyboard and computer are
- within close proximity of each other. 4. Do not use on metal surfaces.
- Try moving away from:

 * Any device that could emit wireless waves: Microwave, cordless
- phone, baby monitor, wireless speaker, garage door opener, WiFi router
- *Computer power supplies

 *Metal or metal wining in the wal

 5. Make sure your operating system (OS) is up to date.

 6. Check if there are any updates running in the background that may
 cause the delirent computer/smartphone/tablet.

 7. Try on a different computer/smartphone/tablet.

- If the problem still persists, you will need to follow specific steps based on our device OS (Windows/Mac OS). Please email ur

More questions about using under Android devices.

Android operating system is still not unified, and different manufacturer make different rule. For standard keyboard, because of rule change, the standard function may not work any more. If you are using under Android device and suffering some problems, please contact us.

If you have any use problems with our keyboard, please do not hesitate to contact us! Please rest assured that we will definitely help you solve them! Please contact us for a 24-month worry-free warranty: Samsers@126.com

