




nextDrive



Quick Start Guide
快速上手指南

for FCC 15b devices

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the distance between the equipment and the receiver.
3. Connect the equipment to an outlet on a different circuit than the receiver.
4. Get help from the dealer or an experienced radio/TV tech.

FCC RF Radiation Exposure Statement:

1. This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
2. This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

NCC警語：

低功率電波輻射性電機管理辦法第十二條經型式認證合格之低功率射頻電機，非經許可，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。

第十四條低功率射頻電機之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。

前項合法通信，指依電信法規定作業之無線電通信。低功率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

02 Quick Start Guide

- 03 Package Contents
- 04 Device Layout
- 05 Installation
- 06 NextDrive Connect App
- 07 Default Setting
- 11 Direct Link Mode
- 17 Warranty and Repair Clause

18 快速上手指南

- 19 產品內容物
- 20 產品簡介
- 21 安裝
- 22 專屬應用程式
- 23 一般設定
- 27 直連模式設定
- 33 保固條款與維修注意事項



Quick Start Guide

Customer Service

Please email to contact@nextdrive.io

Manufacturer : NextDrive Inc.

Trade mark : nextDrive®

Model name : Cube

Product name : IoT gateway


Important Safety Instructions

Please read the following safety instructions which are intended to help avoid the risk of damage to the equipment and injury to the user.


1. Do not place the NextDrive Cube near a source of heat or ignition.
2. Do not install your NextDrive Cube in a wet or damp area. Do not touch or operate the Cube with wet hands.
3. Unplug the NextDrive Cube during a thunderstorm or when it is not in-use for long periods of time to prevent electrical surges from building up and possibly causing damage to the device.
4. Do not plug the product in an enclosed or tight space like a bookcase or wardrobe.
5. Do not insert metal objects of any kind into the NextDrive Cube's USB port.
6. If the NextDrive Cube is not working properly or emitting any unusual noises or an unpleasant odor (burning smell), remove the plug from the outlet immediately and contact the Customer Service Center.
7. Do not disassemble or puncture the case of the NextDrive Cube so as to avoid damaging or coming into contact with any high-voltage internal circuitry. Please read and carefully observe all warnings and instructions contained in the user manual.
* The actual operation is predominantly based on "NextDrive Cube User Manual." (www.nextdrive.io/support)

Caution


1. The NextDrive Connect App provided by NextDrive Inc., is free. However, your network operator may charge for data expenses.
For detailed rate information, please contact your telecommunication service provider.
2. The images and directions in this guide are for illustration purposes and may not be identical to your experiences with the App.
The actual operation will be based on your specific smartphone model and its software.



NextDrive Cube × 1



Quick Start Guide × 1



Multi - Functional Button

LED Light

The LED light displays different statuses.

Blue blinking - Booting

Solid blue - System & Wi-Fi ready for use


Red blinking - Error

Red / blue rapidly interval blinking - Reset to Default


USB Port

Before using the NextDrive Cube

Please Insert the NextDrive Cube into a power outlet. Wait for the NextDrive Cube to boot up.



When the Blue LED stops flashing and remains solidly illuminated, your Cube is ready for use.



Download NextDrive Connect App

Android Devices – The NextDrive Connect App is available through Google Play Search for "NextDrive Connect"



Android Device

iOS Devices – The Next Drive Connect App is available through Apple App Store Search for "NextDrive Connect"



iOS Device


Default Setting

Before start default setting please turn on the Bluetooth on your smart phone.


To use Bluetooth, your mobile device must support Bluetooth 4.0 and have one of the following OS versions:

- * Android OS: Version 4.3 or later
- * iOS: Version 8.1 or later

1 Associate the NextDrive Cube with your phone or tablet



2 Select Cube



3 Add Cube

Connect to the NextDrive Cube,
please wait.




When the device list shows
up, please select Cube-xxxxxx



4 Set the NextDrive Cube's password

Create a password for the Cube



←

Cube name
Cube-xxxxxx

Cube password


Comfirm password

Password must be at least 8 characters long.

OK

5 Join a local Wi-Fi network


Please tap "Yes".



From the Wi-Fi list that appears, choose the network to which you want to connect your NextDrive Cube.

Later Yes

Select a network



← Select a local Wi-Fi network

NextDrive

MeetingRoom01


MeetingRoom02

Lobby

+Add new Wi-Fi


6 Setup is completed!

Enter Wi-Fi password



A mobile app screen for entering a Wi-Fi password. At the top left is a back arrow icon. Below it, the text "Wi-Fi name" is followed by a horizontal line containing "NextDrive". Underneath are two rectangular input fields, each containing eight dots. At the bottom center is a large circular button with the text "OK".

Please enter your local Wi-Fi network's password




Direct Link Mode

In case the App is not able to help you properly configure the Cube via Bluetooth, you can also configure the Cube directly through the **Direct Link Mode**.

If you are having difficulties on setting through Bluetooth, please try the **Direct Link Mode**.


1 Smartphone's Wi-Fi Settings

Goto your smartphone's "Settings" and tap into "Wi-Fi Setting"




2 Find the Cube-xxxxxx

Look for a device with a name in the format of "Cube-xxxxxx" and tap on it.




3 Enter default direct link password

Enter 12345678 as the password and tap Connect.



4 Directly linked to Cube-xxxxxx

Your phone has been directly connected to the Cube.



5 Back to NextDrive Connect App

Launch the App.




6 Add device




7 Select Cube

Select device.



8 Add Cube

Searching for the NextDrive Cube, please wait.




When the device list shows up, please select Cube-xxxxxx



9 Set the NextDrive Cube's password

Create a password for the Cube




10 Join a local Wi-Fi network

Please tap "Yes".



Select a network




← Select a local Wi-Fi network

- NextDrive
- MeetingRoom01
- MeetingRoom02
- Lobby

+ Add new Wi-Fi



Enter Wi-Fi password



←

Wi-Fi name

NextDrive


.....

.....

OK

Please enter your local Wi-Fi network's password

11 Setup is completed!



NextDrive Cube Warranty and Repair Clause

Warranty Coverage

The included warranty extends one year from the invoice date at the time of purchase. If the product fails under normal usage conditions, and it is then confirmed after assessment that the failure was caused by product defect, we shall provide maintenance service within this warranty period. However, cosmetic defects in appearance, the casing, or in ornamental accessories are not covered by warranty.

*About warranty, it is predominantly based on : www.nextdrive.io/support

Caution of Repair

1. While in the process of maintenance, the product will be reset to factory defaults. No user settings will be retained. NextDrive Inc. is not held liable for any data loss that might have been caused by product service and repair.
2. During maintenance, spare parts may be used for the replacement of some parts and assemblies. Therefore, after maintenance, the product or parts and assembly may not be the same as those originally sent in for repair.

Responsibilities Uncovered by Warranty

Any following situation will void the warranty even within the warranty period. In this event, the consumer shall be obligated to pay any and all maintenance charges or material expenses for repair. These charges will be based on the rates used by the appointed maintenance and service points by NextDrive Inc. and its dealers.

1. The product serial number is not the same as the one listed on the Product Warranty. Or, the product serial number is not clear or has been altered or torn.
2. It is determined the damage was caused by improper use, including heavy pressing, impact, crash damage, exposure to moisture or rain, soaking in water, exposure to high temperature, ingress of foreign matters, missing parts, etc., or by a consumer who fails to follow the user manual.
3. Scratches and wear on the product casing or any parts accessible without dismantling under normal use are not covered by the warranty.
4. The product has been damaged by disasters beyond our control such as an Act of God, flood, earthquake, etc.
5. Damage has been caused by human error, including accidents, sabotage, improper use, modifications, power supply problems, etc.
6. Disassembly or maintenance has been performed by unauthorized personnel, or failure or damage has been caused by disassembly or modification of the product by the consumer or by use of accessories not originally supplied by us.
7. Problems or failures caused by software installation/setup errors or a computer virus.
8. Poor signal reception due to the service provided by the mobile or fixed network provider or insufficient network bandwidth.
9. This warranty only applies to the original hardware components supplied with the product and not to any software or other equipment.

快速上手指南

客服信箱 contact@nextdrive.io

客服電話 02-8691-7860 (週一至週五 10:00-18:00)

製造商：聯齊科技股份有限公司

廠牌：nextDrive®

型號：Cube

產品名稱：物聯網開道器

重要安全性指示

請閱讀下列的安全指示說明，其目的在於避免裝備財產損壞與使用者受傷的危險。


1. 請勿將 Cube 置於高溫及火源附近。
2. 請勿將 Cube 安裝於潮溼區域；請勿用濕手觸摸或操作 Cube。
3. 雷雨期間或長期不使用時，請將 Cube 拔下，避免異常突波導入而造成損壞。
4. 請勿將 Cube 置於密閉空間中或侷限空間內，如書櫃或是衣櫥內。
5. 嚴禁將所有種類的金屬製品插入 Cube 的電源接口中。
6. 如果 Cube 運作不正常，特別是有異常聲音或異味（燒焦味）傳出時，請立即拔除並與客服聯繫。
7. 請勿拆解或讓異物刺穿 Cube 外殼，以避免觸碰內部之高壓零件或導致內部零件受損。

請詳閱並遵守手冊內的所有警告與指示。未詳閱並遵守者，其保固將失效。


* 詳細的使用規範，請以官網（www.nextdrive.io/support）之「NextDrive Cube 使用指南」為主。

注意事項


1. 聯齊科技提供之 NextDrive Connect App 是一項免費服務，但網路營運業者會就使用流量收取數據費用。詳細費用資訊請洽詢所配合的電信服務商。
2. 此使用指南或快速指南不一定與實際產品的軟體相符。因手機軟體將依照實際狀況不定時更新，實際操作請以手機為準。



NextDrive Cube × 1




快速上手指南 × 1




使用 NextDrive Cube 之前

請將 NextDrive Cube 插到插座上。



靜待 LED 燈號顯示藍色恆亮，
即為開機完成。



下載 NextDrive Connect App

Android – Google Play
搜尋 NextDrive Connect



Android Device

iOS – Apple Store
搜尋 NextDrive Connect



iOS Device


一般設定

在進行一般設定之前，請先開啟您手機中的藍牙設備


啟動藍牙功能，手持裝置需支援藍牙4.0
作業系統需求：

- * Android 系統需 4.3 以上
- * iOS 系統需 8.1 以上

1 關聯 NextDrive Cube 和手機或平板




在“裝置列表”頁，請點選
右上角“新增裝置”



② 選擇 Cube

選擇裝置



③ 新增 Cube

連結 Cube 中



選擇 Cube

如果無法以藍牙操作，可能手機未支援藍牙 4.0 或作業系統為舊版，請參考第 27 頁的“直連模式”進行關聯



4 設定 Cube 密碼

設定 Cube 密碼

←

Cube 名稱

Cube-xxxxxx

Cube 密碼

確認密碼

這是一個全新的 NextDrive Plug
請設定 Plug 的密碼最少 8 個字元

確認

5 加入 Wi-Fi 網路

請點選“是”

請把 NextDrive Cube 加入
您的 Wi-Fi 區域網路

稍後 是

選擇網路

← 選擇區域網路

NextDrive

MeetingRoom01

MeetingRoom02

Lobby

+ 增加新區域網路

6 完成設置！

加入 Wi-Fi 區域網路



請輸入 Wi-Fi 區網無線基地台密碼

成功新增 Cube




直連模式設定

若無法使用一般模式與 NextDrive Cube 關聯, 請嘗試以"直連模式"完成設定。

當 App 無法藉經預設藍牙模式協助您完成設定時, 請嘗試使用 "直連模式"

1 進入手機 Wi-Fi 設定頁

請開啟手機的 "設定", 點選 Wi-Fi 進入設定頁



2 找到 Cube

請開啟 Wi-Fi (若尚未開啟)
找尋到 "Cube-xxxxxx", 請點選



3 輸入預設直連密碼

輸入 12345678 (預設直連密碼)，
按 "連線"



4 完成直連

您已成功直連您的 Cube-xxxxxx
(如圖中 ✓ 顯示 "已連線")



5 回到 NextDrive Connect App

新增 Cube

點此進入裝置列表




6 新增裝置

在“裝置列表”頁，請點選右上角“新增裝置”



7 選擇 Cube

選擇裝置



8 新增 Cube

關聯 Cube 中




9 設定 Cube 密碼

App 會將找到的 Cube 列出來，
請點選 Cube-xxxxxx



設定 Cube 密碼



10 加入 Wi-Fi 網路

將 NextDrive Cube
加入區域網路，請點選“是”



選擇網路



← 選擇區域網路

NextDrive

MeetingRoom01


MeetingRoom02

Lobby

+ 增加新區域網路



加入 Wi-Fi 區域網路



← 區域網路名稱

NextDrive

.....


.....

確認

請輸入 Wi-Fi 區網無線基地台密碼

11 完成設置！

成功新增 Cube



NextDrive Cube 產品保固條款與維修注意事項

保固範圍

保固期間依購買時開立之統一發票日期起算一年。產品在正常使用情形下發生故障，經鑑定為產品本身之問題，於保固期限內提供維修服務；外觀、外殼及裝飾性零組件機構受損不在本有效保證條款內，無法提供免費維修服務。

維修注意事項

1. 在產品維修過程中，產品將恢復為出廠設定值，所有個人設定將無法回復，倘因前述原因造成之損失，本公司均不予負責。
2. 部分零組件之維修係採取備品更換方式作業，故維修後之產品或零件可能非原本的送修品。

保固除外責任

雖在保固期間內，若屬下列任一情況者，則產品不在保固範圍內，消費者需負擔全部維修費或材料費，收費標準依聯齊科技及其代理商所指定之維修服務據點規定。

1. 產品序號與產品保證書載明不相符者。產品序號不清楚，或被更改、撕毀者。
2. 因消費者未按使用手冊或說明書規定，使用不當而損壞者，包括重壓、撞擊、摔壞、受潮、浸水、淋雨、高溫、異物侵入、遺失零組件等造成之損壞。
3. 因正常使用時，所造成產品外殼或不需拆解而可接觸部分上之刮傷、磨損。
4. 天災、水災、地震等不可抗力之災害造成產品損壞。
5. 因人為疏忽因素包含意外、人為破壞、不當使用、自行變更零件、天然災害或電源問題所造成之損壞。
6. 未經本公司授權之人員拆卸或維修，或自行拆裝、改裝產品、任意變更規格、或者使用非原廠配件所引起之故障與損壞。
7. 因軟體安裝設定或電腦病毒所造成之問題與故障。
8. 因行動網路業者或固網業者提供之服務，所造成的收訊不良或網路頻寬不足，不在本有限保固條款範圍內。
9. 本保固僅適用於產品原始供應之硬體元件，不適用於任何軟體或其他設備。

產品的Rating &環境操作溫度：

額定電源：輸入: 100-240Vac/0.2A, 50-60Hz; 輸出: 5Vdc/0.5A

環境操作溫度：40℃



nextDrive

www.nextdrive.io

© 2015 NextDrive Inc.



HDXI1001010