M0887_001(T7)_说明书_尺寸：72 x90mm(展开尺寸：937x90mm) ,材料128g双铜纸+哑膜，正反面单色印刷

72 mm

90 mm

T7 User Manual

FCC ID:2AFMB-T7

Please read and follow this user guide thoroughly before using the T7 Earphone and keep it for future reference.

Package Includes

Product Layout

1	Touch & call button
2	Microphone
3	Charging pin diode
4	Charging cover

Power on/off

To power on the earphones, simply remove the earphones from the charging case, earphones will automatically turn on if it is charged. To power off the earphones put the earphones back to charging case and closed the case.

Pair with Bluetooth

The earphones are switched into the case, after automatically power on, the earphones automatically connect to each other, and will "pair ing" prompt tone, the LED indicator flashes blue.

Note: The earphones must be connected to the device within 3 minutes. Otherwise the earphones will go in power saving sleep mode. To activate the earphones from sleep mode, place earphones back into charging case and wait a few seconds and the follow the above procedure again.

Turn on the Bluetooth on your device, go to Bluetooth menu, search for T7, select to pair and connect. You will hear "Connected" sound when pairing is complete.

Note: The earphones with master slave switching function.

Best fit & best sound

To deliver one ear tips to find the best fit, to get the best sound experience. Fit is key to good sound quality and bass response. A poor fit can result in sound from the speaker when walking, running or doing any sport activity.

Follow the images and the chart below to learn how to wear the earphones in right manner. Make sure you insert the earphone with the earbigs drooping towards your ear canal, place the earphones gently so they stay fit comfortably and securely in your ear. Not wearing the earphones in right manner will affect the connection signal of the earphone, sound output and the microphone sound input.

Correct way

Incorrect way

Tip: Select the earbigs that sealy your ear canal for the best sound. You will need different size ear tips for left and right.

Music

Once the earphones are paired with your device or any other media device, simply press the touch button to play music or to control music, also to activate the media function like play, pause, volume, tracks, calling from the earphones.

Music touch operation button

(Play/Pause/Previous song/Next Song/Start Siri)

Operation	Left earphone	Right earphone	Siri
Play/Pause	2	2	2
Previous Song	3	3	3
Next Song	4	4	4
Volume+	5	5	5
Volume-	6	6	6
Start Siri	7	7	7
Hangup call	8	8	8
Answer call	9	9	9

Wireless functions are for touch operations.

Call

Note: Both ears can be heard from both ear phones at same time.You can use any earphone control.

Incoming call	Double tap	Answer/Reject call
Hangup call	Double tap	Hangup call
Call waiting	Double tap	Hangup call

Wireless functions are for touch operations.

Charge the earphones

Put the earphones into the case.

Charging will start and indicate the earphones is charging. When completely charged, the light will turn off.

Charge the case

Charge the case by plugging in the charging cable. A pulsing blue light indicates charging.

Battery Alert

When the battery charging level is low and only 5 minutes of playtime is left, you will hear a "battery low" voice message "Battery low". The message is repeated after every 30 seconds.

Earphone status lights

Charging	Pulsing blue light
Fully charged	Lights off
Pairing	Pulsing blue light
Power	Blue light on

Case status lights

When a charging earbud is plugged into the case, you will see charging lights.

Charging	Pulsing blue light
Fully charged	Steady blue light (Turn off if not put into case)
Power	Blue light on

Note: The battery is designed to last 4hours of the playtime. It should only be recharged when the battery is low. We advise the release or replace the battery in accordance with local laws and regulations.

Basic Specifications of Earphone

Bluetooth version: V5.0

Weight: 4.5g

Earphones: 40mAh

Charging time: About 1.5 hour

Working Voltage: 3.3V-5.2V

Standby time: about 8Hours

Talking time: About 3.5hours

Talking Time: 4 hours

Bluetooth version: 5.0

Bluetooth profile: HFP, A2DP, AVRCP

Transmission Range (No): 0.0dBm ~ 1.0dBm

Transmission distance: 10m

Frequency response: 20Hz-20KHz

Audio encoding format: CVSD、MSBC、SBC

SNR: ≥80dB

Working temperature: -20 C ~ +60 C

Working humidity: 20%-90%(no condensation state)

Earphones Speaker Specifications

Speaker specifications: 14mm (DD)

Impedance: 16Ω ±10%

Frequency: 20Hz - 20khz

Sensitivity: 95±3dB

Input Power: 120mW (Normal), 5mW (Maximum)

Earphones MIC Specifications

MIC type: Silicon MIC

MIC Sensitivity: -42±3dB

SPL: 120dB

Basic Specifications of Charging Case

Material: ABS+PC

Weight: 55.5g

Charging Time: 2hours

Charging Output: 5V 1A provide power to earphone. Up to 2 times

Charging time: Up to 2 hrs

Input Voltage: 5V1A

Charging Current: 500mA

Output Voltage: 5V5V

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

Safety instructions for use

To avoid hearing damage, keep the volume at a moderate level.

Do not use headphones while driving, cycling or any other activities that require full attention, as this may cause serious injury. Hearing damage or impaired hearing can also result in traffic conditions including while operating motorcycles, cycling, crossing a railway, walking in a busy area, or any other situation requiring your ability to hear.

Note: If you are wearing earbuds while using your earphones, your audio may be slightly out of synchronization with your device.

Safety Warning

Check thoroughly the cable after charging. Product should not be charging for a prolonged period of time. Please use the charger or adapter with correct voltage and current. Use the charger or adapter with correct voltage and current. The output voltage and current of the charger exceeds the product's requirement, may cause severe damage to the product, and the product warranty will be void.

FAQ

Q: What should I do if there's only one earphone working, or left & right earphone playing different sounds?

A: Please check the earphones are fully charged, turn off the earphones and restart.

Note: If no voice after stand & dispry earphone connection, follow the steps below to pair.

Q: Do I need to re-pair each time I turn it on?

A: No, after the initial pairing, just switching and automatically power on and connect both earbuds (this is important) and your device right after you remove them from the charging case.

Q: Why should I do if the earphone does not automatically connect to the device?

A: Please check T7 from the Bluetooth menu list of your smart device or other accessories. Follow the pairing guide for repairing.

Q: What if the connection is unstable or there is no sound in the left earphone?

A: Please check the earphones are fully charged and the earbuds are in the charging box and connect to the device.

Q: Can a T7 earphone be paired with only one device?

A: No, both earbuds must be paired separately and up to the device can pairing to the earbuds.

Q: How do I know if the earphone is charging in the charging case?

A: Please see status charging of the charging case, T7 earphone is charging.

Q: Can I charge the earphone when I charge the charging case?

A: Yes.

Q: What should I do if the charging case does not work?

A: Replace the Type-C charging cable or charge the charging case for a while and then charge the charging case. If still unable to charge, please contact customer service.

Q: What if the earphone touch button does not work?

A: Please check if it is a short of the earphone button. It is solved with some cleaning. Please check the contact of the earphone battery and the surface of the chipset and try again.

Warranty Card

Warranty Card			
Customer Information			
Model No		Store info	(Signature)
Customer Name		Telephone No	
Sales Phone No		Buy Date	
Product SN			
Customer Add			
Store Add			
Notes			
Date	Problem	Check	Notes