SM-SH-ID215G-V1，双面彩印，85g哑粉，胶装，成品尺寸:63*75mm，通用版本

英

FCC ID：2AWMG2G1WG

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

Smart Watch
User Manual

Thank you for purchasing our product. This manual addresses the safety guidelines, warranty, and operating instructions. Please review this manual thoroughly before operating your device.

Contents

English Version.....5

Getting Started 1
What's in the box.....1
What's in this Document.....1

Setting up Your Watch.....2
Charging your watch.....2
Downloading and Maintaining Your Watch.....4

Wearing Your Watch.....6

Using Your Watch.....8
App Installation.....8
Small Phone System Requirements.....8
Using Your Watch.....9
Pairing the Watch with Your Phone.....11

Getting to Know Your Watch.....14
Function Buttons.....14
Watch Interfaces.....15
Unlock the screen.....15

Function Introduction.....17
1. Tracking Sports.....18
2. Monitoring Heart Rate.....21
3. Monitor Blood Oxygen Level.....22
4. Checking Weather.....22
5. Setting Alarms.....23
6. Tracking Sleep.....23
7. More Functions.....24
7.1 Call Notification.....24
7.2 Message Notification.....24
7.3 Sedentary Reminder.....26

Basic Specifications.....26

FAQs.....27

Warranty.....30

Important Safety Instructions.....31

Deutsche Version.....37

Aviso legal.....38

Aviso legal.....38
Was ist in diesem Dokument enthalten.....38

Einrichten Ihre Smartwatch.....39
Laden Sie Ihre Smartwatch auf.....39
Demontage / Montage Ihre Smartwatch.....41

Tragen Sie Ihre Smartwatch.....43

Benutzen Ihre Smartwatch.....45
Die Installation der App.....45
Mindestanforderungen für Smartphones.....45
Die App fahren.....46
Verbinden Sie die Smartwatch mit Handy.....48

Kennen Sie Ihre Smartwatch.....51
Die Tasterfunktionen.....51
Die Uhrenansichten Schnitte.....52
Den Bildschirm entsperren.....53

Funktion Einführung.....54
1.Sport verfolgen.....58
2. Überwachung der Herzfrequenz.....58
3. Überwachen Sie den Blutsauerstoff.....59
4. Das Wetter zu sehen.....59
5. Alarme einstellen.....60
6. Schlaf verfolgen.....60
7. Weitere Funktionen.....61
7.1 Anruflbenachrichtigung.....61
7.2 Nachrichtenbenachrichtigung.....61
7.3 Sitzende Erinnerung.....62

Grundl-Technische Daten.....63

FAQs.....64

Garantie.....67

Wichtige Sicherheitsanweisungen.....68

Getting Started

What's in the box

What's in this document

This manual guide you started quickly with setting up your watch. Set up a new or your existing watch (you can pair only one watch at the VeryFitPro app), where you can get detailed information on your data, view historical trends, log sleep, and more. As soon as setup is complete, you can use the app to sync, view a reminder of the manual walks you through every function on your ID215G.

Setting up Your Watch

Charging your watch

Please fully charge your watch before initial use.

1. Insert the USB plug of the charging cable into the USB port on your computer or a UL-certified USB wall charger.
2. Place the watch in charging cradle and push it in until you hear a click. The pins on the charging cradle must align with the gold contacts on the back of the watch. If the watch is in the right present charged appears on the screen.

When the watch shows that the battery is low, connect it to a charger. Remove the charging cradle from the pins on the charging cable attach securely to the pins on the smart watch.

Remove the watch from the power supply once fully charged.

- USB charger requirement: DC USB port (5V-500mA)
- Charging time: 2 hours

Disassembling / Assembling Your Watch

Disassembly

1. To remove the wristbands, slide the pin (the side opposite the quick-release lever) into the notch on the watch. Pull the wristband with the clasp to the top of the watch.

2. While pressing the quick-release lever inward, gently pull the wristband away from the watch to release it.

3. Repeat on the other side.

Assembly

1. To reattach the wristbands, slide the pin (the side opposite the quick-release lever) into the notch on the watch. Push the wristband with the clasp to the top of the watch.

2. While pressing the quick-release lever inward, slide the other end of the wristband into place.

3. When both ends of the pin are inserted, release the quick-release lever.

Wearing Your Watch

All-day wear and exercise

For all-day wear when you're not exercising, wear the device on your wrist horizontally, a finger's width below your wrist bone. Not tying too tight, the same way you would put on a watch.

For optimized heart rate tracking, keep these tips in mind:

1. Experiment with wearing the watch higher on your wrist, tighter and/or in a cooler area of your arm. Your arm increases the farther up you go, moving the watch up a couple of inches can improve the heart rate tracking. Tattoos, sunburns, cold, tan lines or weight/lifting require you to bend your wrist frequently, which is more likely to interfere with the heart rate signal if the watch is lower on your wrist.

2. Do not wear your watch too tight. A tight band restricts blood flow, potentially affecting the heart rate signal. It may be comfortable when you first put it on but not comfortable during exercise than during all-day wear.

Using Your Watch

App Installation

Use the watch with our customized VeryFitPro app. You can download VeryFitPro from Apple Store / Google Play or scan the QR codes below to download.

Setting up App: VeryFitPro

Note:

- The VeryFitPro app is only compatible with smartphones, not tablets or PCs.

Smart Phone System Requirements

- iOS 9.0 & higher
- Android 4.4 & higher
- Bluetooth 4.0 & higher

App Interfaces

Pairing the Watch with Your Phone

Please pair the watch with your phone in the VeryFitPro app, NOT in the Bluetooth settings.

1. Enable the Bluetooth of your smartphone.
2. Open the VeryFitPro app on your smartphone and go to the "Device" page, tap "Bind Device", then your smartphone starts searching devices.

3. In the list of found devices that appear on your smartphone, tap "ID215G" to connect the watch to your smartphone.

Note:

If your phone failed to find ID215G, please reset the watch on the app again and keep your watch's screen on and close to your phone. If it still failed, please try to reboot your watch. If there are many Bluetooth devices nearby move to a remote area and try again.

Notes:

- Once the watch is connected to your app, the watch will automatically search and reconnect itself if the connection is lost or when Bluetooth is restarted after being disconnected.
- If the watch is unbinded from the app, the information on the watch will be reset, and the information in the app will be cleared. Please do not unbind the connection unless there is an issue that will require a reset.
- The watch can only pair with to one smartphone at a time. When pairing, please ensure the watch and your smartphone is within 0.3 meters distance.

Getting to Know Your Watch

Function Button

- Press the Up button to unlock the screen or switch interfaces.
- Press and hold the Up button to enter / end the sports mode function.
- Press the Down button to unlock the screen.
- Press the Down button to return to the home screen.
- Press and hold the Down button to turn on / off the watch.

Watch Interfaces

This is a touch screen; swipe the screen to go to different interfaces and tap to enter the function.

The home screen is the clock. On the clock:

- Swipe down to see notifications.
- Swipe up to see the status bar (brightness, do not disturb, system settings).
- Swipe left to switch function interfaces (sports mode, heart rate, weather, blood oxygen level, more functions).
- Swipe right to see the data bar (steps, calories burned, distance).

fig.1

When the battery level is less than 10%, the watch enters battery save mode, at which you cannot start a sports mode. Please charge the watch to use it again.

After the watch is stuck in the app, the home screen will automatically return to the clock in 2 min.

You can customize the home screen by following the steps below:

1. Press the Up or Down button to unlock the screen.
2. Tap and hold the home screen.
3. Swipe left / right to choose one and tap to confirm.

Unlock the screen

To conserve power, the watch has a standby mode in which the screen is locked. To unlock the screen, press the Up / Down button.

Function Introduction

Adjust brightness, turn on / off "do not disturb", view system information, and restart the watch.

1. Tracking Sports

The watch tracks your exercise data in 7 sports modes including outdoor running, indoor running, outdoor walking, indoor walking, hiking, outdoor cycling and pool swimming.

Start a sport

Swipe the screen to enter into sports mode — Swipe up / down to select a sports mode — Tap the sport icon to start the app. The watch will GPS is positioned successfully, tap the sport icon.

Notes:

- When the GPS signal is weak, you can tap **◎** to enter the outdoor running/outdoor walking sports mode directly without GPS positioning. Your movement track will be shown on your watch after the exercise is ended.
- Indoor running, indoor walking, and pool swimming sports modes do not need GPS positioning.
- Outdoor cycling sports mode can only be started after the GPS is successfully positioned.

During sports

- Press and hold the Up button to pause the sport. Tap **▶** to continue the sport.
- Tap the screen left / right to flip through exercise data.

End the sport

- Press and hold the Up button — tap **■** to pause the Down button to stop the sport.
- Exercise data is displayed after the exercise ended. Swipe down the screen to flip through exercise data.

Notes:

- The touch screen function is not available in the pool swimming sports mode. To end this sports mode, please press the Up button and then press the Down button.
- Sports mode is up to 8 hours.
- Exercise data with a distance of less than 10 meters will not be saved.

- When you enter outdoor running, outdoor walking, biking, or outdoor cycling sports mode, the GPS of the watch can display the track on the app map after being positioned successfully.

2. Monitoring Heart Rate

The watch tracks your real-time heart rate automatically and continuously. You can also view your detailed heart rate data on the watch screen or in the app.

Notes:

- To monitor heart rate more accurately, wear the watch on the upper position of your wrist and a bit tighter during sports or exercises. In addition, complete your profile in the app.

- Automatic heart rate monitoring is ON by default, monitoring heart rate all day. Automatically. You can disable / enable automatic heart rate monitoring in the app (Go to "Device" page → "Heart Rate Detection").

3. Monitoring Blood Oxygen Level

Swipe the screen of the watch to enter blood oxygen level interface, and tap the screen to measure. Please stand still to ensure the accuracy of the data.

4. Checking Weather

When the watch has synced with your phone, tap the icon to see the weather forecast and lowest temperatures of the day on the watch.

5. Setting Alarms

1. Go to the "Device" page in the app and tap "Alarm Alert".
2. Tap "+" to add an alarm.
3. Tap the alarm, then set the alarm type, repeat type and time.
4. Tap "✓" to save your settings.

Note:

You can disable / enable the alarm in the app (Go to "Device page" → "Alarm Alert").

6. Tracking Sleep

The watch automatically tracks your sleep duration (Deep Sleep, Light Sleep, and Wake-sleep) and consistency with a comprehensive analysis of sleep quality data so you can see your sleep trends and improve your sleep.

You can check your detailed sleep data in the app.

7. More Functions

7.1 Call Notification

When there is an incoming call, the watch vibrates to alert you, and the screen displays the caller ID.

Tap **Off** on the watch screen to reject the call.

Note:

When only "Call alert" is enabled in the app ("Device" page → "Notification Alert"), only the "Call alert" is enabling / disabling the Call Alert function, tap "✓" to save your settings.

When only "Call alert" is enabled in the app ("Device" page → "Notification Alert"), only the "Call alert" is enabling / disabling the Call Alert function, tap "✓" to save your settings.

When "Call alert" is enabled in the app ("Device page → "Notification Alert"), enable the Sedentary Alert function and set the remind interval.

7.2 Message Notification

When messages (like Facebook, WhatsApp, etc.) notifications come in, the watch vibrates to alert you, and the screen displays the message content.

Notes:

- Only when "SNS Alert" is enabled in the app ("Device" page → "SNS Alert" → "Allow notification"), will messages be notified. (After enabling / disabling the "Allow notification", tap "✓" to save settings.)
- When "Do not disturb" is signed in the watch (Swipe down the screen, and tap **☾**) messages will not be notified on the tracker during the do-not-disturb period.

7.3 Sedentary Reminder

This function reminds you to get up and move if the watch detects you have been sitting too long ("Device" page → "Sedentary Alert", enable the Sedentary Alert function and set the remind interval.)

Basic Specifications

Model No.: ID215G

Screen: 1.7 Full Reflection Screen

Battery Capacity: 260mAh

Working Voltage: 3.8V

Working Temperature: -10 ~ to 40 ℃

Weight: 1.7oz (48g)

Waterproof Rating: 5ATM

Working Time: Approximately 15 days (without GPS mode)

Approximately 20 hours (in GPS mode)

Standby Time: Approximately 40 days (when fully charged)

Electronic Information Products Toxic and Hazardous Substances Statement

RoHS

This product meets the EU ROHS standards

Refer to IEC 62321 and EU RoHS Directive 2011/65/ EU and its revision instructions

FAQs

Failure to find the watch when pairing

1. Make sure the Bluetooth of your smartphone is enabled and your smartphone's system meets the requirements of Android 4.4 or higher, IOS 9.0 or higher, Bluetooth 4.0 or higher.
2. Make sure the distance between your smartphone and the watch does not exceed 0.3 meters and that Bluetooth communication is also within range (10 meters max).
3. Make sure your watch has enough battery life. If the battery is low, please charge it fully charged, please contact us.

Occasional failure to connect with Bluetooth

Reboot your smartphone or restart your smartphones Bluetooth.

Failure to receive SMS / calls notifications

Calls / SMS notification function works when the watch connects to your smartphone via the app. Please kindly refer to the following tips:

1. Go to your smartphone Settings, find VeryFitPro app and enable the Location and all notifications.
2. Enable your phones Bluetooth and go to the VeryFitPro app to bind the watch.
3. Enable the Call / SMS Alert function, and tap "✓" to save your settings.

Failure to connect to smartphone

Please ensure your phone and your smartphone in the following cases:

1. Smartphone Bluetooth is off or exceeds the Bluetooth connection range (the maximum Bluetooth connection range is 10 meters and can easily be interrupted by other signals).
2. The VeryFitPro app is closed on the phone. (The app must actively running under certain circumstances.)

Please ensure that in your smartphone, please kindly take the following steps:

1. Go to your smartphone system Settings, find the VeryFitPro app and enable the Location and all notifications.
2. Enable running / background processes on your smartphone. Go to the VeryFitPro app and swipe down "Homepage", then the watch will reconnect to your smartphone automatically. If you have disabled your smartphone and Bluetooth, then retend the watch in the app.

GPS positioning is inaccurate

1. Ensure that the GPS positioning is successful when you start a sport mode.
2. Wear GPS signal in your exercising environment will also influence the accuracy of the positioning.
3. Please confirm whether the AGPS in the app needs to be updated. The positioning accuracy will be enhanced after the update.

Warranty

We strive to build our products with the highest attention to detail and craftsmanship. However, sometimes there are occurrences of a defect, so we are happy to offer a ONE-year hassle-free warranty on all our devices as we continue to make amazing products. Please contact us if you have any questions about our devices.

Important Safety Instructions

The device contains electrical equipment that may cause injury or damage if misused. Prolonged contact may contribute to skin allergies in some users. To reduce irritation, please read the safety instructions on the following pages to ensure proper use and care.

- Do not expose your device to liquid, moisture, humidity or rain while charging: do not charge your device when it is wet, as this may result in electrical shock or injury.
- Keep your device clean and dry. Do not use abrasive cleaners to clean your device.
- Consult your doctor before use if you have any preexisting conditions that might be affected by using this device.
- Do not wear it too tight. If your device feels hot or warm, or if it causes any skin irritation or other discomfort, please discontinue using your device and consult your doctor.

- Do not expose your watch to extremely high or low temperatures.
- Do not leave your watch near open flames such as cigarettes, candles, or other ignitions.
- This product is NOT a toy – never allow children or pets to play with this product. Always store the product out of their reach. Keep the SMALL accessories or the many small parts they contain may cause choking if ingested.
- Never try to abuse, crush, open, repair or disassemble this device. Doing so will void the warranty and can cause injury or damage.
- If any parts of your product require replacement for any reason, including normal wear and tear or breakage, please contact us.
- Do not use your device in a sauna or steam room.
- Dispose of this device, the device's battery and its package in accordance with local regulations.

- Do not check any notifications, GPS, or any functions that requires your attention while jogging or in other situations where distractions could cause injury or hazard. Always be aware of your surroundings while exercising.

Battery Warnings

- Use only the charger is used in this device. If these guidelines are not followed, batteries may experience a shortened life span or may cause fire, chemical burn, electrolyte leakage, and / or injury.
- Do NOT disassemble, modify, remanufacture, attempt to insert foreign objects into the battery, or immerse or expose to water or other liquids.
- Do NOT remove or attempt to remove the non-user-replaceable battery.
- Do NOT expose the device or batteries to fire, explosion, or other hazards.

Health Warnings

- If you have a pacemaker or other internal electronic equipment, consult your physician before using a heart rate monitor.

- The optical wrist heart rate monitor emits green light into the surrounding capillaries. Consult your doctor if you have epilepsy or are sensitive to flashing lights.
- Always consult your physician before beginning or modifying any exercise program.
- The device, accessories, heart rate monitor, and pedometer are intended for fitness and recreational purposes and not for medical purposes and are not intended to diagnose, monitor, treat, cure, or prevent any disease or condition.
- The heart rate readings are for reference only, and no responsibility is accepted for the consequence of any erroneous readings.
- While the optical wrist heart rate monitor technology is generally considered safe for most healthy users, there are inherent limitations with the technology that may cause some of the heart rate readings to be inaccurate in certain circumstances, including the user's physical characteristics, fit of the device, and type and intensity of activity.

- The smart watch relies on sensors that track your movement and heart rate. The fitness and health information provided by these devices are intended to be a close estimation of your activity and metrics. The data, such as heart rate, pedometer, calorie, sleep, sleep, distance, heart rate, and calorie data.
- If you have eczema, allergies or asthma, you may be more likely to experience skin irritation or allergies from a wearable device.

Maintenance

- Regularly clean your wrist and the smart watch, especially after sweating during exercise or being outdoors in the rain. Wipe the band and the watch with a moistened cloth and mild soap.
- Do NOT wash the watch with household cleaner, bleach, or other chemicals. Rinse thoroughly and wipe with a soft towel or rag.
- While the watch is water resistant, wearing a wet band is not good for your skin.
- If your bands get wet—for example after sweating or swimming—dry them off before putting them back on your wrist.
- Be sure your skin is dry before you put your bands back on.
- Do not bring your device into contact with any sharp objects. This could cause scratches and other damage.
- For light-colored arm bands, minimize direct contact with dark-colored clothing, as color transfer can occur.

德

Smart Watch

Bedienungsanleitung

ID215G

Vielen Dank für Ihren Einkauf, diese Anleitung handelt von der Bedienung der Smartwatch. Bitte lesen Sie die Bedienungsanleitung, bevor Sie die Smartwatch benutzt, bitte lesen Sie diese Anleitung sorgfältig durch.

Anfangen

Ladeanzeige

Was ist in diesem Dokument enthalten?

Dieses Handbuch gibt Ihnen einen schnellen Einstieg in die Bedienung Ihrer Uhr. Es ist wichtig, dass Ihre Uhr Ihre Daten mit der VeryFitPro-App synchronisieren kann, so Sie detaillierte Gesundheitsdaten und Informationen zu persönlichen Trends prüfen, den Kursverlauf protokollieren und vieles mehr. Sobald das Setup abgeschlossen ist, sollte Ihre Uhr für die Verwendung bereit sein. Der Rest der Bedienungsanleitung hilft Sie durch alle Funktionen Ihrer ID215G.

Einrichten Ihre Smartwatch

Laden Sie Ihre Smartwatch auf

Bitte laden Sie Ihre Smartwatch vor dem ersten Gebrauch vollständig auf.

1. Stecken Sie das Ladekabel in den USB-Anschluss Ihres Computers oder in ein UL zertifiziertes USB-Ladegerät.
2. Legen Sie Ihre Smartwatch in die Ladeschale und drücken Sie die Knoten, bis Sie ein Klicken hören. Die Stifte an der Ladeschale müssen mit den Ladekontakten auf der Rückseite Ihrer Uhr übereinstimmen. Der aufgeladene Prozentsatz wird auf dem Bildschirm angezeigt.

Wenn die Smartwatch anzeigt, dass die Batterie vollständig aufgeladen ist, trennen Sie das Kabel vom USB-Ladegerät oder einen Anschluss mit 5V 500 mA an. Stellen Sie sicher, dass die Kontakte am Ladekabel und Ihrer Smartwatch an der Innenseite Ihrer verbunden sind.

Entfernen Sie die Smartwatch von der Stromversorgung, sobald sie vollständig aufgeladen ist.

- USB-Ladegerät erforderlich: DC-USB-Anschluss (5V,500mA).
- Ladezeit: 2 Stunden

Demontage / Montage Ihrer Smartwatch

Demontage

1. Drehen Sie die Smartwatch um und suchen Sie den Entriegelungsknopf.
2. Während Sie den Schnellspannhaken nach innen drücken, ziehen Sie das Armband vorsichtig von der Smartwatch weg, um es zu lösen.

3. Wiederholen Sie dies auf der anderen Seite.

Montage

1. Richten Sie den Stift des zweiten Schnellspannhakens gegenüberliegende Seite) in die Kerbe der Uhr. Befestigen Sie das Armband mit der Schließe dann an der Smartwatch.

2. Drücken Sie den Schnellspannhaken nach innen und schieben Sie das andere Ende des Armbands in die richtige Position.

3. Wenn beide Enden des Stifts eingerückt sind, lassen Sie den Schnellspannhaken los.

Tragen Sie Ihre Smartwatch

Tragen Sie den ganzen Tag und trainieren

Wenn Sie nicht trainieren: Tragen Sie das Gerät horizontal am Handgelenk für den ganzen Tag, mit einer Hand breit Abstand zwischen Handgelenk und Ende Ihrer Tasch legend, genau wie Sie eine Uhr tragen würden.

Für eine optimierte Herzmessung, sollten Sie diese Tipps beachten:

1. Experimentieren Sie, indem Sie die Smartwatch mehrmals am Handgelenk tragen und Ihre Ergebnisse vergleichen. Da der Blutfluss in Ihrem Arm mit zunehmender Höhe zunimmt, können Sie das Herzfrequenzsignal verbessern, indem Sie die Smartwatch einige Zentimeter unter Ihrem Handgelenk tragen. Wenn Sie Ihren Fahrzeuglenker oder Gewichtheber Ihren das Handgelenk häufig gebeugt werden, was das Herzfrequenzsignal mit Sicherheit beeinflussen wird, sollten Sie Ihre Smartwatch lieber am Handgelenk tragen.

2. Tragen Sie Ihre Smartwatch nicht zu eng. Ein enges Band behindert den Blutfluss und beeinträchtigt die Genauigkeit der Herzfrequenzmessung. Wenn Sie trainieren möchtest sollte die Smartwatch während des Trainings etwas enger sein (eng anliegen, aber nicht einschnüren) als während des ganzen Tages.

Benutzen Ihre Smartwatch

Die Installation der App

Verwenden Sie die Smartwatch mit VeryFitPro app. Sie können VeryFitPro im Apple Store / Google Play herunterladen oder scannen Sie die folgenden QR-Code, um die App zu herunterladen.

Android

Apple

Hinweise:

- Die VeryFitPro App ist nur mit Smartphones kompatibel, nicht mit Tablets oder PCs.

Systemanforderungen für Smartphones

- iOS 9.0 & höher
- Android 4.4 & höher
- Bluetooth 4.0 & höher

Die App Seiten

Startseite

(Ziehen Sie die Seite nach rechts, um die Einstellungen mit Ihrem Handy zu synchronisieren)

Einstellungen

Gerät

Benutzer

Verbinden Sie die Smartwatch mit Handy

Bitte aktivieren Sie Bluetooth auf Ihrem Handy in der VeryFitPro-App, aber NICHT in der Bluetooth Liste des Handys.

1. Aktivieren Sie das Bluetooth Ihres Smartphones.
2. Öffnen Sie die VeryFitPro App auf Ihrem Smartphone und wählen Sie "Gerät" aus, dann wählen Sie "Gerät binden", dann starten Sie Smartphone das Suchen nach Geräten.

3. Tippen Sie auf „ID215G" in der Liste der gefundenen Geräte, sie auf Ihrem Smartphone erscheinen, um die Smartwatch mit Ihrem Smartphone zu verbinden.

Hinweis:

Wenn Ihr Handy das ID215G nicht gefunden hat, suchen Sie bitte die Smartwatch in der App erneut und halten Sie die Bildschirm Ihrer Smartwatch während dieser Zeit aktiv. Wenn Ihr Handy das ID215G bereits zuvor gefunden haben, versuchen Sie bitte, Ihre Smartwatch neu zu starten. Wenn sich viele Bluetooth-Geräte in der Nähe befinden, bewegen Sie sich in einen entfernten Bereich und versuchen Sie es erneut.

Hinweis:

- Deaktivieren Sie Bluetooth auf Ihrer App verbunden ist, schalten die Smartwatch automatisch mit dem Handy und stellt sich wieder her, wenn die Verbindung unterbrochen wird oder wenn Bluetooth nach einem Ausschalten wieder eingeschaltet.
- Wenn die Smartwatch nicht an die App gebunden ist, werden die Informationen auf der Uhr Bildschirm zurückgesetzt und die Informationen auf der App werden nicht mehr mit der Uhr synchron sein. Wenn dies nicht, wie auf dem, es liegt ein Problem vor, das einen Reset erfordert.
- Die Smartwatch kann immer nur mit einem Smartphone gleichzeitig verbunden werden. Stellen Sie sicher, dass Sie die Verbindung zu Ihrer Smartwatch und Ihr Smartphone innerhalb von 0.5 Meter Entfernung definieren.

Kennen Sie Ihre Smartwatch

Die Tastenfunktionen

- Drücken Sie Up Taste, um den Bildschirm zu einschalten, um zu scrollen oder um Ihre Bewegungsdaten zu wechseln.
  - Halten Sie Up Taste, um den Sportmodus zu starten / beenden.
- Drücken Sie Down Taste, um den Bildschirm zu entsperren.
  - Halten Sie Down Taste, um zu der Startseite zurückzukehren.
- Halten Sie Up Taste, um die Smartwatch ein-und auszuschalten.

Die Smartwatch Oberfläche

Das Bildschirm ist ein Touchscreen, berühren Sie den Bildschirm, um zu den verschiedenen Seiten zu gelangen, und die Funktion einzugehen.

Die Startseite ist die Smartuhr. Auf der Smartwatch:

- Berühren Sie nach unten, um die Benachrichtigungen zu sehen.
- Berühren Sie nach oben, um die Statusleiste zu sehen (Ton, Bluetooth, Ruhemodus, Helligkeit).
- Berühren Sie nach links, um die Funktionsschaltflächen zu wechseln (Sportmodus, Wetter, Herzfrequenzmo-itor, Sauerstoffgehalt im Blut, weitere Funktionen).
- Berühren Sie nach rechts, um die Galeriseite zu sehen (Schrittzahl, Herzfrequenzwert, Entfernung).

Wenn der Strom der Batterie weniger als 10% beträgt, wechselt die Uhr in den Batteriesparmodus, in dem Sie nur die Zeit und das Datum ansehen. Bitte laden Sie die Uhr auf um sie wieder zu bedienen.

Nachdem die Smartwatch an die App gebunden ist, zeigt der Startseite die Uhrzeit und das Datum an, wie in fig.1 dargestellt.

Sie können die Startseite wie folgt anpassen:

1. Drücken Sie Up oder Down Taste, um zu der Startseite zu gelangen.
2. Tippen Sie auf die Startseite und halten Sie es gedrückt.
3. Berühren Sie nach links / rechts, um eine auszuwählen, und tippen Sie auf Bestätigung auf.

Den Bildschirm einschalten

Drücken Sie kurz auf die Uhr über einen Standby-Modus, in dem der Bildschirm gesperrt ist. Um den Bildschirm zu entsperren, drücken Sie Up / Down Taste.

Funktion Einführung

Überprüfen Sie Ihre Nachrichten
Überprüfen Sie Ihre Anrufe und Ihre Nachrichten
Wecken Sie Ihre Smartwatch auf
Erhalten Sie Benachrichtigungen
Sie können Ihre Smartwatch zurücksetzen
Sie können Ihre Smartwatch ausschalten
Sie können Ihre Smartwatch neu starten