User Manual

Please read the user manual of this product carefully before use to ensure proper use and operation. After reading, please keep the user manual for future reference. In the case of consulting with sales and qualifications, our company reserves the right of final interpretation.

We are constantly iterating and upgrading our products, which may change different program schemes in the process. If you find any discrepancies in the information, please contact our customer service staff directly, or at follow the "THE FOURTH SPACE official account to obtain the latest product information.

Thank you for your understanding and support.

1. Product Specification

Basic Information
Product name: TH-01
Product model: Remote Control
Rated voltage: DC 3V
Net weight of product: 60g (excluding battery)
Product size: 93 × 61 × 15mm

2. Remote Control Instructions

The following content is only applicable to the remote control version. If you have any questions, please contact customer service directly.

2.1 Introduction to remote control buttons

2.2 Introduction to Remote Control Display Screen Icons

2.3 Operating instructions

- Matching connection:
  ① Insert the battery into the remote control and turn on the remote control.
  ② When the air conditioner is turned on, press and hold the ECO button on the air conditioner for 5 seconds to enter pairing mode. When — is displayed on the screen, press any key on the remote control to complete the matching.
- On/Off button: Press and hold for 1 second to turn on the air conditioner and press and hold for 2 seconds to turn off the air conditioner.
- Function button:
  Short press the function button to select cooling, dehumidification, heat. The heating function is applicable to both cold and warm models. Please contact customer service for more information.
- Fan speed button:
  Short press the MAX button once to enter MAX mode and short press again to enter AUTO mode.
  Short press the ECO button once to enter ECO-sleep mode, ECO energy-saving mode, and AUTO mode.
  Short press the ECO button once to enter ECO-sleep mode (short press twice to enter ECO energy-saving mode, short press three times to enter AUTO mode.
  The above cycles in sequence
- Timer button: Can be set to turn off the air conditioning in a fixed time within 0-12 hours. Short press to increment, long press to scroll through numbers. After completing the timer setting, press and hold the button for 2 seconds to reset the timer to zero and reset it.
  When the air conditioner, press the timer button twice in a row can directly time for 1 hour.

2.4 Introduction to remote control display screen icons

- Light on/off button: Short press the light button to turn on/off the screen and the power indicator light on the air conditioner.
- Wind speed button: Short press the wind speed button. There are a total of 6 levels of wind speed, which can be adjusted by short pressing the increase/reduce button.
- Temperature increase/reduce button: Short press the temperature increase/reduce button to adjust the temperature. The temperature setting range is: Heating function: 24~32℃, with an increase of 1℃. Cooling function: 16~30℃, with an increase of 1℃.
- Change the temperature unit:
  The default temperature unit is Celsius + ℃, press and hold the light button for 3 seconds to switch to Fahrenheit + ℉.

2.4 Other Function Description

- Screen display function:
  Press any button to turn on or off the screen. After 30 seconds of inactivity, turn off the screen display.
- Temperature and humidity display:
  The remote control is equipped with a temperature and humidity sensor, which will display the current ambient temperature and humidity on the screen. Due to changes in the actual usage environment, there may be errors. The values displayed on the screen only and cannot be used as measuring tools.
- Magnetic adsorption function:
  The remote control is equipped with a built-in magnet, which can be directly magnetically attached to any magnetic object to avoid loss.
- Power supply: Use 2 pieces LR03 AAA (1.5V) batteries.

2.5 Note:

- This remote control is not waterproof and should not be submerged in water.
- When not using the remote control for a long time, please remove the battery.
- Please replace the batteries according to the specified model and dispose of the used batteries in accordance with relevant national regulations.

- The operation of the product host button and remote control should be completely turn off the air conditioning power. If the air conditioner is not used for a long time, please unplug the power plug.

3. Warning

⚠ Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.

⚠ User: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This air conditioner is produced by Fourth Space Co., LTD.
Service hotline: 400-616-7796

360x240mm

THE FOURTH SPACE
CYBERTAKE AIR CONDITIONAN

USER MANUAL

用户使用手册

使用前请仔细阅读此说明书
Please read this manual carefully before use

用户使用手册

在使用前，请认真阅读本产品的用户手册，以保证在完全理解后正确使用。阅读后，请将用户手册妥善保管以备日后参考。在遵从法律法规的情况下，我们保留最终解释权。寻找手您的支持，我们会不断迭代创新和升级产品，过程中可能会变更不同的程序软件和设置流程，还请谅解！如您发现信息差异，还请直接与我们客服人员联系，或关注某牌空调+微信公众号，以获取最新的产品信息。

感谢您的理解与支持！

1.产品参数

基本信息

产品名称：某牌空间Cybertake户外空调专用遥控器
产品型号：Y6-01
额定电压：DC 3V
产品净重：600g（不含电池）
产品尺寸：93*61*15mm

2. 遥控器操作说明

2.1 遥控器按键介绍

2.2 遥控器显示屏图标介绍



2.3 操作说明

- **匹配连接：①遥控器装入电池，开启遥控器；**
  ②空调在开机情况下，长按空调主机ECO键 6 秒，进入配对状态。当屏幕上显示—时，再按遥控器任意键即可完成匹配。
- 开/关键：长按1秒开启空调，长按2秒关闭空调。
- 功能按键：短按功能按键，可选择制冷、除湿、送风、制热功能。
  注：制热功能仅限冷暖款，详情请咨询客服人员。
- 模式选择：在制冷功能下：
  可选择MAX模式、ECO+睡眠模式、ECO节能模式、AUTO自动模式。
  短按1次MAX按键，可进入MAX模式，再次短按，可进入AUTO自动模式。
  短按1次ECO按键，进入ECO+睡眠模式，短按2次，进入ECO节能模式，短按3次，进入AUTO自动模式。
  以上依次循环。
- 定时按键：可设定0-12小时内定时关机。短按递增，长按数字递减。
  完成定时设置后，长按2秒定时按键，定时清零。可重新设置定时；开机状态下，在原来设定定时的情况下，连续按两次定时键，直接定时1小时。
- 灯光开/关键：短按灯光键，打开/关闭空调上的屏幕与电源指示灯。
- 风速加/减键：风速一共6挡，可短按加/减键进行调节。
- 温度加/减键：可短按温度加/减键调节温度，温度设置范围为：
  制冷功能：16 ~ 28℃，间隔1℃
  制热功能：29 ~ 32℃，间隔1℃
- 温度单位切换：默认温度单位为摄氏度~℃，长按3秒灯光按键，可切换为华氏度~℉。

2.4 其他功能说明

- 屏显功能：
  在开机或关机状态下，按下任一按键，点亮屏幕。持续30秒无任何操作后，关闭屏显。
- 温湿度显示：
  遥控器内置温湿度传感器，屏幕上会显示对应的室内温度与湿度。因实际使用环境的变化可能会有误差，数值仅供参考，不可作为计量工具使用。
- 磁吸固定功能：
  遥控器内内置磁铁，可直接磁吸在任一磁性物体上，避免遗失。
- 供电方式：2节7号碱性电池，LR03 AAA (1.5V)。



2.5 注意事项

- 本遥控器不防水，不可接没在水中。
- 长期不使用遥控器时，请取出电池。
- 请按规定型号电池进行更换，并必须照国家相关规定处置用完的电池。
- 产品主机按键和遥控器操作关机，不能使空调电源完全关闭，如长时间不使用空调，请拔掉电源插头。

本空调由 某牌空间（深圳）创新科技有限公司 出品
服务电话：400-616-7796