Apolosign

PackGo

Briefcase Smart Screen

USER GUIDE

Please read the manual before using this product, and store it for future use.

Catalogue

Preface.....2
Warning.....2
Packing List.....3
Product Specifications.....4
Product usage method.....5
Port connection instructions.....6
Key Description.....6
Touch Function Description.....7
Instructions for built-in battery.....7
Projection.....8
Download application software.....8
Instructions for using the remote control.....9

Preface

Thank you for choosing a portable smart screen!
This manual provides detailed guidance for user manual to understand the usage methods and precautions of this product.

Warning ⚠

- The device can only use the power AC cable accessories provided by the original factory. Using other power sockets or the machine are used for ventilation and heat dissipation. Do not block or cover gap these gaps and openings.
- Do not use or store the machine in dusty, humid, or high-temperature environments. When the female machine malfunctions, please do not disassemble and repair it yourself. Please contact the manufacturer for repair or replace to restore the issue dissipation. Do not block or cover up these gaps and openings.
- Avoid stepping on the AC power cord to avoid potential hazards such as electric leakage caused by the damage. If the wire of the power AC line is damaged, do not continue to use it, otherwise danger may be caused.
- In thunderstorm weather or when not using this device for a long time, please unplug the power plug.
- When using, please do not place the machine on the edge of the table or in areas that are easily disturbed by vibrations to avoid machine damage or injuries.
- During transportation, please do not forcefully squeeze the display screen. Do not use sharp tools or hard objects to damage the display screen, as this may cause damage to the display screen.
- Please use a dry soft cloth or a soft cloth slightly dipped in a flexible cleaning agent to clean the machine. Do not use any type of solvent, such as alcohol Or gasoline, otherwise it may damage the surface treatment layer.
- It is important to make children aware of the dangers of climbing this product, as falling or tripping it over can cause serious personal injury.
  Women should take precautions in pregnancy or lifted positions.
- Be sure to hits up the camera connected to the product in a timely manner to avoid tripping, puffing, or grabbing them.

Packing List

After opening the packaging, please confirm the packaging content below.

Displayer

Power Insert

Type-C Insert

User Manual×1

Bluetooth remote controller

Product Specifications

Different models have different configurations.

Specifications	System	RK3588 Eight-Core
	CPU	2.4GHz
	Memory	128GB
	Operation system	Android 12
	Panel Size	27.5CM
	Resolution	1920*1080
	Number of points	10-Point
	Aspect Ratio	16:9
Interface	Wi-Fi	802.11b/g/n/ac/ax 2M Wi-Fi 6
	BT	Bluetooth 5.2
	DP IN	Charging module、DP Signal
	AC Power input	Input Voltage AC100V ~ 240V
	Power switch	Control the motherboard battery switch
	Type-c	2Output Display+Data Transmission
	USB	USB Host1
	HDMI IN	1920*1080@60HZ
	VESA	100x100mm
	Key	Power/Function/Volume
	Gravity Sensor	Screen rotation
Other	Fold switch	Close the top cover to sleep, open the top cover to automatically turn on(wake up) the screen. Support the top cover mounting to forward and backward
	Speaker	4Ω 10Watt
	Microphone	Built in 4 microphones, supporting noise reduction and echo cancellation
	Battery pack capacity	14.4V / 6800mAh
	Storage temperature	-20 ~ +60℃
	Operation temperature	-15℃ ~ 60℃ 10~90%RH

Product usage method

1.Place the product on a flat surface, resting passively.

2.Connect the power cord for first use, the power indicator light will turn on and cover on the back of the product.

3.Unlock the front latch of the product and open the upper cover of the product.

4.Please lift the display screen upwards, with the screen being forced ↑

5.Please pull the display screen upwards as much as possible and then press it downwards (Cannot rotate counterclockwise).

6.Please open the groove located at the bottom of the product with eight fixed ※ screws with accessories such as power AC cables manually.

7.Open the port cover location on the left side of the product and check the battery switch button When the battery switch is in the off direction, it can connect to the power AC cable to charge the device. When the power AC cable is connected, the power indicator light will turn on. As the battery level increases, the power indicator light will turn green from red.

8.When the display screen upwards, with the screen being forced ↑

9.Please pull the display screen upwards as much as possible and then press it downwards (Cannot rotate counterclockwise).



10.Please open the groove located at the bottom of the product with eight fixed ※ screws with accessories such as power AC cables manually.

Battery level	Indicator light
0%-20%	Red
20%-40%	Red and Yellow
40%-60%	Yellow
60%-80%	Yellow and Green
80%-100%	Green

Battery level	Indicator light
0%-20%	Red flashing
20%-40%	Red and Yellow flashing
40%-60%	Yellow flashing
60%-80%	Yellow and Green flashing
80%-100%	Green flashing

Port connection instructions

Port interfaces, supporting multiple external device connections.

USB DP IN Type-C

HDMI IN 1 Used to connect external high-definition video signal inputs.
USB 1 Can be used with USB storage device or for mouse and keyboard receiver.
DP IN 1 Multi functional interface: 1. supports PD fast charging protocol, with adaptive voltage and current of 5V9V12V15V20V.
Maximum 100W.
2. Supports DP screen mirroring and screen control mode protocol.
Remarks: Switch game consoles via TYPE-C cable cannot be used.

Type-c 1 Connect Type-C docking station, which can be connected to USB drives, mice, etc.

Key Description

Please use the standard AC power cord.

Button	Function
⏻	When pressed in the ⏻ direction: Power off status of the entire machine: Short press for 1 second to turn on the device. When in shutdown state: Press for 2.5 seconds to turn on the device. When turned on: ① Press 2.5 seconds to enter shutdown confirmation interface. ② Short press to enter screen rest mode, then short press again to release screen rest
☀	Adjusting the system's brightness to increase
☾	Adjusting the system volume to decrease

⚠ While inserting the power cord plug into the wall to supply power to the box, please ensure that the power cord does not cause the risk of electric leakage caused by forceful pulling or damaging the power cord.

Touch Function Description

Adopting IPS full HD ten point capacitive touch LCD display screen.
To keep the screen clean, please make sure it is clean.

Instructions for built-in battery

This product size is equipped with a built-in power supply board and rechargeable battery. The battery switch button is located on the left side of the product. When the battery switch button is in the off direction, it can connect to the power AC cable to charge the device. When the power AC cable is connected, the power indicator light will turn red. As the battery level increases, the power indicator light will turn green from red.

Battery level	Indicator light
0%-20%	Red
20%-40%	Red and Yellow
40%-60%	Yellow
60%-80%	Yellow and Green
80%-100%	Green

Battery level	Indicator light
0%-20%	Red flashing
20%-40%	Red and Yellow flashing
40%-60%	Yellow flashing
60%-80%	Yellow and Green flashing
80%-100%	Green flashing

⚠ **Pay attention to:**
When the battery is exposed to the microwave, the battery life will decay to a certain extent, which is a normal phenomenon.
To extend the battery life, it is recommended to charge the battery after using it for a period of time (when the battery is in the off direction, it can be charged).
Do not keep the battery fully charged and do not charge it in extreme environments.
※ The standard usage time in the manual is based on the laboratory test data of our company, and the actual time may vary depending on the usage conditions.

Projection

Wireless screen mirroring, supporting multiple protocols: Apple AirPlay, Miracast, Google Chromecast.
Android phone: Phone and device are on the same network: ①Phone enters the shortcut menu: ②Click "screen cast" ③Select the screen to be projected.
Device Name: ①Phone screen appears on the device, successful screen mirroring.
Windows: Computer and device are on the same network: ①Windows enters Settings.
②System ③Screen ④Multiple displays ⑤Click.
"Connect to wireless display" ⑥Select the name of the device being projected. ⑦The device appears on the screen, and the projection is successful.
Mac: Computer and device are on the same network: ①Mac enters preference settings.
②Display ③Add display ④Select the screen projection setting.
Backup Name: ⑤The device appears on the screen, and the screen mirroring is successful.
Audio and video push: The projection device and the device are on the same network: ①The projection device enters the video APP ②Select the video ③Click on the video

Download application software

Overseas: Enter the "Google Play Store" on the device, log in to the Google account, select the downloadable applications and then install successfully.
Domestic: Enter the "App Store" on the device, select the downloaded application, and then install it successfully.

Instructions for using the remote control

1. Click the Settings button in the upper right corner ⚙ of the main page.
2. Click "Remote Controller".
3. Click the pairing button.
4. Simultaneously press and hold the left and right function buttons on the remote control, and release it after the indicator light on the remote control keeps flashing.
5. Under (Available Devices), a new connected device Remote Controller appears, select Remote Controller. Pairing devices.
6. The interface will display a pairing inquiry. Click on pairing and the remote control will be set successfully.

Attention: Due to safety regulations, the remote control is not equipped with batteries by default. Please purchase two No. 5 batteries yourself.

The remote control for Android smart set-top boxes is only suitable for the following applications:
1. Twitch and these video brushing: press up and down on the remote control to switch between video brushing (you can't drag it to comment on the remote control).
2. Manga TV, Cool Movie Video, TV Home: Suitable for all situations.

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference
(2) This device must accept any interference received, including interference that may cause undesired operation.
Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device,pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:
This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provided with antenna installation instructions and transmitter operating conditions for satisfying RF exposure compliance.
The device has been evaluated to meet general RF exposure requirement. The device can be used inportable exposure condition without restriction.

The device complies with parts of the FCC rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interfere mothat may cause undesired operation

The product complies with the essential requirements of European safety regulations and has passed the product safety conformity assessment procedure. It also has a manufacturer's declaration of conformity to ensure that every product delivered to the customer is safe.

SIZE:100x150MM 材质：128G铜版纸4色印刷