Date: 20 08 2024
Product: SP-01003 IM

SP-1003 IM
Size: 195(w) x 200(h) mm

书纸材质 双面印刷

Disney Stitch

Elvis Stitch LED Karaoke Microphone

Instruction Manual

Thank you for purchasing the Elvis Stitch LED Karaoke Microphone.
This manual provides more information about this LED Karaoke Microphone, please read the instructions before using.

©Disney
www.disney.com

Elvis Presley™
© 2025 ABG EPE IP LLC

Product Overview

Front

Back

Bottom



Package Contents

1(One) Elvis Stitch LED Karaoke Microphone
3in. x 3.5in. x 10.5in. (7.5cm x 8.9cm x 26.7cm)
1(One) USB Type-C Charging Cable 19.7in. (50cm)
1(One) Instruction Manual

Power On/Off

Power on
Press and hold the Power Button.

Power off
Press and hold the Power Button.

Note: Always power off the karaoke microphone when not in use.

Pair Wireless Microphone Speaker with your mobile device

1. Keep the distance between your wireless microphone speaker and mobile phone (or other devices) within 32.8 feet.
2. Power on the wireless microphone speaker.
3. Activate the Bluetooth function on your phone within range and select "SP-1003-ELVIS-STITCH" from the list shown.
4. You will hear a beep sound when pairing is successful.

Reconnect Wireless Microphone Speaker to your mobile device

When powered on, the wireless karaoke microphone will automatically connect with the last successfully paired device.

Technical Specification

Driver Diameter : 52 mm
Impedance : 4 Ohms
Playing Time : 2.5 - 3 Hours
Charging Time : 2 - 2.5 Hours

Power Supply : Li-Ion Battery 3.7V 600 mAh
Bluetooth Range : 32.8 feet
Bluetooth Version : 5.3
USB-Type-C Charging Cable Included

How to use

Playing Music and Singing
1. Switch on your microphone
2. Connect the microphone to any audio device by Bluetooth in order to listen to music.
3. Play your music track and adjust volume by your audio device or speaker volume button.

FM Radio
1. Plug-in the USB Type-C charging cable as FM antenna.
2. Short press Power button to switch between Bluetooth Speaker and FM Radio.
3. Short press Play button to auto scan FM channels.
4. Long press Prev or Next button to switch channels.
5. Short press Speaker Volume button to adjust the volume.

Charging Your Wireless Microphone Speaker

⚠ For your safety, please always use appropriate 5V output charger/Adapter to charge the product. **DO NOT USE** Quick Charging USB Adapter to charge the product, as it might damage the product.

1. Use the USB Type-C charging cable provided with this Wireless Microphone Speaker.
2. Connect the USB Type-C plug to USB Type-C charging port on the microphone, then connect the USB plug to a USB port on a wall adapter to begin charging.
3. The LED Indicator will turn red while charging and will turn off once fully charged.

NOTE:
- You must select a qualified charger from a regular manufacturer.
- You must charge the Wireless Microphone Speaker if it has been not used for more than 6 months.

USB Type-C Charging Cable rating 5V/1A Max.

⚠ **CAUTION:** The USB Type-C charging cable included with this item is intended for use with this product. Only use the included USB Type-C charging cable to charge this product.

FAQ

- **If the wireless karaoke microphone cannot be paired with your device, please try the following:**
  Ensure that your microphone is in pairing mode or reconnection mode.
  Ensure that Bluetooth search function of your mobile device is activated.

- **If the wireless karaoke microphone cannot be recharged:**
  If you use a power outlet, ensure that the power supply is connected securely and the outlet works.

⚠ Safety instructions for the lithium battery and charging the product

-The input voltage to the product is DC 5V 1A.

-In order to charge the product in safe manner and reliable conditions, please only adopt certified appropriate charger/ adapter for charging the product.

-Only charge the product at ambient temperatures between 10 °C/ 50 °F and 40 °C/ 104 °F.

-Do not heat above 70 °C/158 °F, eg. Do not expose to sunlight or throw into fire.

-Switch off the product after use.

-Please note that we won't take any responsibility for any wrong operation (eg. Voltage higher than 5V) as this may result in severe injury or loss of property, and we cannot control the operating process during the time the user using this product.

-In extreme cases, abuse or misuse of Lithium battery pack can lead to explosion, heat generation, fire development or smoke development.

FCC Statement

This device complies with the part 15 of the FCC rules. Operation is subject to the following two conditions:(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with instructions may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on. The user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or experienced radio/ TV technician for help.

RF warning statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC ID: 2ADM5-SP-1003V3

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by 1616 Holdings, Inc. is under license. Other trademarks and trade names are those of their respective owners.

Keep All Relevant Information For Future Reference

Made in China
ITEM# SP-1003-ELVIS-STITCH