C3

## BONE CONDUCTION HEADPHONES

USER MANUAL

Package List

Bone Conduction Headphone

Earplug

Charging cable

User Manual

Packing Contents:

Bone Conduction Headphone x 1
Earplug x 2
Type-C Charging Cable x 1
User Manual x 1

Tips: If you have a problem that is not mentioned in the user manual, please check the product description on Amazon (FAQ at the product listing bottom), or contact our store customer service team through the Amazo platform, we will reply within 24 hours.

Product Overview

1. USB C Charging Port
2. Volume +/Power Button
3. Volume - Button
4. L/R Marking
5. LED Indicator Light
6. Microphone
7. Vibration Area

How to Wear

As shown below, wrap the headphone around the back of your head, then hook it over your ears, instead of putting it in the ear.

If you don't want to be disturbed by external sounds when using the headphone, that can be done if you use the earplugs with it. The usage method is as follows:


Pairing

❶ Press and hold the "+" button on the side of the headphone for 3 seconds to power on, and you will hear a voice prompt "Power On"; "Pairing". The indicator flashes blue-red to wait to pair.

❷ Turn on the Bluetooth of your phone to search and click the "C3", headphone will connect with your phone, and you will hear a voice prompt "Connected" while pairing successfully.

NOTE:

* After it is disconnected from the phone, the headphone will automatically enter the pairing state and auto power off after 5 minutes.

* If there is a pairing record, it will automatically reconnect to the last connected device when power on next time.

Power On

Press and hold the "+" button on the side of the headphone for 3 seconds, and you will hear a voice prompt "Power On". The blue indicator light flashes 3 times.

Press and hold for 3s

Power Off

Press and hold the "+" button on the side of the headphone for 5 seconds, and you will hear a voice prompt "Power Off". The red indicator light flashes 3 times.

Press and hold for 5s

Phone Calls Control

Answer/Hangup Calls:
Press once the "+" button on the side of the headphone.

Press once

Reject Calls:
Press twice the "+" button on the side of the headphone.

Press twice

Music & Activate "Siri"

Play/Pause:
Press once the "+" button on the side of the headphone.

Press once

Volume Up:
Press twice the "+" button to increase the volume.

Press twice

Volume Down:
Press twice the "-" button to decrease the volume.

Press twice

Previous Track:
Press Triple the "+" button on the side of the headphone.

Press three times

Next Track:
Press Triple the "-" button on the side of the headphone.

Press three times

Activate "Siri"
Press and hold the "-" button on the side of the headphone for 2 seconds.

Press and hold for 2s

Resetting

1. In the state of power on, press "+" button on the side of the headphone four times, and you hear a voice prompt "Di, Power off".

Tips:
When the earphones are already connected to the device, you hear a voice prompt "Di, Disconnect, Power off".

2. Delete "C3" record on your phone and deactivate the bluetooth setting.

3. After 10 seconds, Press and hold the "+" button on the side of the headphone for 3 seconds to power on, and you will hear a voice prompt "Power On"; "Pairing". The indicator flashes blue-red to wait to pair.

4. Turn on the phone's bluetooth to search "C3" and pair.

Charging

Use the Type-C charging cable (provided) to connect your computer(with power on) or an adapter(not provided) to the headphone. The indicator will stay red when charging and stay blue after fully charging. (About 1.5 hours for fully charged)

Charging Port

USB external power supply

Note:

The power level down to 3.1V starts to alarm, there will be a voice prompt " battery low", and the earphone will automatically shut down when the power drops to 3.0V.

Specification

Model	C3
Version	V5.3
Supporting Protocols	A2DP\AVCTP\AVDTP\AVRCP\HFP\SPP\HID
Transmission Distance	10m/33 feet (without obstacles)
Battery Capacity	3.7V/180mAh
Charging Time	About 1.5 Hours
Talk/Music Time	About 10 Hours
Standby Time (BT connected)	About 45 Hours
Standby Time (Power Off)	About 300 Hours
Charging port	Type-C
Dimensions of item	125*100*40mm
Weight of item	About 23g

FAQs List

① The headphone cannot be turned on.

* The headphone battery is too low, please charge the earphone in time.

② Headphones can't connect with device.

* Check whether the connected device supports Bluetooth, download or update the Bluetooth driver of the connected device.
* The Bluetooth is disabled. Enable the Bluetooth feature on your Bluetooth device, and start the Bluetooth function of the Bluetooth device before turning on the headset.
* Resetting the headphone.

③ The headset pairing name cannot be found in the device list.

* The headset may have automatically connected to the last connected device. Please turn off the connected device or move it out of range.
* Resetting the headphone.

④ The audio quality is poor and static noise can be heard.

* The headphones and the device exceed the effective distance, reduce the distance between your headphones and device, or remove obstacles between them.
* Make sure the earphone has enough power, if the power is too low Please charge your headphones.
* When the product is used in an environment with electromagnetic fields or radiation, the connection may be disturbed.

Safety Instruction

* Do not expose the headphone to a very high or low temperature, such as exposing it to sunlight for a long time.
* Do not use caustic cleaners to clean this product.
* Do not dispose of this product in the fire to avoid an explosion.
* Do not immerse the product in liquids and do not touch the charging port with wet hands.
* Do not make any alterations to this product, we do not guarantee performance if it is modified by people.
* Keep the product away from fire and heat sources.
* Built-in lithium-ion battery, keeps the headphone away from children and pets.
* To protect your ears, please adjust to an appropriate volume when using headphones.
* If you feel sick while using this product, please stop using it immediately.

Kind Tips

1. If you don't use this product for a long time, please store it in a dry environment, and avoid extreme temperature and dust. Charge the headphones at least once a month to prolong life.
2. Clean the headphones with a soft, dry cloth after use.
3. Listening to loud music for a long time may cause discomfort, Please give your ears a rest by taking them off every few hours.
4. This headphone is water resistant, but not completely waterproof. It can't be placed in water for a long time and cannot be used for diving.
5. If you have any questions while using the product, you can contact us via Amazon mail, it will be our pleasure to support you.

Warning:

This device complies with Part 15 of the FCC Rules.Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.These limits are designed to provide reasonable protection against harmful interference in a residential installation.This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.

NOTE: This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

THANK YOU