D3X Quick Start Manual

Product Overview

Important Reminder:
Before installing the headset, please connect your mobile phone according to the quick manual guide to test the sound effect and volume.
If there is a big difference in sound effect and volume after installing into the helmet, please adjust the position of the speaker inside the helmet.

Power on/off

Double-click to switch language broadcasts (Disconnect wireless)



Press and hold for 3 seconds to turn on/off

Power on/off tone

LED light breathing

Wireless connection



Wireless not connected
Blue light blinks fast

Wireless mode tone



Wireless connection
Blue light flashing slowly

Music Sharing Pairing

Short press to toggle into music sharing mode



Music sharing mode tone

After both devices are powered on, both short press the mode button to switch into music sharing mode, in music sharing mode, double press the mode button to switch between music sharing transmit and music sharing receive mode

Music sharing pairing transmitter: blue light flashes fast;
Music sharing pairing receiver: Blue light blinking slowly

Music Sharing Transmitter pairing success: blue light flashes fast;
Successful pairing of music sharing receiver: blue light long on

Telephone function

Double click to switch manual/ automatic answer (Disconnect wireless connection)

Automation (after 15 seconds)

(Incoming call)

Answer the phone

Manual answer "short press"

(Incoming call)

Answer the phone

Long press 2 seconds

(Incoming call)

Cancel a call

"Short press" during a call

(On the phone)

Hang up the phone

Double click

Redial the last number

Short press

(Making a phone call)

Cancel a call

Music function

Short press

(while music is paused)

Play

Short press

(while music is playing)

Pause

Volume down button

(while music is playing) short press"Volume down button"

Volume up button

(while music is playing) short press"Volume up button"

Short press previous song

Long press volume down



Short press next song

Long press Volume up

Voice assistant



Voice assistant button
(under successful wireless connection)

Short press
(short press again to exit the voice assistant)

Wake Up AI Voice Assistants

Pairing Reset

Press simultaneously for 5 seconds

Volume - button
Volume + button



Introduction to wireless intercom connection operation (half-duplex intercom and music sharing are turned off by default every time you turn on the power)
I: Speech half-duplex mode (unlimited number of people within effective distance).After the two machines are turned on, all short press the mode key to switch to half-duplex walkie-talkie speech receiving mode, when one of them needs to speak, press and hold the speech key without letting go, that is, enter the half-duplex walkie-talkie speech transmitting mode, after the connection is successful, you can speak, let go and exit to the half-duplex walkie-talkie speech receiving mode: when the other one needs to speak, press and hold the speech key without letting go, that is, you can speak, let go and exit, and so on, and so on, repeat the operation. Repeat the operation to realize half-duplex speech. (Half-duplex transmitter is connected successfully or not without any prompts, only the successful connection of the receiver will have an indicator light and electronic tone prompts)
II: Clear intercom pairing and restore factory settings.Power on without connecting wireless and intercom, press and hold the volume down and volume up buttons at the same time for 5S, after the indicator light blinks fast, it will restore the factory settings and clear all the pairing information.
III: Music sharing (unlimited number of people within effective distance).After the two devices are switched on, press the mode button briefly to switch to music sharing transmitter mode or music-sharing receiver mode, accompanied by a prompt "Music Sharing Transmittinge mode" or "Music Sharing Receiving mode".Connect the device with wirelessly of mobile phone and play music, one device is in music sharing transmitting mode.Another device is in music sharing receiving mode. After the other devices receive the signal successfully, there will be a "Music Sharing Connection Successful" prompt, which means the music sharing is successful.Please note that there will not be a successful connection prompt on the transmitting side of music sharing; if both devices are connected to play music wirelessly, only the device in music sharing transmitting mode can share.
IV: Prioritization of telephone calls.After powering on the machine, the machine is connected to the wireless, no matter which mode the machine is in, when the machine calls or goes to the phone, it will be prioritized to automatically enter the phone mode, and hang up to restore the corresponding mode.

Half-duplex intercom



Mode button (Wireless【power on default wireless mode】/ Half-duplex intercom mode / music sharing mode)

Short press to toggle half-duplex voice mode

In speech mode

Press and hold this button to speak, and release it to exit the speech state.

Connection conditions: the machines need the same model to be paired, unlimited number of people within the effective distance.
Connection: After the two machines are turned on, press the mode key to switch to half-duplex speech mode, when one of them needs to speak, press and hold the speech key without letting go, it can speak, let go and exit; when the other one needs to speak, the same operation can realize half-duplex speech.
When speaking in half-duplex: only one can be allowed to enter the speaking state, and none of the others can be in the speaking state.

Product List

D3X Device*1



Speakers & Microphone*1



Clip on Base*1

Velcro Package*1

Type-C Charging Cable*1



User Manual *1

Caveat

1. To avoid explosion,please do not put the product into the flame;
2. Please do not disassemble the product to avoid damage to the electronic components of the product;
3. Please keep away from sharp objects to avoid damage to the product,;
4. Please keep in a dry place if not used for long time;
5. Before using the wireless device, please fully charge it;
6. If the red light does not come on while charging, it may be the voltage is too low;
7. To extend the life of the built-in lithium polymer battery, please charge the device at least once a month.

Instruction warning

NOTE: This product has been tested, meet the restrictions of Class B digital device, pursuant to part 15 of the FCC Rules.
These limits aredesigned to provide reasonable protection against harmful interference in a residential installation.
This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception,
which can be determined by turning the equipment off and on,
the user is encouraged to try to correct the interference by one or more of the following measures.

-Reorient or relocate the receiving antenna.
-Increase the separation between the device and receiver.
-Connect the device into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the device.
This device complies with Part15 of the FCC Rules. The operation needs to fulfil the following two conditions.
(1)This device may not cause harmful interference.
(2)This device must accept any interference received, including interference that may cause undesired operation.