修改区域	描述	日期	担当
1	XXXXXXXXXXXXXXXXXXXXXXXXXXXX	XXXXXXXX	XXXXXX

封面

Lifestyle advanced

Bluetooth

HIGH DEFINITION
SOUNDBAR
WITH COLOR CHANGING LED LIGHT

User Manual

1

2

Important Safety Instructions

⚠WARNING: To reduce the risk of electric shock, do not dismantle the product and do not expose the product to rain or moisture.No user-serviceable parts inside. Refer servicing to qualified personnel only.

1.**Read the user manual before use**. Keep all instructions for future reference
2.Always operate the product from a power source of the same voltage, frequency and rating as indicated on the rating label.
3. This product is intended for indoor,household use only.
4.To protect against electric shock: do not immerse unit,plug or cord in water or spray with liquids; do not place unit on windowsills or other places where it may be exposed to dripping or splashing of water; do not place vases or similar objects filled with liquids near the unit.
5.Do not use this product in the immediate vicinity of water such as bathtubs, washbowls, swimming pools etc. where the likelihood of immersion or splashing occur.
6.Keep the unit away from heat sources like radiators, heat registers, stoves or other products that produce heat. No open flame sources like candles should be placed on the unit.
7.Use only with attachments/accessories specified by the manufacturer.Use of attachments/accessories not recommended can be hazardous.
8.This appliance is not intended for use by persons (including children) with reduced physical,sensory or mental capabilities,or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
9.This product is not a toy!Children should be supervised to ensure that they do not play with the appliance.
10.Do not cover the unit during use. Do not impede ventilation by covering ventilation openings with cloths, curtains or similar items.
11.Do not operate the product with a damaged cord or plug or if the product malfunctions, or is dropped or damaged in any manner.
12. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid hazard.
13.For safety reasons, do not remove any covers or attempt to access the inside of the product.
14.Do not clean the unit with any harsh chemicals as this might damage the finish, Wipe clean with a dry cloth.
15. When removing the power plug from the wall outlet, always pull directly on the plug;never pull on the cord.
16.Do not expose the batteries to excessive heat, direct sunlight, fire or similar.
17.Do not throw used batteries in your household rubbish.Dispose of it responsibly according to local regulations.

3

Front/Back panels

FRONT



1. ☀
Press ☀ to switch the LED lighting mode.

2. VOL– / ⏮
Volume down (long press)/Previous (short press).

3. ⏯
Pause/Play
In Bluetooth mode, long press to disconnect Bluetooth;
In FM mode, long press to search for FM channels automatically.

4. VOL+ / ⏭
Volume up (long press)/Next (short press).

5. ⏻ / MODE
Power On/Off (long press);
Mode (USB, TF, AUX, FM Radio)(short press).

4

Front/Back panels

BACK



1. DC 5V
DC 5V ⎓ 1A(Charging Port).

2. Indicator light for charging
Red: charging
Red light off: full charged

3. AUX Port
Audio input.

4. TF (Micro SD Card)
Port for TF keys (32 GB maximum).

5. USB Flash Drive
Port for USB keys (32 GB maximum).

6. Indicator light for Playing

5

Quick Start Guide

In your phone's Bluetooth' settings select: "**LIFESTYLE ADVANCED LED SOUNDBAR**" to pair

Bluetooth Mode:

1.On the Soundbar, press the "MODE" button repeatedly until Bluetooth Mode is selected.

2.On your Bluetooth-enabled device, power on Bluetooth to search for the device. Select"LIFESTYLE ADVANCED LED SOUNDBAR".

3.Now you can play music from your Bluetooth-enabled device on the sound bar.

Aux Input

Press Power/Mode key on the panel of the soundbar to select AUX mode and use AUX cable to connect the soundbar to the audio equipment.

Indicator light for Playing

In the mode of Bluetooth, quick flash for Bluetooth pairing, slow flash for playing and solid blue for pause;
In the mode of USB and TF, slow flash for playing, solid blue for pause and intermittent flash for single song playback;
In the mode of AUX, solid blue for playing;
In the mode of FM, quick flash for searching for FM channels and solid for playing.

FM Radio

Plug in the AUX Cable as an antenna before searching for radio channels.
Press the mode button till you are prompted to FM. ***Short press*** the play button to mute, and ***long press*** the play button to automatically search for radio channels.

6

Connection schematic

RECOMMENDED PLACEMENT



Soundbar: Under the TV(if wall-mounted)/in front of the TV

Speaker Specification

Soundbar Rated Power	10W+10W (20W Total)
Input Voltage	5V ⎓ 1A
Power consumption	20W
Battery	3.7V 2400mA
Input signal source	AUX, USB, TF, BT, FM
Dimensions for sound bar	600*70*75mm
ACCESSORIES:	AUX Cable, Type-C Cable

RMJ Group International declares that radio equipment **LASB-3300BLK** is in compliance with directive 2014/53/EU.
The EU Declaration of conformity is available at:
www.rmjgroup.com/docs

RMJ Group International LLC, Brooklyn, NY 11223

RoHS Made in China

封底

FCC Warning

15.19 Labeling requirements.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
15.21 Information to user.
Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
15.105 Information to the user.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.
FCC RF Radiation Exposure Statement:
1.This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
2.This equipment complies with RF radiation exposure limits set forth for an uncontrolled environment.
This equipment should be installed and operated with minimum distance 5mm between the radiator and your body.

骑马钉册子 成品尺寸：140*210MM 105g铜版纸 单黑印刷

广东万圣科技有限公司 GUANGDONG WANSHENG SCIENCE AND TECHNOLOGY CO.,LTD			订单编号：			
			料号：			
设计：	吴梓鹏	2024/11/25	文件编号：			
业务：			名称：	LASB-3300BLK 说明书 RJ 美国		
电子：			审核：			页次：1/1
结构：			核准：			版次：1.0