
ROAM II RECEIVER EXI-202-A2
Do not place components within dot line.
Note: Used in Assembly 600-000011-000
SIZE
DRAWN:
ENGR:
DRAWING NUMBER
911-000008-000
REV.
1.00
FILE
202r100.DBF
SCALE:
DATE:
06-OCT-99
SHEET 1 OF 1