Polaroid

7" Tablet

Quick Start Guide
Model : Q7

In the box



Quick Start Guide

AC Adaptor

USB Cable

Buttons, ports & hardware



1. Micro USB port
2. HDMI
3. Reset
4. Headphone Jack
5. Micro SD
6. Front Camera
7. ⏻ Power
8. Volume
9. Rear Camera
10. Speaker

Google Play™

Google Play enables you to store up to 20,000 songs for free and buy millions of new songs. It's home to 1,000,000 Android™ apps and games. It houses the world's largest selection of eBooks. It's where you can rent thousands of movies including new releases and HD titles. It's how you buy and experience digital entertainment on your Android device and any web browser on any computer.

To take advantage of these features please login or set up a Google™ account, this can be done in the setup wizard the first time you power on the tablet.

Play Store

Charging the tablet

Charging the battery:

Connect the tablet to a wall outlet using the included AC adaptor and USB cable as shown below.



Power ON / OFF

Turning on the tablet

Press and hold the ⏻ button until the startup screen appears.

Power off the tablet

Press & hold the ⏻ button until the "Power off" options appear.

Startup screen

Lock the tablet (standby)

Briefly press the ⏻ button, (Lock the tablet to conserve the battery).

Unlock the tablet

Briefly press the ⏻ button, and slide the "Lock icon" to the right.

Lock icon

Lock screen

Connecting

Wi-Fi and Bluetooth®

To setup Wi-Fi or connect the tablet to a Bluetooth enabled device, slide down on the top right of the home screen as shown below.



Quick Settings

Home screen



Apps screen

Widgets

To add a widget, press and hold anywhere on the home screen. Select the Widgets option as shown below.

Press and hold Widgets to place them on the Home screen.

Micro SD card

Inserting a Micro SD card

The tablet supports Micro SD cards up to 32GB (not included).

To install a Micro SD card into the tablet, gently slide the card into the slot as shown below until it is firmly inserted.



HDMI®

You can connect the tablet to an HD display with a Mini HDMI to HDMI cable (not included).

To connect:

1. Connect the Mini end of the HDMI cable to the "HDMI" port of the tablet.
2. Connect the other end of the HDMI cable to the "HDMI port" of the TV or display.
3. The tablet display is now shown on your TV or display.



Legal information

FCC Part 15:

This device has been tested and found to comply with the requirements for a Class B digital device under Part 15 of the Federal Communications Commission (FCC) rules. These requirements are intended to provide reasonable protection against harmful interference in a residential area. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Do not attempt to repair or modify this equipment.

Warning: Changes or modifications to the equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

"This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation."

Shielded USB cable must be used with this unit to ensure compliance with the Class B FCC limits.

PLB IP Holdings, LLC, its licensees and affiliates, fully support all electronic waste initiatives, as responsible stewards of the environment, and to avoid violating installation laws, you should properly dispose of this product in compliance with all applicable regulations, directives or other governments in the area where you reside. Please check with local authorities or the retailer where you purchased this product to determine if/location where you can appropriately dispose of the product.

You may also go to www.plbipr.com and reference **Serial Responsibility** www.plbipr.com/serial-responsibility.aspx to learn more about the specific laws in your area and to develop a disposal habit that's kind to your home.

If your electronic device has internal memory on which personal or other confidential data may be stored, you should take steps to remove personal or other confidential data before disposal. To ensure that another party cannot access your personal data, Data sanitization varies by the type of product and its software, and you may want to research the best sanitization process for your device before disposal. You may also check with your local recycling facility to determine their data sanitization procedures during the recycling process.

Polaroid, Polaroid & Pixel, Polaroid Dolly Spectrum and Polaroid Classic Border Logo are trademarks of PLB IP Holdings, LLC, used under license. All other trademarks are the property of the respective owners. Polaroid Consumer Electronics, LLC, Polaroid Mobile, LLC, PLB IP Holdings, LLC does not manufacture this product or provide any Manufacturer's Warranty or support.

© 2014 All Rights Reserved

www.plbipr.com

Android, Google, Google Play and other marks are trademarks of Google Inc.

The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc.

All other trademarks and trade names are those of their respective owners.

Limited warranty

LIMITED WARRANTY TO ORIGINAL CONSUMER

This Product including any accessories included in the original packaging(as supplied and distributed new by an authorized retailer is warranted to PLB Inc. (PLB) to the original consumer purchaser against defects in materials and workmanship ("Warranty") as follows:

Product Type: Tablet PC **Parts Warranty:** 1 Year
Territory: United States / Canada **Labor Warranty:** 1 Year

To obtain Warranty Service and Troubleshooting Information

1) Visit our website at: **www.soundsentertainment.com** Click on "Product Support"

2) Call us at: **1-973-768-0381** Monday-Friday 8am-5pm (EST)

To receive Warranty service, the original consumer purchaser must contact PLB or an authorized service provider for service determination and service procedures. Proof of purchase in the form of a bill of sale or equipment invoice, establishing that the Product is within the applicable Warranty period, MUST be presented to Distributor, or an authorized service provider of the Distributor, in order to obtain the requested service.

Shipping expenses to the authorized service center or Return Facility are not covered by this warranty, and must be paid by the consumer.

Exclusions and Limitations

This Warranty covers manufacturing defects in material and workmanship encountered in the normal consumer use of the Product. This Warranty does not cover damage due to acts of nature, accident, misuse, abuse, negligence, commercial use or modification of, or to any part of the Product. In addition, this Warranty does not cover images "burnt" into the screen. This Warranty applies to the original consumer only and does not cover products sold "AS IS" or "WITH ALL FAULTS" or products purchased through auctions. Consumable items, such as fuses, batteries, CLEAN etc., This Warranty is void if the factory seal(s) on a number has been altered or removed from the Product. This Warranty is valid only in the country where the consumer purchased the product, and only applies to products purchased and serviced in that country.

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. NEITHER PLB INC. NOR ANY OF ITS AFFILIATES SHALL BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES OR ANY EXPRESS OR IMPLIED WARRANTIES BY ANY PERSON. THIS WARRANTY GIVES YOU SPECIFIC RIGHTS. YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE. YOUR SOLE REMEDY IN THE EVENT OF A DEFECTIVE PRODUCT SHALL BE LIMITED TO: • REPLACEMENT OR REFUND OF THE ORIGINAL PURCHASE PRICE • AT DISTRIBUTOR'S SOLE DISCRETION • ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN NO EVENT SHALL PLB IP HOLDINGS, LLC BE LIABLE FOR ANY INCIDENTAL, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, LOSS OF SAVINGS, OR DAMAGES ARISING FROM THE USE OR MISUSE OR INABILITY TO USE THE PRODUCT, EXCEPT AS STATED ABOVE. NO OTHER WARRANTIES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMER'S LEGAL RIGHTS, IF ANY, ARISING FROM THE SALE OF THE PRODUCT, OR THE PRODUCT DOES NOT MEET THE WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.

Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies.