IPRO

SHARK II

IP67

Thanks for selecting this mobile phone. For the best performance we recommend that you read the manual carefully.

Contents

Overview

1. Introduction

2. Function of main menu

3. Maintenance and service

Phone Display

1,Torch	2,Receiver	3,Screen
4,Left soft key	5,Dial key	6,Right soft key
7,End/Power key	8,Loudspeaker	9,Camera
10,USB		

Overview

Please read the following concise rules carefully. Noncompliance to the rules may lead to danger or violence of the law. The user's manual gives details about the safety precautions.

Emergency call

Make sure the equipment is in the covered area of the network service and the calling function is activated. As per the specific requirements, press the key of finish to clear the screen and return to the standby state. Input the emergency call number (112) and press the call key.

Function Description

The phone is a perfect combination of humanized design and exquisite workmanship. The streamline and ingenious body is comfortable to hold. With streamline and ingenious frame, it feels comfortable to hold the mobile phone in your hand. It supports TXT electronic book, Bluetooth, dual SIM cards with one standby, network camera, camera, FM radio etc. It makes your work more convenient and your free time more fun with the abundant entertainment functions. The phone's standby may look cartoon head portrait for incoming calls, strong file management function (supporting T-FLASH card), fashionable camera function and long time tape recording function, music player, video player.

1.Introduction

Insert the SIM card and the battery

Ask your SIM card dealer whether he has provided SIM card service and the method of usage who may be service provider or other dealers . SIM card and its contacts are vulnerable to scratch or bending. Attention shall be attached when use, insert or take out the card.

Inserting/taking out T-FLASH CARD

Only use approved and compatible T-FLASH card applicable to this mobile phone. Approved memory card basic standard is applied, however, certain bands may not be completely compatible with the mobile phone. Using incompatible memory card may damage not only the card and the mobile, but also the data stored in the card

Charging the battery

Check the model number of the charger before using it to charge the mobile. Only use approved battery, charger and accessories applicable to the specific mobile model. Using other types of battery charger and accessories may void the warranty and may cause the mobile phone damage and may result in danger. Refer to the dealer for supply of relative approved accessories.

Startup and shutdown

Press the key of power supply to start up or shut down the mobile phone. If it is prompted to input PIN or UPIN, please input the required password (shown as "*" on the screen)

2.Function of main menu

Contacts

Save the information of contacts, including names and telephone numbers in the contacts.

Message

Write a message: You can choose to send the complete message from SIM card 1 or SIM card 2. You can choose multiple receivers to send the message to more than 1 person.

Call logs

Missed calls: If you need to check you call logs, pick select call logs menu>Menu 1.All calls 2.SIM1/2 missed calls 3.SIM1/2 Dialled calls 4.SIM1/2 Received calls 5.SIM1/2 Rejected calls 6.Delete call logs 7.Call timers.

Settings

Phone settings

1.1.Date&Time: You can set the phone's time and date and the format.

1.2.Language Settings: You can select the phone's display language .

1.3.Shortcut Settings: You can set the phone right soft keys and the navigation key shortcut function.

1.4.Auto power on/off: After setting the time, and by that time the phone will auto power on/off.

1.5.Power management: Battery remains.

1.6.Restore factory settings: Enter the correct password of the phone will have to change your phone settings back to factory settings. Default: 1122. Be aware of the function be used with caution. Default password: 1122.

Display Settings

1.1.Animation effect: Set power on/off animation.

1.2.Wallpaper setting: Set wallpaper.

1.3.Idle display settings: You can choose to display or not display.

1.4.Brightness: The menu is to control of mobile phone screen brightness.

1.5.Display backlight: The menu is to control of mobile phone display backlight time.

1.6.Keypad backlight: The menu is to control of mobile phone keypad backlight time.

Call settings

This is some of the communications settings. There are have Dual-SIM, Call forwarding, Call waiting, Call barring, Hide ID and others.

Security

PIN/PIN2: The SIM1/2 security setting need provided network operator. For more details, please contact your operator.

Phone lock: You can switch on or off to activate the phone lock function to protect your phone.

Modify the phone password: You can change password here. The default password is "0000".

Privacy: You can open the privacy protection function, set up mobile privacy.

Auto keypad lock: You can set the on/off automatically lock function of the phone.

Lock screen by end key: Set end key as dedicated key to lock the phone.

Fixed dialing: You can set a fixed dialing.

Connections

Configure the network parameter in the phone.

Camera

In the options of camera, you may set the photometry mode, flash light , exposure compensation, avoidance of flickering, postponing shooting, white balance, photo quality, photo size, special effect, profile and etc. You may enter the album to check the formats that the cell phone supports.

Image viewer

Check the pictures in the memorial card in formats supported by the cell phone.

Video Recorder

phone provides video recording, select video footage that can enter the video recording. In the preview video press OK button to begin, press stop again, can have white balance, exposure compensation, night mode, avoid flashing to set one by one, Settings are stored path cell phone or memory card, Restore all the camera options of setting for the system default values.

Video player

Check the video files in the memory card supported by the cell phone.

Play your favorite video files.

Sound Recorder

Open the recording function, can pause, stop and play. After recording, the recording can be played

FM radio

Turn on FM broadcast, and you may press the direction keys of left and right to manually save the channel. Press the direction key of upward to turn on or off the auto-searching mode. Press the direction key of downward to turn on or off the FM broadcast. In the options, you may set manually or automatically searching for channels, turning off the background during broadcasting as well as the format of recording thereof.

File Manager

Phone & memory card

The File Manager list the all the files stored in your phone or memory card, you can view folder, delete folder, view the detail with folder (rename, copy, cut), search folder, mark folder, sort the folder, and view the memory status.

Games

This phone provides you some built-in games. You can also adjust the game settings when you enter the game menu. Please refer to help option of each game for specific operation and instructions.

KS INDEX

About my phone: This menu is mobile phone support the introduction of the performance.

Blacklist: You can open or close the blacklist, and set the numbers of blacklist.

Facebook : facebook network link access.

Fix priority: this menu is mobile phone fix priority function.

Mobile Tracker: This menu is sales statistics function.

WhatsApp: WhatsApp network link access.

Services

Internet

your mobile Internet support based on wireless application protocol (WAP) service. You can access a variety of WAP service. WAP service need network support, the WAP service availability, price and fee, please contact your network operator or provide you with the service providers of services required.

SIM

This function by the network providers, according to the SIM card provides services will appear different menu options. If a SIM card and network supplier does not support this service, this function will not be used. If you need to get more information please contact with network providers.

Tools

Bluetooth

You may establish wireless connection with other compatible devices with the Bluetooth technology; you may send images, videos, music files and etc. with the Bluetooth technology.

Alarm

Set the time of alarm clock, ring signal, ring mode, alarm ring mode and interval between repeated alarm rings.

calendar

calendar this feature allows you to view the calendar. In the calendar interface, press left soft key, you can make a new schedule, view the schedule, edit the schedule, empty, empty all, go to the date than day, weekly show operation, etc.

Calculator

Your cellular phone has a built in calculator, Enter the numbers with the keypad.

Torch

Turn on or off the flashlight, press 0 key on the keyboard for 5secs to power on or off torch.

World clock

You can view the local date and time via selecting the GMT and city, When the cross points out a certain city, it will show the local date and time.

Stopwatch

The function for time measurement

Music player

The music player is used to play music files in supported formats in the current player's list. You may view details of the music files and set the current music file as the ring signal for incoming call. You can enjoy the music with this function.

3. Maintenance and service

The music player is used to play music files in supported formats in the current player's list. You may view details of the music files and set the current music file as the ring signal for incoming call. You can enjoy the music with this function.

4.the cell broadcast

Enter Message menu to view Broadcast list

The purpose of cell broadcasting is to inform mobile phone users of the danger such as serious threats, child abduction and so on. Through some alerts issued by operators, the function is activated by default

FCC Warning

Specific Absorption Rate (SAR) information: SAR tests are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the equipment while operating can be well below this maximum value. In general, the closer you are to a wireless base station antenna, the lower the power output. Before a new model phone is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the exposure limit established by the FCC. Tests for each phone are performed in positions and locations (e.g. at the ear and worn on the body) as required by the FCC.

For body worn operation, this mobile phone has been tested and meets the FCC RF exposure guidelines when used with an accessory designated for this product or when used with an accessory that contains no metal and that positions the handset a minimum of 0.5 cm from the body.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.