1. Components

Table of Components for AIS Model JHS-180

No.	Name	Type	Quantity		Remarks
			Per set	Total	
1.	Standard Components				
1.1	AIS Transponder	NTE-180	1	1	With whip antenna, 2m connection cable, and fitting bands
1.2	Junction Box	NQD-4190	1	1	
1.3	AIS Controller	NCM-722	1	1	
1.4	Connection Box	NQE-3111	1	1	
1.5	Power Supply Cable	7ZCJD0095	1	1	Length=5m
1.6	Control Cable 1	7ZCAF0078	1	1	Length=5m
1.7	Control Cable 2	7ZCAF0079	1	1	Length=5m
1.8	Power Supply Unit	NBD-577A	1	1	
1.9	Spare Parts	7ZXJD0027	1	1	
2.	Options				
2.1	Console Mounting Kit	MPBP30837	1		For NCM-722 Color: 2.5G7/2
2.2	Console Mounting Kit	MPBP30838	1		For NCM-722 Color: 7.5BG7/2