BEITONG
BTP-2585NS
MADE IN CHINA

BEITONG ASURA 2
GAME CONTROLLER MULTI-MODE

USER MANUAL

CERTIFICATE IS INSPECTED

1

2

I. KEYS INTRODUCTION

1. Indicator light 1
2. Indicator light 2
3. Indicator light 3
4. Indicator light 4
5. SELECT
6. TURBO
7. HOME
8. START
9. Left Stick/LS (Press down)
10. D-Pad
11. Right Stick/RS (Press down)
12. ABXY

13. RB
14. LB
15. RT
16. LT

II. TURN ON AND OFF INSTRUCTIONS

Turn on
Press LOGO button

Turn off
Press and hold Select + B for 3 seconds

① When the controller is working, it will automatically shut down in idle 10 minutes.
② When the controller is not working, it will automatically shut down in idle 120 seconds.
③ When the battery is low, the controller will automatically shut down.

Notice!
When the battery power of the controller is less than 30%, the mode indicator light flashes quickly and the vibration is turned off, please charging as soon as possible.

III. TUTORIAL FOR CONNECTION

Press RB + SELECT + RS + LOGO button to turn on the controller, pairing information can be actively cleared.

Connect to computer
Use the data cable to connect the controller to the USB port of the computer, and then tap the LOGO button to turn it on. Then the device vibrates and the indicator light 2 is on, connection complete.
*The controller does not support Bluetooth wireless connection of the computer currently.

Connect to TV/Smartphone
① Press and hold the LOGO Button + B in the power-off state to turn on the controller into the BFM mode, while the indicator light 3 will flash.
Press and hold LOGO Button + B in the power-on state switch to the BFM mode, while the indicator light 3 will flash.
② Open up the Bluetooth function interface of the TV/Smartphone, search or select and connect the device"BEITONG 2585NS BFM".
③ Wait for a while, the controller vibrates and the indicator light 3 is on, connection complete.

Connect to Nintendo Switch
Turn on the Switch, open up the "Controller and Sensors" , "Change Grip/Order";

Press the LOGO Button of the controller to turn it on, and then press and hold LB + RB until the pairing interface appear on Switch ,and then press the A button to pair.

After the pairing is successful, just turn on the controller and it will automatically connect.

Connection failed :

go into system settings and select controllers and sensors , scroll down to find and click disconnect controllers , press and hold the X button on the joy-con at this interface until prompt that has been disconnected from the controller;

Press the RB + SELECT Button + RS + LOGO Button to turn on the controller until the indicator light flashes, press and hold the SELECT + B to turn off the controller. After that, turn it on again, press and hold LB + RB to re-pair;

If the controller has been already once connected to the Switch , re-connect only by pressing the LOGO button of the controller next time in state of none device connected.

After the connection is successful, the corresponding button of the controller are as follows:

BACK = -   TURBO+RS = Screenshot   SHIFT = HOME Button
START = +   *Short Press: Screenshot   *Short Press: Back to Desktop
　　　　　　*Long Press : Screen Recording   *Long Press: Menu Options

---

IV. OTHER FUNCTIONS

Toggle A/B button value
Press the LOGO button+ B to switch the controller working mode, and different key values will be automatically switched.

NS mode: indicator light 1 on, A means A, B means B

Wired PC Mode: indicator light 2 on, A means B, B means A

BFM Mode: indicator light 3 on, A means B, B means A

Button function description in NS mode

Button	Button value in NS mode	Operation
HOME	HOME	Press the HOME button to return to the NS Main interface
TURBO	Button Burst /Screenshot	1. Press Turbo + any action to burst 2. Press Turbo + any action to cancel 3. Press Turbo +press down Right Stick to take a screenshot (only valid on the NS platform, long press to record the screen)
SELECT	-	/
START	+	/

Motion Sensing Adjustment
The Motion Sensing function only supports the connection of Nintendo Switch

Turbo + D-Pad LEFT, Sensitivity reduced

Turbo + D-Pad RIGHT, Sensitivity enhancement

Turbo Function Settings
Press the Turbo button in the power-on state, and then press any action button to achieve the Turbo function, repeat this operation to cancel the Turbo function.

*Action button refer to A,B,X,Y,LB,RB,LT,RT

Vibration Intensity Adjustment
Turbo + D-Pad UP, Vibration intensity enhances

Turbo + D-Pad DOWN, Vibration intensity weakens

V. PRODUCT SPECIFICATION

Name	BEITONG ASURA 2 GAME CONTROLLER MULTI-MODE
Model	BTP-2585NS
Compatibility	PC Window 7 and later, Android TV, Nintendo Switch
Wireless Connection	Bluetooth 5.0
Wired Connection	USB Cable
Weight	～216g
Battery	600mAh Rechargeable Lithium Ion Battery
Product Size	165x105x62.5MM

VI. Warranty Card

Dear customer,

Thanks for using BEITONG gaming peripheral products.
We focus on providing gamer with a better gaming experience, please provide the information through your email for customer service:

a. Purchasing Channel
b. Buyer ID
c. Order Number
d. Product Model

Please provide the below information for us according to the product situation:

1.Please provide service reason
a. Function is not good
b. Bad appearance
c. Can not use in my device
d. Can not play the game I want to play
e. Other

2.Please provide the service you need
a. Replacement
b. Repairing
c. Return
d.Other

Customer service contact: beitong.oversea@betop-cn.com

We also welcome our customer to provide suggestion so that to improve and upgrade our product. Any good idea for our products, please feel free to contact us. It's very grateful. Meanwhile we'll select the customer who in high-quality advice to experience our new products for free opportunity.

Sincerely,

BEITONG Customer Service Team