WIRELESS SPORTS HEADPHONES

User Manual

UBR

Thank you for purchasing our products. Please read the user manual carefully before use.

English Version ---------- 1

Deutsche Version ---------- 15

French Version ---------- 31

Español Version ---------- 46

A Package Contents

① Bluetooth headphones × 1

② Carry bag × 1

③ Earbps × 4 pairs (L, M, S, XS)

④ Micro USB cable × 1

⑤ Wire clip (removable) × 1

⑥ User manual × 1

B At a Glance



① Microphone

② MFB button (Multi-function button)

③ Volume + / Next

④ Volume - / Previous

⑤ LED indicator

⑥ Micro USB port

LED Indicator Guide

- **Power on:** LED indicator flashes blue for one second.
- **Power off:** LED indicator flashes red for 2 seconds.
- **Pairing:** LED indicator flashes red and blue alternately.
- **Paired:** LED indicator flashes blue once every 10 seconds.
- **Low battery:** LED indicator flashes red twice every 3 seconds.
- **Charging:** LED indicator stays red during charging and turns blue when headphones are fully charged.

C Get Comfortable

Wearing the Headphones

1) Identify the right and left earbuds.

2) Gently push the headphones into your ear and adjust the ear hooks until you feel comfortable with it. The earbps are in different sizes, Please choose the right size of earbps to find the most secure and comfortable option for yourself (small fits medium ones are suitable for 70% of people).



D Using the Headphones

Charge the headphones

1) Open the hinged door on the bottom of the right earpiece.

2) Plug the small end of the USB cable into the Micro USB port of the headphones.

3) Plug the other end into a USB wall charger or computer (DC 5V) that is powered on.

Notes:

- Fully charge the headphones before using them for the first time.
- The indicator stays red during charging and turns blue when the headphones are fully charged.
- The indicator flashes red, and a voice reminder prompts when the headphones are in low battery.

Power on/off

- **Power on:** Press and hold the MFB button for 2 seconds.
- **Power off:** Press and hold the MFB button for 3 seconds when the headphones are on.

Pair

1) Turn on the Bluetooth of your phone or other Bluetooth devices.

2) Turn on the headphones when they are in disclosure state (put the headphones into your ears and take them out), they will enter pairing mode.

3) In the list of found Bluetooth devices in your phone or other Bluetooth devices, choose "UBR" to pair.

4) Enter "0000" or "1234" if your phone or Bluetooth device asks you to enter a code to pair.

Notes:

- When the headphones are in but are not paired with your phone or other Bluetooth devices, they will be automatically off in about 5 minutes (to save battery power). Turn them on manually.
- The headphones will enter pairing mode the first time you put them on, and they will connect to the last paired Bluetooth device automatically when turned on.
- If you put the headphones into the pairing mode when the headphones have been paired with a Bluetooth device, turn off the headphones and press and hold the MFB button for 3 seconds (indicator flashes red and blue alternately).

Volume up/down, next/previous song

- Press the "+" button to increase the volume, press and hold the "+" button for 2 seconds to skip to the next song.

- Press the "-" button to decrease the volume, press and hold the "-" button for 2 seconds to skip to the previous song.

Play/pause playing songs

Press the MFB button to pause and press the MFB button again to resume playing songs.

Answering/ending calls

- Press the MFB button to operate on your phone to answer an incoming call.
- Press the MFB button to operate on your phone to hang up an ongoing call.
- Hold the MFB button for 2 seconds to reject an incoming call.

Redial the last number

Hold the "+" and "-" buttons at the same time for 2 seconds.

Activate voice assistant of phone

Press the MFB button twice, and you will hear a "Du" sound to activate the voice assistant of your phone; press the MFB button again to exit the voice assistant of your phone.

Note:

This function works only when your phone has voice assistant function. Please refer to the instructions of your phone for details.

Reset the headphones/Clear all pairing information on the headphones

1) Turn off the headphones.

2) Press and hold the MFB button for 12 seconds, the indicator flashes red and blue, and you hear a "power on" sound first and then hear the "pairing" sound, keep holding the MFB button and then you hear 3 times, the headphones are ok.

E FAQs

Q: I paired the headphones with my phone before, but it failed to pair them to my phone again.

A: 1) Turn off the Bluetooth of your phone and in "APP Manager", "Bluetooth", "Paired Devices", "Forget This Device".

2) Turn off the headphones.

3) Reset the headphones by holding the MFB button for 12 seconds.

4) Pair the headphones.

5) Pair the headphones with your phone again following the instructions in the previous part "Pair".

Q: I paired the headphones with my phone, but I hear music from the phone's speaker.

A: Make sure the headphones are each one. Mono, Some phones ask for the setup of the wireless headphones as an audio output device before the sound is transmitted, Please refer to the instructions of your phone. If the "Pair" is for a mono phone or other devices, please make sure it supports A2DP stereo music profile.

Q: Why isn't the sound stable and consistent?

A: Bluetooth connection between headphones and phone and your headphones and your phone must be in line of sight, no obstacle between, and no radio or WiFi interference nearby.

Q: Can I use the headphones during charging?

A: No, you can't use the headphones during charging.

Q: My headphones will not switch on.

A: Please recharge the headphones and make sure they have enough battery power. If they are fully charged and still nothing happens or if you are not able to charge the unit, please contact our customer support for further information.

F Specifications

- Bluetooth Standard: V5.0
- Wireless Profile: A2DP, HFP, HSP, AVRCP, SPP, PBAP
- Operating Range: 33 feet/10 meters (No obstacle between)
- Waterproof Rate: IPX7
- Standby Time: 240 hours
- Charging Time: 1.5 hours
- Talk/Playing Time: about 7~12 hours (Varies according to volume level and audio content)
- Charging Voltage: DC 5V
- Charging Current: 5V 500mA
- Battery Capacity: 110mAh/3.7V

G Attention

Use original or certified cables.

Don't expose to liquids.

Don't disassemble.

Avoid dropping.

Avoid extreme temperatures.

SAFETY AND WARRANTY

Important Safety Instructions

- Use of headphones may impair your ability to hear other sounds. Use caution while using your headphones when you are engaging in any activity that requires your full attention.
- Consult your physician before using medical implanted devices, you should consult your physician before using this product.
- This package contains small parts that may be hazardous to children and should be kept out of their reach. Do not let children play with this product. Always store the product out of reach from children. Do not let children play with small parts they contain may cause choking if ingested.
- Never try to disassemble the product yourself, or push objects of any kind into the product, as this may cause short circuits which could result in a fire or electric shock.
- None of the components can be replaced or repaired by users. Only authorized dealers or service centers may open the product. If any parts of your product require replacement for any reason, please contact us. In case of heat leak or breakage, please contact us.
- Avoid exposing your product to heat and humidity to protect against damage to the product or injury to you.

- Keep all products, cords, and cables away from operating machinery.
- If the product overheats, if the product has been dropped or damaged, if the product has a damaged cord or plug, or if the product has been exposed to liquid, discontinue use and contact us.
- Do NOT use in areas where there are explosive hazards.
- Do NOT submerge the headphones in water. Do NOT use the headphones for mixing water, tea, from a faucet, etc.
- Do NOT wear the headphones while showering or bathing, or when participating in water sports, sea, swimming, waterskiing, surfing, etc.
- Do NOT use headphones while driving. Consult your physician on whether this might affect your implanted medical devices.
- Leaving the product in hot or cold places, such as in a closed car in the summer and winter, may deteriorate the battery capacity and lifetime of the headphones.
- Dispose of the product according to local standards and regulations.
- Remember always drive safely, avoid distractions and stay focused!

Using the headphones while operating a motor vehicle, bicycle, scooter or bicycle may be dangerous, and is illegal in some jurisdictions. Just as use of the headphones with both ears covered while driving is not permitted in certain jurisdictions, it may be illegal to drive with only one ear covered by headphones when you are engaging in any activity that requires your full attention. While engaging in any activity that requires your full attention, you may wish to turn off your headphones, or keep you from being distracted, so as to avoid accident or injury. Do not take notes or read documents while driving.

WARRANTY

We strive to offer our products with the highest attention to detail and craftsmanship, however, sometimes there are occurrences of defects.

We are happy to offer 1year hassle-free warranty to all our products as we continue to make amazing wireless products. Please contact us if you have any questions about our devices.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and radiates radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radiocommunications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

(1) Reorient or relocate the receiving antenna.

(2) Increase the separation between the equipment and receiver.

(3) Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

(4) Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.