
23
320
10
6.5
eARC / ARC
HDMI
HDMI(ARC)
HDMI(ARC)
AUB OUT
ARC
HDMI ARC
OPT
VOL
RESET
Step 1:
Connect one end of the HDMI cable to the eARC / ARC port on the back of your TV.
Step 2:
Then connect the other end to the HDMI(ARC) port of the soundbar.
Step 3:
Press " ARC " button on the remote control to select "HDMI(ARC)" input.
Note:
Make sure your TV HDMI supports ARC , otherwise the Dolby Atmos audio signal cannot be transmitted.
Atmos: If you are watching a movie in the Dolby Atmos format, please set the audio output on your TV to Pass Through:
TV Settings > Home > Settings > Sound > Digital Audio Output> Pass Through.
DTS & Others: If you are watching a movie in the NON-Atmos format, please set the audio output on your TV to PCM:
TV Settings> Home> Settings>Sound>Digital Audio Output>PCM.
Note: Please turn on the "CEC" function on your TV.
When eARC / ARC is connected, your TV remote control can control the soundbar and TV simultaneously:
❶Turn on / off ❷Adjust the volume
Peel Here
20
45
TONOR
TNS2102
AUX/USB
BT
Standby
OPT
HDMI eARC
Dolby Atmos


125.0
153.5
TONOR
TNS2102 2.1 Channel Soundbar
Model Number:SL4100
FCC ID:2AZNY-SL4100S
FREQ.RANGE:2402-2480MHz
HVIN:SL4100
IC:30108-SL4100S
Power Supply: DC 24V 2.5A
MANUFACTURER: EASTWEST ELECTRONIC COMMERCE CO., LIMITED
ADDRESS: 6/F MANULIFE PLACE 348 KWUN TONG ROAD KL
EMAIL: SUPPORT@TONORMIC.COM
EC-REP: Lifewit GmbH
ADDRESS: Friedenstraße 5 97072 Wuerzburg Germany
EMAIL: LIFEWITDE@LIFEWIT.COM
UK-REP: LIFEWIT LIMITED
ADDRESS: UNIT 2, VINCENT HOUSE, FIRCROFT WAY, EDENBRIDGE UNITED KINGDOM
US-REP: EASTWEST ELECTRONIC COMMERCE CO US LIMITED
ADDRESS: 3500 SOUTH DUPONT HIGHWAY, SUITE G106 DOVER, DE 19901 UNITED STATES
Official Website: www.tonormic.com
Customer Service Email: support@tonormic.com
MADE IN CHINA
CAUTION
WARNING RISK OF ELECTRIC SHOCK DO NOT OPEN
WARNING:TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.
RoHS
Bluetooth
Dolby Atmos
HDMI
50.0
15.0