封面

REDRAGON
IRE PRO
ULTRA-LIGHT WIRELESS
GAMING HEADSET

Please scan here to download user manual

Ultra-light Wireless Gaming Mouse Operating Instructions

封底

REDRAGON
IRE PRO
ULTRA-LIGHT WIRELESS
GAMING HEADSET

CE EAC FC RoHS

Ultra-light Wireless Gaming Mouse Operating Instructions

US UK

Dear user

Thank you for choosing our REDRAGON product. To protect your rights and for better customer service, we ask that you note our warranty rules.

1. Within guaranty period, repair is guaranteed free of charge due to electrical circuit problems, factory defects, such as disassembly, hard impacts, submersion in any liquid, plugging in the wrong power or voltage, and damage caused by natural disasters are not covered by the warranty and are chargeable.
2. Consumable parts (such as foot pad) and spare parts replacement are not included in our warranty.

OS Support

Windows XP/ Vista/ Win 7/ Win 8/ Win 10/ Win 11

Packaging content:

A. Headset ——————————————————— 1PCS
B. USB dongle ——————————————— 1PCS
C. TYPE-C charging cable ——————— 1PCS

Headset button and receiver LED indication:

Receiver LED:
① Blue LED twinkle: Connecting cut off
② Blue LED light on: Connected, MIC ON
③ Blue LED OFF: Connected, MIC mute

Headset buttons:
① Volume +
② Volume -
③ Power
④ MIC ON/OFF
⑤ TYPE-C charging port
⑥ Indicator LED

Detachable Microphone

The headset microphone is detachable, please plug it into headset according the fig pointi, follow the instruction as following photos to plug in.

How to charge the headset battery

1) Plug this charging cable to type C slot on headset, plug the charging cable to USB port on PC or DC 5V power adapter, the headset LED turns ON in red while charging, the charging time is around 2.5 hours.
2) At 2.4G mode, charging by power adapter, LED turn ON in Red and Blue (2.4G connecting status), the headset LED indicator turn OFF after 10 minutes, LEDs ON in Red, it is turn OFF after charging complete.
3) At 2.4G mode, charging by PC, 2.4G connectivity will be cut off, headset how works via wired connecting, LED turns ON in red and blue, it is turn OFF after charging complete.
4) Charging at BT mode, the headset will be turns OFF, LED is turn ON in red, LED turns OFF after charging complete.
5) Charging when headset turns OFF, the LED is ON in red, the Red LED will be turn off after charging complete.

Device name

1) USB dongle (USB receiver): H848 Wireless headset
2) BT mode headset name: H848
3) Wired mode headset name: H848 USB Gaming Headset

How to pair

1) Turn OFF headset, take OFF USB dongle.
2) Press power button to turn on headset, LED turns ON in blue, flash slowly, press power button twice quickly, headset is switch to 2.4G mode, indication tone: gaming mode.
3) Plug USB dongle to PC or PS4 or smart phone, the dongle LED is on in blue, the blue light is twinkle waiting for pair.

4) Press and hold microphone button for 3 seconds, pairing complete, the indication tone: gaming mode. Power on.
Note1: USB dongle may turn OFF while pairing, it may be caused by microphone button being pressing.
5) For re-connecting, Headset and dongle will be pairing automatically, dongle LED lights ON in blue.

Headset function instruction

2.4G mode:
1) Plug headset dongle to PC/PS4/Smart phone (via Type C port), dongle LED lights ON then turn off after 10 minutes.
2) Press power button to turn ON headset, start to pairing, headset and dongle LEDs are light on in BLUE after pairing complete. The LEDs are twinkle if pairing failed.
3) Adjust volume by volume + / - buttons.
4) Microphone is default to ON, press MIC button to turn it OFF,Dongle LED turns OFF now), press MIC button again to turn it ON, Dongle LED turns ON.
5) Headset default to stereo sound effect, press MIC button twice to switch the sound to virtual 7.1 sound effect. headset paired "da-Da" for indication, do it again switch back to stereo sound(headset paired "da" for indication).
6) Button function in 2.4G as following:

	Button/function/ indicator	Function instruction	How to process	Indication tone
		2.4G+wired mode		
Left setup	2.4G+wired mode/ BT switch button	Switch 2.4G+wired mode and BT mode	Double click power button	2.4G+wired mode connecting complete: "Gaming Mode", BT mode connecting: "Pairing", "Disconnect mode, Power off"
	Volume+ button	Increase volume	Click press and hold	Max volume "Da Dong"
	Volume- button	Decrease volume	Click press and hold	Minimum volume "Da Dong"
	Microphone ON/OFF button	MIC ON/Mute	Click	Mute: "Ding Dong", Open: "Da Dong"
		2.0/7.1	Double click	Default is ON(Dongle LED is ON), Default is stereo sound: "Da Da", Virtual 7.1 sound effect: "Ding Ding"
		2.4G pairing	Press and hold for 3 seconds	2.4G pair complete: "Gaming Mode"
	Power button	ON/OFF	Turn ON: Press and hold for 1.5 second, Turn OFF: Press and hold for 3 seconds	

Wired mode:
1) Please take off the dongle if headset works at 2.4G mode.
2) Turn on headset by press power buy, double click power button to switch the headset to 2.4G+wired mode, headset and dongle LEDs are light on in BLUE after pairing complete, headset to PC or other devices by type C cable (please noted that to avoid headset is working in bluetooth mode , the headset must be switch to 2.4G/2.4G+wired mode, then plug the type C cable), now the headset is in USB wired mode, headset indicator will turn on in red and blue.
3) Adjust volume by volume + / - buttons.
4) Microphone is default to ON, press MIC button to turn it OFF(Indication tone"Ding Dong"), Do it again to turn it ON(Indication tone"Ding").
5) Headset default to stereo sound effect, press MIC button twice to switch the sound to virtual 7.1 sound effect. headset paired "da-Da" for indication, do it again switch back to stereo sound(headset paired "da" for indication).
6) The headset can not switch to Bluetooth and 2.4G mode when it is connected with PC/PS4/Devices by type C cable, it must be plug off the cable before headset switch to bluetooth and 2.4G mode.
7) Button function in wired mode as following:

	Button/function	Function indication	How to process	Indication tone
		USB wired mode		
Left setup	2.4G+wired mode/ BT switch button	Switch 2.4G+wired mode and BT mode	Double click power button	2.4G+wired mode connecting complete: "Gaming Mode", BT mode connecting: "Pairing", "Disconnect mode, Power off"
	Volume+ button	Increase volume	Click press and hold	Max volume "Da Dong"
	Volume- button	Decrease volume	Click press and hold	Minimum volume "Da Dong"
	Microphone ON/OFF button	MIC ON/Mute	Click	Mute: "Ding Dong", Open: "Da Dong"
		2.0/7.1	Double click	Default is ON(Dongle LED is ON), Default is stereo sound: "Da Da", Virtual 7.1 sound effect: "Ding Ding"
	Power button	ON/OFF	Turn ON: Press and hold for 1.5 second, Turn OFF: Press and hold for 3 seconds	
	Charging indicator	Red LED	Turn ON: Press and hold for 1.5 second, Turn OFF: Press and hold for 3 seconds, LED light up in RED, it is turn OFF when charging complete	
	Charging indicator	Blue LED	Twinkle when it is pairing, it is OFF after connecting	

Bluetooth mode
1) Turn on headset, switch to BT mode, indication tone "Bluetooth mode, pairing", headset ready to pairing.
2) Open Bluetooth headset compatible with most of PC and PS4 / smart phone and other devices.
3) Press and hold MIC button for 3 seconds, headset start to pair with bluetooth device.
4) Turn on bluetooth at PC, PS4/smart phone, the devices will scan the bluetooth device, or press the search button to find the headset.
5) Click the headset name to connect, the LED light keeps in the lick, then press it to pairing.
6) The indication tone "connected" after pairing successful.
7) Headset default to stereo sound in bluetooth mode, not available with other sound effect.
8) Button function in BT mode as following:

	Button/function	Function indication	How to process	Indication tone
		Bluetooth mode		
Left setup	2.4G+wired mode/ BT switch button	Switch 2.4G+wired mode and BT mode	Double click power button	2.4G+wired mode connecting complete: "Gaming Mode", BT mode connecting: "Pairing", "Bluetooth mode, Power off"
	Volume+ button	Increase volume	Click	Max volume "Da Dong"
	Volume- button	Decrease volume	Click	Minimum volume "Da Dong"
	Microphone ON/OFF button	MIC ON/Mute	Click	Mute: "Ding Dong", Open: "Da Dong"
		Previous track	Double click	Default is ON (Dongle LED is ON), Default is stereo sound: "Da Da", Virtual 7.1 sound effect: "Ding Ding"
	Power Button	ON/OFF	Turn ON: Press and hold for 1.5 second, Turn OFF: Press and hold for 3 seconds	Bluetooth Mode
		Play/pause	Click	
		Answer/Hang up	Click	
		Refused phone	Press and hold for 1.5 second	

The headset compatibility:

HB48 works with following devices			
Available devices	**Bluetooth**	**2.4G**	**wired**
Android phone	Yes	Yes (with type C adapter)	Yes (with type C adapter)
Windows notebook	Yes	Yes (by USB port)	Yes (by USB port)
Windows PC	N/A	Yes (by USB port)	Yes (by USB port)
Apple notebook	Yes	Yes (with type C adapter)	Yes (with type C adapter)
switch	Yes	Yes (with type C adapter)	Yes (with type C adapter)
PS3	N/A	Yes (by USB port)	Yes (by USB port)
PS4	N/A	Yes (by USB port)	Yes (by USB port)
PS5	N/A	Yes (by USB port)	Yes (by USB port)
XBOX one	N/A	N/A	N/A

Low power warning

The headset indicator lights up in Red and twinkle when the power is below to 3.2V, the indication tone "Battery low", then USB dongle LED twinkle, the headset turn OFF automatically when the power is below to 3.2V.

How to keep the headset

The headset should be keep in the condition of temperature of -5 ~ 35°C, it should be a dry place, avoid the headset being contaminated by water or other corrosive objects and the fire or heat source, please charge the headset every 6 months.

Remark

1. Do not put the headset in humid and wet place.
2. Do not put the headset in high temperature place or hearing.
3. Do not put self's strength to pull the cable.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device contains license-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device.

1

2

3

4

5

6

7

8

9

10

11

12

13

BATTERY SAFETY GUIDELINES

DO NOT replace the battery with a different model.
DO NOT use this product if the battery shows signs of damage including, but not limited to leaking, deformation, leakage, or the smell of electrolyte material.
DO NOT dispose of the battery in a fire or near a heat source. Immediate medical attention if any material comes into contact with your skin or eyes.
DO NOT expose the battery to liquid, heat sources, electricity (outside of the product itself), or other non-standard operating conditions.
DO NOT remove the battery except for proper disposal and recycling as required by local laws and regulations.
DO NOT impact, bend, pierc, disassemble, or otherwise damage the battery as the contents, are volatile, hazardous, and can be harmful.

⚠ CAUTION

Failing to follow all safety guidelines may result product damage, explosion, fire, and/or electric shock.

Cet appareil contient des émetteurs / récepteurs exempts de licence conformes aux RSS (RSS) d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes: (1) Cet appareil ne doit pas causer de brouillage électromagnétique. (2) Cet appareil doit accepter tout brouillage radioélectrique susceptibles de provoquer un fonctionnement indésirable de l'appareil.

ES

Estimado usuario

Gracias por elegir REDRAGON. Lée. Para proteger sus derechos y ofrecer un mejor servicio al cliente, le pedimos que preste atención a las reglas de la garantía.
1. Dentro del periodo de garantía, la reparación está garantizada por fallos debidos a problemas en el circuito eléctrico. Los daños causados por el hombre, como desmontaje, impactos duros, inmersión en cualquier líquido, conectar a la corriente o un voltaje incorrecto y los daños causados por desastres naturales como incendios, inundaciones y terremotos no están incluidos.
2. Las partes consumibles (tal como un basilar) y el reemplazo de repuestos no está incluido en nuestra garantía.

Soporte técnico

Windows XP/ Vista/ Win 7/ Win 8/ Win 10/ Win 11

Contenido del paquete:

A. Auriculares ——————————————— 1 pieza
B. Dispositivo USB ——————————— 1 pieza
C. Cable de carga TIPO-C ————— 1 pieza

Indicador LED de los botones de los auriculares y del receptor:

① Blue LED: Conexión cortada
② LED azul encendido: conectado, micrófono encendido
③ LED azul apagado: conectado, micrófono silenciado

Botones de los auriculares:

① Bajar volumen
② Subir volumen
③ Encendido/Apagado del Micrófono
④ Puerto de carga TIPO-C
⑤ LED indicador

Micrófono desmontable

El micrófono de los auriculares es desmontable, así que conéctelo a los auriculares de acuerdo con el punto fijo y siga las instrucciones que se muestran en las fotos siguientes para conectarlo.

Cómo cargar la batería de los auriculares

1) Conecte el cable de carga al puerto de carga del auriculares conectar el cable de carga a puerto USB de la PC o adaptador de corriente de 5 V, el LED de los auriculares se ENCENDERÁ en rojo mientras se carga, el tiempo de carga es de una 2.5 horas.
2) A modo 2.4G, el cargar con el adaptador de corriente, el LED se encenderá en rojo y azul (conexión de 2.4G) se interrumpe durante la carga), y los auriculares se apagarán después de 10 minutos, el LED se encenderá en rojo y luego se apagará al completar la carga.
3) A modo 2.4G, el cargar desde la PC, la conectividad 2.4G se cortará, los auriculares funcionarán con el cable de conexión por cable, el LED se encenderá en rojo y azul, y se apagará al completar la carga.
4) Cargando en modo BT, los auriculares se apagarán, el LED se encenderá en rojo, y el LED se apagará al completar la carga.
5) Al cargar con los auriculares apagados, el LED se ENCENDERÁ en rojo, y el LED rojo se apagará al completar la carga.

Nombre del dispositivo

1) Nombre del dongle USB (receptor): H848 Auriculares inalámbricos H848
2) Nombre de los auriculares en modo BT : H848
3) Nombre de los auriculares en modo por cable: auriculares para juegos USB H848

Cómo sincronizar

1) Apague los auriculares, retire el dispositivo USB
2) Encienda los auriculares, presione el botón multifunción 3 veces, el LED se encenderá en azul y destellará brevemente, presione el botón de alimentación dos veces rápidamente, los auriculares cambiarán al modo 2.4G, y el tiene de indicación: modo de juego.
3) Conecte el dispositivo USB a la PC, a la PS4 o a teléfonos inteligentes, el LED del dispositivo se encenderá en azul, la luz azul estará destellando en espera de la sincronización.

4) Presione y mantenga presionado el botón del micrófono durante 3 segundos, y la sincronización de los auriculares se completará. Encendido de los auriculares.
Nota: el dispositivo USB puede APAGARSE durante la sincronización, y esto puede deberse a que se ha presionado el botón del micrófono.
5) Para volver a conectar, los auriculares y el dispositivo USB se sincronizarán automáticamente, las luces LED del dispositivo USB se encenderán en azul.

Instrucciones de las funciones de los auriculares

Modo 2.4G
1) Conecte el dispositivo USB de los auriculares a la PC/PS4/teléfono inteligente (a través del puerto tipo C), los luces LED del dispositivo se encenderán y luego destellarán en espera de sincronización.
2) Presione el botón de alimentación para ENCENDER los auriculares, continúe la sincronización, los LED de los auriculares y del dispositivo USB se iluminarán en AZUL, después de la sincronización, los LED se apagarán. Si falla la sincronización.
3) Ajuste el volumen con los botones de bajar y subir el volumen.
4) El micrófono está predeterminado en Encendido, presione el botón MIC para apagarlo (el LED del dispositivo USB se apagará ahora), presione nuevamente para encenderlo (el LED del dispositivo USB se encenderá ahora).
5) Los auriculares están en modo estéreo de sonido predeterminado, presione el botón MIC dos veces para cambiar el sonido al efecto de sonido virtual 7.1, los auriculares sonarán "da-da" como indicación, vuelva a cambiar el sonido estereofónico (los auriculares sonarán "da" como indicación).
6) Función de los botones en 2.4G de la manera siguiente:

	Modo 2.4 GHz			
Auriculares inalámbricos	Botón/Función/ indicador	Instrucción de la función	Cómo procesar	Tono de indicación
	Botón de cambio de modo 2.4G por cable y BT	Cambiar el modo 2.4G por cable y BT	Doble clic en el botón de alimentación	Conexión de modo 2.4G por cable completa: "Modo de juego", Conexión BT completa: modo de emparejamiento, "Desconexión, Apagado"
	Botón Subir volumen	Subir el volumen	Clic/clic y mantener presionado	Volumen máximo "Da Dong"
	Botón Bajar volumen	Bajar el volumen	Clic/clic y mantener presionado	Volumen mínimo "Da Dong"
	Botón de encendido/ apagar el micrófono	Encender/ Silenciar el micrófono	Un clic	Silenciar: "Ding Dong", Encendido: "Da Da", Predeterminado a ON (LED del dispositivo USB es ON),
		2.0/7.1	Dos clics	Sonido estéreo predeterminado (LED del dispositivo USB es ON), Sonido virtual 7.1: "Da Da",
	Botón de emparejamiento de 2.4G	Encender/Apagar	Mantener pulsado por 3 seg	Sincronización completa: modo de juego
		Sincronización 2.4G	Mantener pulsado por 3 seg	Encendido: mantener pulsado por 3 seg, Apagar: mantener pulsado por 3 seg
	Botón de alimentación	Encender/ Apagar	Clic	Sincronización de 2.4G completa: modo de juego

Modo Por cable

1) Conecte el dispositivo USB dongle a los auriculares funcionan en modo 2.4G.
2) Encienda los auriculares presionar la tecla de alimentación, luego dos clics en el botón de alimentación para cambiar los auriculares a modo 2.4G y por cable, el tono de indicación de los auriculares: "modo de juego", luego conecte los auriculares a la PC a otros dispositivos mediante un cable tipo C (tenga en cuenta que para evitar que los auriculares funcionen en modo Bluetooth, los auriculares deben estar en modo por cable USB 2.4G, luego conecte el cable tipo C), ahora los auriculares están en modo por cable USB, el indicador de los auriculares se encenderán en rojo y azul.
3) La PC detectará los auriculares como auriculares USB para juegos HB48 después de conectarlos correctamente.
4) Ajuste el volumen con los botones de subir y bajar el volumen.
5) El micrófono está predeterminado en Encendido, presione el botón MIC para apagarlo (tono de indicación "Ding Dong"), Apagado de nuevo para encenderlo (tono de indicación "Ding").
6) Auriculares predeterminados al efecto de sonido estereofónico, presione el botón MIC dos veces para cambiar el sonido al efecto de sonido virtual 7.1, los auriculares sonarán "da-da" como indicación, vuelva a cambiar al sonido estereofónico (los auriculares sonarán "da" como indicación).
7) Los auriculares no pueden conectarse al modo Bluetooth y 2.4G cuando están conectados a una PC/PS4 Dispositivos mediante un cable tipo C, así que debe desconectar el cable antes de que los auriculares puedan conectarse al modo Bluetooth.
8) Función de los botones en modo Por cable de la manera siguiente:

	Modo Por cable USB			
Auriculares inalámbricos	Botón/Función	Indicación de la función	Cómo procesar	Tono de indicación
	Botón de cambio de modo 2.4G por cable y BT	Cambiar el modo 2.4G por cable y BT	Dos clics en el botón de alimentación	Conexión del modo 2.4G por cable completa: "Modo de juego", Conexión BT completa: modo de emparejamiento, "Desconexión, Apagado"
	Botón Subir volumen	Subir el volumen	Clic/clic y mantener presionado	Volumen máximo "Da Dong"
	Botón Bajar volumen	Bajar el volumen	Clic/clic y mantener presionado	Volumen mínimo "Da Dong"
	Botón de encendido/ apagar el micrófono	Encender/ Silenciar el micrófono	Un clic	Silenciar: "Ding Dong", Encendido: "Da Da", Predeterminado a ON (LED del dispositivo USB es ON),
		2.0/7.1	Dos clics	Sonido estéreo predeterminado (LED del dispositivo USB es ON), Sonido virtual 7.1: "Da Da",
	Botón de alimentación	Encender/Apagar	Mantener presionado por 3 seg	Encendido: mantener pulsado durante 1.5 segundos, Apagado: mantener pulsado por 3 seg
	Indicador de carga	LED Rojo	Conectado a un cable de carga: el LED se encenderá en rojo, Apagado después de cargar	
	Indicador de carga	LED Azul	Conectado a un cable de carga: el LED se encenderá en azul, Apagado después de cargar	

Modo Bluetooth

1) Encienda los auriculares, cambie al modo BT, el tono de indicación: "Modo Bluetooth, sincronización".Auriculares listos para sincronizar.
2) Los auriculares Redragon son compatibles con la mayoría de los PC y PS4/teléfonos inteligentes y otros dispositivos.
3) Presione y mantenga presionado el botón MIC durante 3 segundos, y los auriculares comenzarán a emparejarse con el dispositivo Bluetooth.
4) Active el Bluetooth en la PC/PS4/teléfono inteligente, y el dispositivo explorará el dispositivo Bluetooth o presione el botón de búsqueda para encontrar los auriculares.
5) Busque el dispositivo de auriculares Redragon llamado H848 en la lista, luego presiónelo para sincronizar.
6) El tono de indicación será "conectado" después de lograr la sincronización.
7) Los auriculares tienen sonido estereofónico predeterminado en modo bluetooth, y no está disponible con otros efectos de sonido.
8) Función de los botones en modo BT de la manera siguiente:

	Modo Bluetooth			
Auriculares inalámbricos	Botón/Función	Función indicación	Cómo procesar	Indicación tono
	Botón de cambio de modo 2.4G por cable y BT	Cambiar el modo 2.4G por cable y BT	Dos clics en el botón de alimentación	Conexión del modo 2.4G por cable completa: "Modo de juego", Conexión BT completa: modo de emparejamiento, "Desconexión, Apagado"
	Botón Subir volumen	Un clic	Mantener presionado	Volumen máximo "Da Dong"
	Botón Bajar volumen	Bajar volumen	Un clic	Volumen mínimo "Da Dong"
	Botón de encendido/ apagar el micrófono	Encender/ Silenciar el micrófono	Dos clics	Predeterminado a Encendido (LED del dispositivo USB es ON), Encendido: "Da Da", Silenciar: "Ding Dong",
		Sin sincronización	Mantenga pulsado durante 3 segundos	Sonido del tono desconectado
	Botón de alimentación	Encendido/ Apagado	Presionado durante 1.5 segundos, Presionado durante 3 segundos	Encendido: mantener pulsado durante 1.5 segundos, Apagado: mantener pulsado durante 3 segundos
		Reproducir/pausar	Un clic	Bluetooth Modo
		Contestar/Colgar	Un clic	
		Teléfono rechazado	Mantenga pulsado durante 1.5 segundos	

Compatibilidad de los auriculares :

HB48 funciona con los dispositivos siguientes			
Dispositivos disponibles	**Bluetooth**	**2.4G**	**Por cable**
Teléfono Android	Sí	Sí (con adaptador tipo-C)	Sí (con adaptador tipo-C)
Cuaderno de Windows	Sí	Sí (por puerto USB)	Sí (por puerto USB)
PC de Windows	N/A	Sí (por puerto USB)	Sí (por puerto USB)
Cuaderno para Apple de Apple	Sí	Sí (con adaptador tipo-C)	Sí (con adaptador tipo-C)
Switch	Sí	Sí (con adaptador tipo-C)	Sí (con adaptador tipo-C)
PS3	N/A	Sí (por puerto USB)	Sí (por puerto USB)
PS4	N/A	Sí (por puerto USB)	Sí (por puerto USB)
PS5	N/A	Sí (por puerto USB)	Sí (por puerto USB)
XBOX one	N/A	N/A	N/A

Advertencia de poca energía

El indicador de los auriculares se iluminará en rojo y destellará cuando la energía sea inferior a 3.2 V, se enviará el tono de indicación "Batería baja", luego el LED del dispositivo USB destellará, los auriculares se apagarán automáticamente cuando la energía sea inferior a 3.2V.

Cómo mantener los auriculares

Los auriculares deben mantenerse en condiciones de temperaturas de -5 ~ 35 °C, debe estar en interiores en un ambiente limpio y seco. Manténgalos alejados de los líquidos corrosivos y de una fuente de calor o fuego. Cargue los auriculares cada 6 meses.

Notas

1) No utilice los auriculares si tiene problemas en los oídos.
2) Escuche a alto volumen durante largos periodos puede dañar su audición.
3) No use mucha fuerza para tirar del cable.

型号	红龙H848 9159		备注：尺寸：L100*W100mm 材质：80g书写纸，装订成本 印刷：单色		
名称	说明书（英+西班牙）				
日期	2023-7-5				
页码	1 OF 1	文件编号			
绘图	吴九香	审核		核准	版本 A.0