折页正面

58 mm

06 Resetting N Tag

06.1 Remove The N Tag From Find My App:

Open Find My app and select the "Items" tab.

Tap on your N Tag from the list

please ensure "Lost Mode" is disabled

Scroll to the bottom of the screen and tap "Remove Item"

A summary will open tap "Remove" to confirm.

06.2 Factory Reset Your N Tag:

After successfully removing the N Tag from Find My app, press the N Tag's button four times rapidly and then hold it a fifth time until you hear a ringing chime.

The N Tag is now reset and ready to be paired to a new Apple ID

52 mm

07 Extras

07.1 Unwanted tracking:

If any Find My network accessory separated from its owner is seen moving with you over time, you'll be notified in one of two ways:

1. If you have an iPhone iPad, first the will send a notification to your Apple device.The feature is available on iOS or iPadOS 14.5 or later.

2. If you don't have an ios device or a smartphone, a find my network accessory that isn't with its owner for a period of time will play a sound when it moves.

These features were created specifically to discourage people from trying to track you without your knowledge

52 mm

08 The Fine Print

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or changes to this equipment. Such modifications or changes not expressly approved by the party responsible for compliance could void the user's authority to operate the device.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. Federal Communication Commission (FCC) Radiation Exposure Statement Power is so low that no RF exposure calculation is needed.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user

52 mm

08 The Fine Print

is encouraged to try to correct the interference by one or more of the following measures:Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

IC Caution:

English:

This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions:

(1) This device may not cause interference, and

(2) This device must accept any interference, including interference that may cause undesired operation of the device.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. Federal Communication Commission (FCC) Radiation Exposure Statement Power is so low that no RF exposure calculation is needed.

French:

Le présent appareil est conforme aux CNR d' Industrie Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée à la condition que les deux conditions

(1) l'appareil ne doit pas produire de brouillage et

(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même le brouillage susceptible d'en compromettre le fonctionnement.

Le dispositif a été évalué afin de répondre à l'exigence générale d'exposition aux radiofréquences. Le dispositif peut être utilisé dans des conditions d'exposition portables illimitées.

52 mm

09 About Apple Find My

The Apple Find My network provides an easy, secure way to locate compatible personal items or a map using the Find My app on your iOS, iPadOS, or macOS device. Compatible items work with the Apple Find My app to view it right alongside your Apple devices. If your item ever goes missing, you can put it in Lost Mode to be notified when it is found and receive a map of where it might find it. The Find My network is encrypted and anonymous, so no one, not even Apple or the maker of your personal item, can see this data.

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified by the badge, and has been certified by the developer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this product or its safety, compliance or its compliance with safety and regulatory standards.

Apple, Apple Watch, iPad, iPadOS, iPhone, and macOS are the trademarks of Apple Inc., registered in the U.S. and other countries. iOS is a trademark or registered trademark of Cisco in the US and other countries and is used under license.

52 mm

N Tag

User Manual

Works with Apple Find My

折页背面

58 mm

Index

01 Getting Started
02 Add Your N Tag
03 Locate Your N Tag
04 Notifications
05 When Your N Tag Is Lost
06 Resetting N Tag
07 Extras
08 The Fine Print

52 mm

01 Getting Started

01.1 Power On / Off:

Press the N Tag Function Button once to turn it on. It should beep once to indicate that it is powered on.

To power off, hold the same button for at least three seconds. You will hear two beeps to indicate that your N Tag is powered off.

01.2 Check For Updates:

To use the Apple Find My app to locate this item, the latest version of iOS, iPadOS, or macOS is recommended. The Find Items app on Apple Watch requires the latest version of watchOS.

52 mm

02 Add Your N Tag

02.1 Start The App

Open Find My app on your supported iPhone.

02.2 Connect Your N Tag

Press the function button once to power on your N Tag.

Tap+, then "Add Other Item"

Once your N Tag is located, tap "connect"

Enter a name and choose an emoji for your N Tag and tap "Continue"

Find My will ask for confirmation to add your N Tag to your Apple ID Tap "Agree"

Tap "Finish" and your N Tag will be set up and ready to be used

52 mm

03 Locate Your N Tag

03.1 Find N Tag When It's Nearby:

Open Find My app and select the "Items" tab or open the Find Items app on your Apple Watch.

Tap on your N Tag from the list

Tap "Play Sound" to make your N Tag beep.

Tap "Stop Sound" to stop the beeps once you find.

03.2 Find N Tag's Location:

Open Find My app and select the "Items" tab or open the Find Items app on your Apple Watch

Tap on your N Tag from the list

Your N Tag's location will appear on the Map with a time stamp of when the item was located.

To navigate to the N Tag's location, tap "Directions" to open Apple Maps

52 mm

04 Notifications

04.1 Enabling 'Notify When Left Behind':

Open Find My app and select the "Items" tab or open the Find Items app on your Apple Watch.

Tap on your N Tag from the list

Under "Notifications" enable the "Notify When Left Behind" toggle

A screen detailing Lost Mode will pop up, tap "Continue"

Enter your phone number or email address and tap "Next"

You may enter a message that will be shared with the person that finds your item.

Tap "Activate" to enable "Lost Mode"

Note: When "Lost Mode" is enabled, "Notify When Found" will automatically enable.

Note: When "Lost Mode" is enabled, your N Tag is locked and cannot be paired to a new device.

04.2 Enabling 'Notify When Found':

Under "Notifications", enable the "Notify When Found" toggle

When your N Tag is seen by another Find My network device, you will receive a notification of its location.

Note: " Notify When Found" can only be activated when your N Tag is out of range

52 mm

05 When Your N Tag Is Lost

05.1 Enabling "Lost Mode":

Open Find My app and select the "Items" tab or open the Find Items app on your Apple Watch.

Tap on your N Tag from the list

Under "Lost Mode" tap "Enable"

A screen detailing Lost Mode will pop up, tap "Continue"

Enter your phone number or email address and tap "Next"

You may enter a message that will be shared with the person that finds your item.

Tap "Activate" to enable "Lost Mode"

Note: When "Lost Mode" is enabled, "Notify When Found" will automatically enable.

Note: When "Lost Mode" is enabled, your N Tag is locked and cannot be paired to a new device.

52 mm