SPBTRGB 英文说明书

SENTRY INDUSTRIES

SPBTRGB

LIGHT-UP
WIRELESS SPEAKER

LIGHT-UP WIRELESS SPEAKER



Specifications:

Driver Unit: 40mm
Impedance: 32+/- 5ohms
Sensitivity: 120dB+/-4dB
Power: 10mW
Battery: 130mAh cell
Frequency: 20Hz-20KHz
Playback: 4HRS@50% volume
CLASS 1 LED PRODUCT
Communication system: Bluetooth Specification version 5.2 Battery Capacity: 400mAh
Operating Temperature: 0 °C to 40 °C Radio Frequency: 2.402 GHz-2.480 GHz
Note: Actual playback times and charge times are approximate and based on 50% volume, and the product is fully charged. Battery performance may be affected by multiple factors including but not limited to ambient temperature, listening, usage, and/or distance from the source audio device.
USB Type-C® and USB-C® are registered trademarks of USB Implementers Forum.

Bluetooth Pairing/Connection:

Turn on the product. Bluetooth mode will be activated automatically. Enable bluetooth function on your media device. Search the bluetooth device named **SPBTRGB**. Click or tap to connect (pair). After successful connection (pairing), you will hear "connected". Now you can play music, or use bluetooth phone functions.

Key Functions:

On/Off: Press and hold the ⏻ for 3 seconds to turn on/off.
Music Pause: Press the ⏯ button to pause playing, and press the ⏯ again to resume playback.
Volume Increase: Press and hold the ⏯ button. Volume Reduction: Press and hold the ⏮ button.
Next Song: Press the ⏭ button. Previous Song: Press the ⏮ button.
Answer/Hang up: Press the ⏯ button to answer when the call is incoming, and press it again to hang up.
Rejection: Double click the ⏯ button then release it. Change mode: Press the ⏻ button to switch PW mode.
Lighting control: Press the 🔆 button to change the color of the light.
Disconnect: Press and hold the ⏯ button for 3 seconds to disconnect the bluetooth.

Solutions to conventional problems

★ Unsuccessful connection and pairing

1. Check whether the speaker is in the search state, or reboot
2. Too many peripheral Bluetooth devices make searching difficult. Turn off other Bluetooth devices
3. Check if there is any Bluetooth device connected to this machine around. It needs to be disconnected

★ Low or distorted sound

1. Please charge the battery when the voltage is low
2. Check the volume of the Bluetooth device and adjust the volume to a suitable sound level(different songs have different decoding rates and different response sound effects)

3. Restart the Bluetooth speaker and mobile phone digital device Bluetooth connection

★ Music breaks

Whether it exceeds the effective connection distance of the speaker, or whether there is an obstacle between the speaker and the Bluetooth device

Included Cables

USB-C® TO USB-C® Charge cable
Fast charge cable (Note: USB-C cable is the only charging port on your bluetooth speaker. Use a power adapter to charge. Do not use any other charging cable or power adapter. Use only the supplied charging cable or an equivalent cable that is certified for use with this product. Failure to do so may damage your device.)
WARNING: Do not attempt to modify or change the USB-C cable in any way. Doing so may damage your device and void your warranty.

Important Safety Instructions & Warnings

Charging your device

Only use a power adapter with applicable country regulations and international and regional safety standards. Use a power adapter may not be compatible with some countries and only such adapter is recommended to avoid risk of death or injury.

Avoid prolonged skin contact with the charging cable and connector when the charging cable is connected to a power source because it may cause discomfort or injury. Resting or sitting on the charging cable or connector should be avoided.

Important Safety Instructions

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this device near water.
6. Clean only with a dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not charge near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not bypass the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding-type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician to replace the obsolete outlet.
10. Protect the cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the device.
11. Only use attachments/accessories specified by the manufacturer.
12. Unplug this apparatus during lightning storms and when unused for long periods of time.
13. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
14. Headphones are capable of producing sound levels which can be harmful to your hearing. Do not listen at high volume for extended periods of time.

Headphones may block out surrounding sounds.
Never wear headphones while operating a vehicle. Headphones may block out surrounding sounds.
Never wear headphones while operating a vehicle. Use with caution. Use extreme care if ride bicycle with the use of this product.

WARNING

- DO NOT TO prevent electric shock, use only compatible and certified USB charging device.
- **WARNING:** To reduce the risk of fire or electric shock, do not expose this product to rain or moisture.
- Do Not make any changes or adjustments or perform any repairs other than those specified may damage your device.
- **WARNING:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- **WARNING:** Storage area is a safe dry location.
- **WARNING:** Headphones are capable of producing sound levels which can be harmful to your hearing.

Do not listen at high volume for extended periods of time. Headphones may block out surrounding sounds. Never wear headphones while operating a vehicle. Use with caution. Use extreme care if ride bicycle with the use of this product.

- **WARNING:** Do not use in hot or wet areas. Discontinue use if the device gets damaged or broken. Only use designated pads. Do not use this in dangerous pools.
- Contains small parts that may present a choking hazard. Keep away from children.

Important Safety Instructions

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this device near water.
6. Clean only with a dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not charge near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not bypass the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding-type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician to replace the obsolete outlet.
10. Protect the cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the device.
11. Only use attachments/accessories specified by the manufacturer.
12. Unplug this apparatus during lightning storms and when unused for long periods of time.
13. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
14. Headphones are capable of producing sound levels which can be harmful to your hearing. Do not listen at high volume for extended periods of time.

Headphones may block out surrounding sounds.
Never wear headphones while operating a vehicle. Headphones may block out surrounding sounds.
Never wear headphones while operating a vehicle. Use with caution. Use extreme care if ride bicycle with the use of this product.

90-Day Warranty

Sentry warrants this product to be free from defects in materials and workmanship for 90 days from the date of original purchase. This warranty does not pertain to damage resulting from accidents, abnormal use, misuse, or neglect. Any defective product will be replaced if returned to an authorized Sentry dealer or to Sentry directly. P.O. Box 485, One Bridge St., Irvington, NY 10533. Please enclose a check for $5.00 for shipping & handling.

FCC ID: 2ACFKSPBTRGB Model: SPBTRGB

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG,Inc. and any use of such marks by Sentry Industries Inc. is under license. Other trademarks and trade names are those of their respective owners.

Sentry Industries Inc declares that radio equipment **SPBTRGB** is in compliance with Directive 2014/53/EU. The full declaration of conformity is available at https://sentryproducts.com/en/support-declaration-of-conformity/

Conformity with Directives
This product is CE marked to denote conformity with Directives 73/23/EEC (low voltage) and 89/336/EEC (Electromagnetic Compatibility), as amended.
Environmental Protection
Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice.

Supplier's Declaration of Conformity 47 CFR 47 CFR Part 15.21, 15.105(b)

Compliance Information:
Sentry Bluetooth Speaker
Responsible Party –
Sentry Industries Inc.
One Bridge street, Irvington, NY 10533
Tel: +1 845 753-2818

FCC Compliance Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

WARNING: To prevent possible hearing damage, do not listen at high volume levels for long periods. In traffic safety, do not use headphones while driving or cycling. If you have a pacemaker or other electrical medical devices, you should consult your physician before using this product.
Choking Hazard: This product, packaging and some of the included accessories may present a choking hazard to small children. Keep these accessories away from small children. The bags that wrap or the many small parts may contain toxic (poisonous) if ingested.
Danger: Improper battery replacement may cause an explosion and injury.