Hatch Whisper

Quick Start Guide

REV 3

Date: July 21, 2023

Scale 1:1

Full color print, 2 sides

Diecut and fold

Folded size: 112mm x 112mm

Paper Stock:
PURE Super Fine 180g 102061431

Note: Paper stock and print colors should match Rest Go QSG and Restore 2 QSG.

Fold *Fold* *Fold* *Fold*

Front *This panel should face upwards in packaging box*

15mm Radius

Étape 1. Configuration

Téléchargez l'application Hatch et configurez votre Restore 2. Une fois cette opération terminée, accédez à la liste des appareils pour ajouter votre Whisper.

Étape 2. Associez

Suivez les étapes de l'application Hatch pour terminez l'appairage entre Whisper et Restore 2.

Étape 3. Sommeil

Une fois appariés, les sons de Restore 2 seront diffusés par Whisper. Allumez-le, glissez-le sous votre oreiller, logo vers le haut, et laissez les sons apaisant vous submerger.

Contrôles

Indicateur de batterie

- Vert - 100-80%
- Ambre - 80-40%
- Rouge - Moins de 40%

Bouton d'alimentation

- Appuyez et maintenez pour allumer
- Appuyez et maintenez pour éteindre

Astuces Rapides

Conseil du premier soir

Vérifiez l'indicateur lumineux avant d'aller au lit. Vert signifie qu'il durera toute la nuit.

Mise en charge

Chargez votre Whisper chaque matin pour qu'il soit prêt pour la nuit. La batterie durera 10 heures lorsqu'il est complètement chargé. Le chargement de Whisper peut prendre jusqu'à 2 heures.

Volume

Le volume peut être réglé dans l'application et/ou contrôlé par Restore 2.

INFORMATIONS IMPORTANTES SUR LA SÉCURITÉ:

Whisper Pillow Speaker est destiné à être utilisé sous l'oreiller d'un adulte pour favoriser un sommeil réparateur sans déranger votre partenaire. Les utilisateurs sont entièrement responsables du choix du volume et des réglages sonores qui leur conviennent. Consultez toujours votre médecin avant d'utiliser une machine à sons. N'utilisez jamais l'appareil lorsqu'il est en charge, dans ou près de l'eau, ou si le boîtier en plastique est endommagé. Ne jamais démonter.
Tenir hors de portée des enfants.

Le présent appareil est conforme aux CNR d' Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Le présent appareil est conforme Après examen de ce matériel aux conformité ou aux limites d'intensité de champ RF, les utilisateurs peuvent sur l'exposition aux radiofréquences et la conformité et compliance d'acquérir les informations correspondantes.

CAN ICES-003(B)/NMB-003(B)

Meet Whisper

Back *This panel should face downwards in packaging box*

112mm

112mm

Step 1. Setup

Download the Hatch app and set up your Restore 2. Once this is complete, go to the device list to add your Whisper.

Step 2. Pair

Complete the steps in the Hatch app to finish pairing Whisper to Restore 2.

Step 3. Sleep

Once paired, Restore 2 sounds will play through Whisper. Turn it on, tuck it under your pillow, logo facing upwards, and let the soothing sounds wash over you.

Controls

Battery Indicator

- Green - 100-80%
- Amber - 80-40%
- Red - Less than 40%

Power Button

- Press and hold to turn on
- Press and hold to turn off

Quick Tips

First night tip

Check the indicator light before going to bed. Green means it will last the night.

Charging

Charge your Whisper each morning so it's ready to go by evening. The battery will last 10 hours when fully charged. Charging Whisper can take up to 2 hours.

Volume

Volume can be set in app and/or controlled by Restore 2.

IMPORTANT SAFETY INFORMATION:

Whisper Pillow Speaker is intended to be used under an adult's pillow to promote restful sleep without disturbing your partner. Users assume all responsibility for selecting volume and sound settings that are appropriate for them. Always check with your physician prior to using any sound machine. Never use while charging, in or near water, or if plastic housing is damaged or hot. Never disassemble. Keep out of reach of children.

FCC and ISEDC Caution:

This device complies with part 15 of the FCC Rules and Innovation, Science, and Economic Development Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

IMPORTANT NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. The device is in compliance with RF exposure guidelines, users can obtain Canadian information on RF exposure and compliance.

FCC ID: 2AFY2-WHISPER01 / IC: 23920-WHISPER01

Learn More

Pour en Savoir Plus

hatch.co/whisper-support