FRONT

Do Not Return Card

IMPORTANT

PLEASE DO NOT RETURN TO STORE

If You're Having Trouble, We're Here to Help!

STOP

Call us 24/7 at 1-855-292-4087
E-mail us at alsupport@sekar.com or visit us at alteclansing.com

---

ALTEC LANSING

WELCOME

Thank you for purchasing an Altec Lansing product. Download our App to unlock all the features our products have to offer!

ALTEC LANSING

JUST LISTEN.

AquaBliss
Wireless Speaker
QUICK START GUIDE
Item#: INW259

In the Box

A Closer Look



Charging

Connect the USB charging cable into the charging port to charge the speaker.
The speaker indicator will turn red while charging and turn off when it is fully charged.

- **Charging** (continuous red light)
- **Fully charged** (off)

Powering On

Press and hold the power button to turn on the speaker. The LED rapidly blinking Blue indicates that the speaker has entered Bluetooth Pairing mode.

Pairing Mode
Blue blinking LED

BACK

REGISTER YOUR PRODUCT

To receive news, exclusive deals, OTA or firmware updates, warranty information and more please register your product at

alteclansingsupport.com

ALTEC LANSING

ALTEC LANSING

FOLLOW US ON

#myalteclansing
alteclansing.com

12 Month Limited Warranty

All Altec Lansing products come with 12 month limited warranty from the date of its original purchase

24 Hour Customer Support

We love our customers, and we care about your experience with Altec Lansing. If you need assistance, please call us at 1.855.292.4087 or e-mail alsupport@sekar.com
www.alteclansing.com
Altec Lansing Edison, NJ 08817

Bluetooth Pairing

Once the speaker is on, look up for " AL AquaBliss " in your smart device's Bluetooth pairing list. Once pairing is successful, the speaker LED indicator will flash in solid Blue.

Controls

Function	Required action
Power ON/OFF	Press and hold the Power button for 3-5s
Play/Pause Music	When music is playing, press the Play/Pause button to pause the music; press again the same button to resume playing the music.
Accept/end-Reject Call	When receiving an incoming call, press the Call button once to accept call, press again to hang up call. If you press and hold the Call button, it will reject the incoming call instead of picking it up.
Voice Assistant	Press twice the Call button to activate your smart device's voice assistant.
Volume control	Tap the "+" button to increase the volume. Tap the "-" button to decrease the volume
Next / Previous track	Press and hold the "+" button to skip to the next track. Press and hold the "-" button to return to the previous track.

Notes

"To use voice assistant, you must have a phone that is equipped with a voice assistant.

"You must be within Bluetooth range to use voice assistant via your speaker.

Your speaker's voice assistant feature will not work if a voice assistant is not first enabled within the settings on the phone. For more information, see your phone's user manual

For additional user materials and warranty information, please visit alteclansing.com

---

Notes

FIRST

FCC ID: 2ALBS-INW259

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or TV reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
– Reorient or relocate the receiving antenna.
– Increase the separation between the equipment and receiver.
– Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
– Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:
This device has been evaluated to meet general RF exposure requirement. The device can be used in the portable exposure condition without restriction.
This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

FOLLOW US ON
#myalteclansing
alteclansing.com