Kzzi I75Pro MECHANICAL KEYBOARD



FCC WARNING:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pourtsuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

WHEN USING A KEYBOARD:

1.Maintain proper posture and avoid excessive force on the keys.
2.Take regular breaks to prevent hand fatigue.
3.Clean the keyboard regularly to remove dust and dirt.
4.Avoid exposing the keyboard to liquids.
5.Keep the keyboard in a suitable environment, free from extreme temperatures or humidity.

Remember these tips for a comfortable and durable keyboard experience.

WARRANTY 12 MONTHS WARRANTY

GUARAN
Non-human d
12-month wa

产品基础
PRODUCT BASIC INFORMATION

说明书 Manual | 拔轴拔键器 Switch and Keycaps Puller | 键盘 Keyboard | Type-C 数据线 Type-C Cable | 2.4G接收器 2.4G Receiver

旋钮功能
KNOB FUNCTION



长按旋钮三秒切换旋钮模式
Long press knob for 3 seconds to switch knob mode

音量模式（默认）：顺时针音量加、逆时针音量减、按压静音
Volume Mode (default): Clockwise Volume Up, Counterclockwise Volume Down, Press to Mute

背光模式：顺时针背光亮度加、逆时针背光亮度减、按压切换灯效
Backlight mode: clockwise backlight brightness plus, counterclockwise backlight brightness minus, press to switch the light effect

尺寸/Size	Layout	版本/Version	背光/Backlit	轴体/Key Switches
327.5(L)×150.71(W)×30.03(H)±2	80 keys	有线/2.4G/BT USB-C wired/2.4G wireless/BT	RGB	矮轴 low profile switch

有线模式
WIERD MODE

1



有线模式：连接USB至设备，电源开关拨到中间挡位为有线模式
Wired Mode: Connect USB to the device and pull the power switch to the middle position for wired mode.

BT连接
BT CONNECTION

1 **BT配对方法**
BT Pairing Method

1.开关拨到B状态
Switch to B

2.FN+Q / W / E 任意一组长按对码，比如长按Fn+Q，此时Q键快速闪烁，表示已进入配对状态，慢闪标表示键盘在回连状态
FN+Q / W / E, any group of long-press pairing code, for example, long-press Fn+Q, at this time, the Q key flashes quickly, indicating that it has entered the pairing state, and the slow flash indicates that the keyboard is in the back-connecting state.

3.打开电脑/手机BT，搜索并连接设备，搜索显示的名称：Kzzi-I75 3.0（连接PC端Windows7以下系统），Kzzi-I75 5.0（连接Windows8以上系统版本，移动设备等）
Open PC/Mobile BT, search and connect the device, the search shows the name: Kzzi-I75 3.0 (connect to PC with Windows 7 or below), Kzzi-I75 5.0 (connect to Windows 8 or above system version, mobile devices, etc.)

4.完成连接
Completing the connection



以此类推：重复以上步骤，Q/W/E/可存储3组BT设备，在使用切换时 短按Fn+Q/W/E,即可在不同BT设备之间切换（温馨提示：使用切换前，请先配对好3组BT）
And so on: Repeat the above steps, Q/W/E/can store 3 groups of BT devices, when using the switch Short press Fn+Q/W/E, you can switch between different BT devices (Warm tips: before using the switch, please pair up the 3 groups of BT)

2.4G连接
2.4G RECEIVER CONNECTION

1 **键盘开关拨到2.4G状态**
Switch to 2.4G

2 **2.4G配对方法**
2.4G pairing method



开关拨到2.4G状态，长按FN+P对码，P键快速闪烁插入接收器，P键停止闪烁即对码成功。
Switch to 2.4G，Long press FN+P to pair code,P key blinks to insert the receiver, P key stops blinking that means code pairing is successful.

3



（温馨提示：出厂时已配对好接收器，无需自行再次配对2.4G；此方法只是2.4G无法连接的时候使用，首次设置即可，无需每次都设置）
(Tips: The receiver is set to be paired at the factory You just need to set it only once, when pairing not working properly.)

指示灯
INDICATOR LIGHT

轻触开关：显示桌面功能
Tap this key: Quick desktop view switch

（出厂默认为显示桌面，如果想更换其它功能，可自行用驱动程序自定义更改按键功能）
(The factory default is to display the desktop, if you want to change other functions, you can use the driver to customize the function of the key)

1.Win Lock(白光)
Win Lock (white light)

2.充电指示灯（红光）,充电常亮，充满熄灭，低电量闪烁
Charging indicator (red light): Charging (solid), Fully charged (off),Low battery (flashing)

电池电量提示
BATTERY LEVEL CHECK

键盘背光可显示当前电池电量状态
The keyboard's lighting can display the current battery level status

(无线模式下查看)
View in wireless mode

按FN+ENTER 查看电池电量情况
Pressing FN+ENTER allows you to view the battery level status.Each key from "1" to "0" represents a specific battery level range.

比如：
For example:

1 背光亮 表示此时键盘10%的电量
The backlight of the "1" key is illuminated, indicating that the keyboard's current battery level is at 10%.

1 - 0 背光同时亮，表示此时键盘20%的电量
The "1" and "2" keys are both illuminated, indicating that the keyboard's current battery level is at 20%.

以此类推
Similarly

1 - 0 背光同时亮，表示此时键盘电量 100%
When the backlighting illuminates from 1 to 0 simultaneously, it indicates that the keyboard battery is at 100% charge.

背光控制
BACKLIGHT CONTROL



Fn + \ **支持多种背光效果切换**
Multiple backlight effects switch

Fn + △ **背光亮度 +**
Backlight brightness +

Fn + ▽ **背光亮度 -**
Backlight brightness -

Fn + WIN **窗口锁定**
Windows lock

Fn + ' **背光单色切换**
Backlight monochrome switching

Fn + ◁ **背光速度 -**
Backlight speed -

Fn + ▷ **背光速度 +**
Backlight speed +

Fn + space bar **长按3秒，恢复出厂设置**
Long-press for three seconds to restore factory settings

FN组合键功能
FN KEY COMBINATION FUNCTION

Fn + Del — Prtsc

Fn + PgUp — Home

Fn + PgDn — End

Fn +] } — Ins

Fn + [{ — ScrLk

Fn + ' " — Pause

Kzzi I75Pro MECHANICAL KEYBOARD



ISED STATEMENT:

English:This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:
(1) This device may not cause interference.
(2) This device must accept any interference, including interference that may cause undesired operation of the device.
The digital apparatus complies with Canadian CAN ICES-3 (B)/NMB-3(B).
French: Cet appareil contient des émetteurs/récepteurs exempts de licence qui sont conformes aux RSS exempts de licence d'Innovation, Sciences et Développement économique Canada.
L'exploitation est soumise aux deux conditions suivantes :
(1) Cet appareil ne doit pas provoquer d'interférences.
(2) Cet appareil doit accepter toute interférence, y compris les interférences susceptibles de provoquer un fonctionnement indésirable de l'appareil.

Appareil numérique du client conforme canadien pend. ~3-0(c) nmb ~ 3 (b).
This device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS 102 RF exposure, users can obtain Canadian information on RF exposure and compliance.pel appareil est conforme à l'exemption des limites d'évaluation courante dans la section 2.5 du rss ~ 102 et conformité avec rss 102 de l'exposition au rf, les utilisateurs peuvent obtenir des données canadiennes sur l'exposition aux champs rf et la conformité.
This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment.Cet équipement est conforme aux limites d'exposition aux rayonnements du Canada établies pour un environnement non contrôlé.

BATTERIES:

A warning that batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the light.
1) Replacement of a battery with an incorrect type that can defeat a safeguard.
2) Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion;
3) Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas.
4) A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

WARRANTY 12 MONTHS WARRANTY

GUARANTE
Non-human dama
12-month warran

背光录制
BACKLIGHT RECORDING



WINDOWS多媒体键
WINDOWS MULTIMEDIA KEYS

Windows模式下（FN+A：切换到Windows系统）
In Windows mode (FN+A: Switch to Windows system)

Fn + F1 屏幕亮度- Screen Brightness-	Fn + F4 计算器 Calculator	Fn + F7 上一曲 Previous Song	Fn + F10 静音 Mute
Fn + F2 屏幕亮度+ Screen brightness +	Fn + F5 播放器 Media Player	Fn + F8 播放/暂停 Play/Pause	Fn + F11 音量- Volume -
Fn + F3 邮箱 Email	Fn + F6 停止 Stop	Fn + F9 下一曲 Next Song	Fn + F12 音量 + Volume +

MAC多媒体键
MAC MULTIMEDIA KEYS

Mac模式下（FN+S：切换到MAC系统 MAC系统视窗键和ALT键互换）
In macOS mode (FN+S: Switch to macOS system)

F1 屏幕亮度 - Screen Brightness -	F4 搜索 Search	F7 上一曲 Previous Song	F10 静音 Mute
F2 屏幕亮度 + Screen Brightness +	F5 siri	F8 播放/暂停 Play/Pause	F11 音量- Volume -
F3 多屏显示 Multiscreen Display	F6 勿扰（仅在有线模式下支持） Do Not Disturb (only supported in wired mode)	F9 下一曲 Next Song	F12 音量 + Volume +

Thank you for choosing KZZI products! If you have any questions or need assistance, please feel free to contact us. Our team is dedicated to providing support and addressing your inquiries.

We highly value your feedback and suggestions as they help us continuously improve and enhance product quality. Once again, we appreciate your support for KZZI!

Kzzi

服务热线：400-0221-288
邮箱：kzzi@kzzi.com
官网：www.kzzi.com
品牌方：珂芝(惠州)电子科技有限公司
执行标准：GB / T 14081-2010

Hot-line:400-0221-288
Email:kzzi@kzzi.com
Official Website: www.kzzi.com
Brand：Kezhi(huizhou)Electronic Technology Co., Ltd
Executive standard：GB / T 14081-2010

166-66101-02